



Removing Washable Marker

Marker ink washes from skin with warm, soapy water. If markers come in contact with washable fabrics, immediately launder in hot water and detergent without pre-wash solution or chlorine bleach. Repeat wash cycle if necessary. Keep markers away from wallpaper, painted walls, finished and unfinished wood, vinyl, carpeting, countertops, and other stainable materials. Markers are intended for external use only and should not be ingested. These instructions are provided as a courtesy to Ozobot customers. We cannot be held responsible for the results obtained from these washing instructions.

Ozobots conform to the requirements of ASTM standard consumer safety specifications on Toy Safety F963. Markers conform to ASTM D4236.

Battery is 3.7V, 135mAh (3.7*0.135=0.500W).

Product and colors may vary. The toy contains batteries that are non-replaceable. Please retain this packaging for future reference.

Not recommended for children under the age of 6.

For more information please contact us at info@ozobot.com

Product name: OZOBOT Evo

FCC ID: 2A6UW-040101

IC: 28624-040101

Charging Instructions

To charge your Evo Classroom Kit, simply drop the robot wheels-down in the cradle to begin wirelessly charging. Green LEDs will flash to indicate charging is in progress and light up solid green when charge is complete.

User Manual

Go to ozo.bot/manuals. The information provided in the user manual is for reference purposes only and may be modified. The latest version of the manual can be found at ozobot.com/manuals.

Not all devices are compatible. Check ozobot.com/devices for more information.

Limited Warranty

Ozobot limited warranty information is available online: ozobot.com/supply/warranty.

Battery Warning

To reduce risk of fire or burns, do not attempt to open, disassemble, or service the battery pack. Do not crush, puncture, short external contacts, expose to temperature above 60°C (140°F), or dispose of in fire or water.

The transformer, power supply or battery charger used with the device are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired. Battery is 3.7V, 135mAh (3.7*0.135=0.500W).



Input: 5V === 0.5A

This toy is only to be connected to equipment bearing either of the following symbols.



Use only with the output of charger is 5V DC, 0.5A supply.



WARNING: For the purpose of recharging the battery, only use the detachable supply unit provided with this toy (output of charger is 5V DC, 0.5A).



WARNING:

CHOKING HAZARD—

Toy contains a small ball and small parts. Not for children under 3 years.

WARNING: This toy produces flashes that may trigger epilepsy in sensitized individuals.

Model: 040101

SKU: 051810-01-03

Manufactured by Ozobot

©Ozobot | ©2022 Ozo Edu., Inc.

3 Corporate Plaza Drive,
Suite 100,
Newport Beach, CA 92660

ozobot.com

Rev 1 - 22



Evo

by ozobot

FCC ID: 2A6UW-040101

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

IC: 28624-040101

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC AND IC RADIATION EXPOSURE STATEMENT:

This equipment complies with FCC and Canada radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Ozobot Evo is a USB-compatible device. Use the micro-USB port for charging and file transfers of user OzoBlockly programs.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Ozobot Evo can operate to a high rate of speed. Use with caution when playing on elevated surfaces.

The product may turn off during use in the presence of electrostatic discharge (ESD). Normal operation can be resumed by restarting the device.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Ozo Edu., Inc. dba Ozobot is under license.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

CAN ICES-3 (B) / NMB-3 (B)

Model: 040101

Products and colors may vary.

For more information contact us at info@ozobot.com

Bluetooth Technical Specifications:

Frequency Range: 2402-2480 MHz

Max Output Power: 0dBm

Bluetooth Version: v5.2

Battery Type: Lithium ion

Hereby, Ozo Edu., Inc. declares that the ozobot Evo is in compliance with RED 2014/53/EU. The full text of the EU DOC is available at the following internet address: ozobot.com

