



Content

1 The Introduction of Shape and Button.....	2 -
2 Turn on/ Shut Down	3 -
3 Screen Lock/Unlock	3 -
4 Menu Options	3 -
5 Virtual Keyboard & Input Method.....	4 -
6 WIFI	4 -
7 Download APK program & installation.....	4 -
8 Charge the unit	5 -
9 Use Guidelines	5 -
10 Conditions of Guarantee.....	5 -

1 The Introduction of Shape and Button



keys function description:

1. Camera	9. Mini-HDMI Port
2. Display (800x480)	10. USB/PC Connector (OTG)
3. Status light	11. Charger Port (5V DC)
4. Back (Soft Key)	12. Power ON/OFF Button

5. Home (Soft Key)	13. Volume Up Button
6. Menu (Soft Key)	14. Volume Down Button
7. MIC	15. Micro-SD Port
8. Headphone Port (3.5mm)	16. Speaker

2 Turn on/ Shut Down

- 1、 Turn on: Long press power key for 3 - 5 seconds to turn on.
- 2、 Shut down: Long press power key for 3 - 5 seconds, choose-shut down- OK


3 Screen Lock/Unlock

- 1、 Lock: Short press power key, screen will enter into black and locked.
- 2、 Unlock: Short press power key, and the screen will light up. Then, sliding the



unlock circle to the "tapered end" to open the lock.


4 Menu Options


- 1、 Click " " on home screen, then enter into a list of programs;



- 2、 Click  on the home screen, return to the higher level menu for



level; Click  on the left bottom corner of the screen, return to main menu;

- 3、 Click " "on the upper right corner of the screen, jump out of the menu options



5 Virtual Keyboard & Input Method

- 1、 Tap any browsing bar:



- 2、 Virtual keyboard will be pop out on the screen bottom:



- 3、 Tap the browsing bar to change language.
- 4、 Tap  to change to digital & symbols menu.
- 5、 Tap  to choose case letters.
- 6、 Tap "ENG" or "CN" to transfer between English and Chinese input (in Chinese input condition).
- 7、 Tap "GO TO" to your input web after your input.

6 WIFI

WI-FI connecting instruction:

1. Tap "WI-FI" in "WI-FI & Network" interface.
2. Tap "WI-FI" setting.
3. Tap the WI-FI account you want to connect.
4. Input the password in the pop out dialog box to connect the WI-FI account.

7 Download APK program & installation

- 1、 Please make sure your WIFI connecting is OK.

- 2、 Go to any web to download ".apk" program (it would be application program or games), choose the APK you want to install, the system will confirm the installation with you, confirm your choosing, the system will install the APK automatically. You can also uninstall any APK program after your enter it.

8 Charge the unit

- A. Output voltage: 5V~5.5V
- B. Input voltage: 1500mA~2000mA

Attention: It is forbidden to use any other chargers not comply with the above specification. Or, we would not be responsible for the faulty.

9 Use Guidelines

- *Store the unit & accessories in a safe place, away from headwaters.
- *Only use the original accessories, any un-authorized accessories would damage the device or shorten its working life.
- *Avoid any weight or slide from high place, do not make the device in forced service.

Conditions of Guarantee

1. For the guarantee to be carried out, all products must be delivered to IJOY perfectly packed, preferably in its own original packing, with all accessories, user manuals and drivers that the packaging would originally contain. Otherwise, IJOY will not be held responsible for damages that might occur during transportation.
2. To be able to carry out the guarantee it will necessary to have a copy of the proof of purchase, preferably with a copy of the original bill.
3. The repair of the products will be carried out according to the problem reported by the client; therefore it is essential that the client indicates in a clear form and in the most specific way possible where the problem lies, to be able to solve it in the correct manner. In the case that there is not problem with the product a diagnosis and transportation charge can be applied.
4. The client must have carried out a security copy of the data as during the reparation process there exists the possibility that such data may be lost and/or erased. In any case IJOY will not be held responsible for the loss of data contained in hard drives, as well as any other non –original accessory, might there be batteries , memory cards, CD's DVD's, etc.
5. In the case that there is no possibility of repair of the product, it can be replaced by another one of similar or superior characteristics, taking into consideration the state in which the product is received, such as usage marks , scratches, etc. In any case the product returned to the customer will have been tested to be functioning correctly.
6. The Guarantee will only cover errors caused by deficiencies in manufacturing, and does not therefore cover damage caused by mis-use, modifications or damages caused by accidents of any nature of caused by the client. The guarantee does not cover: Accessories, pieces exposed to normal wear and tea. The Guarantee will not be valid when the product is not used for the purpose for which it was originally conceived.
7. In the case of TFT, there exists what are known as *dead pixels* or *bright dots* (due to the complexity of the manufacturing process), in such cases, there exists a maximum limit permitted by law (ISO 13406/02) that allows this not to be considered defective.
8. The power supplies or chargers and batteries will have a guarantee limited to six months as long as they used within the established operating conditions for the correct usage have not been exposed to power surges.
9. It will be necessary that the equipment has a legible serial number, that the guarantee seal has not been manipulated and in perfect state; that the equipment has all original

seals in all components so that the guarantee is valid.

10. The guarantee period starts in the moment of first purchase of the product. The reparation or substitution of the product will not imply an extension of the guarantee period.
11. In the case that the product is not covered by the guarantee, a budget will be drawn up which has to be approved by the client. In the case that the budget is not approved by the client, the client must pay for the cost incurred in the transportation, manipulation and diagnosis of the product.
12. Once the product is repaired after notifying the client, the client will have a period of ten working days to pick up the product. After this period of time, a daily storage charge will be applicable depending on the volume of the product.

i-Joy

C/ Mario Roso de Luna, 31 · P.I. Fin de Semana · 28022-Madrid (Spain)

Tel. +34 902 55 55 60

E-mail: rma@i-joy.es (Under warranty) | postventa@i-joy.es (Technical doubts)

Web: www.i-joy.es