


材质：157G双铜，规格：单页尺寸，90*150 双面彩色印刷，折页



User Manual

Arteck K730 Wireless Keyboard

Arteck™

Welcome

Thank you for choosing this Arteck K730 wireless keyboard. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep the manual for future reference.

Product Specifications



Wireless Specification	2.4G USB Wireless
Operating Range	Up to 10 Meters
Modulating System	FSK
Operating Voltage	3.0-4.2V
Operating Current	<20mA
Standby Current	0.2mA
Sleeping Current	<10mA
Standby Time	>200 days
Uninterrupted Working Time	>250 hours
Battery Type	AAA batteries
Key Strength	50~80g
Key Life	3 million strokes
Operating Temperature	-10 ~ 50°C

Package Contents:

Arteck K730 Wireless Keyboard	1
USB nano 2.4G receiver	1
AAA Battery (installed at the battery holder at the back of keyboard)	1
User manual	1

Getting Started Guide

1. Product Overview

1. Power Indicator: Lights up green for about 3 sec when being powered on.
2. Low Battery Warning: Red light will be flashing when the battery is running out.
3. CAPS Lock Indicator: Green light on when CAPS lock is on.
4. Number Lock Indicator: Green light on when number lock is on.
5. Nano 2.4G USB Receiver Storage Box
6. Foldable raised stand legs

2. Function Keys

Mute	Volume down	Volume up
Previous Track	Play / Pause	Next Track
Brightness down	Brightness up	Calculator
Search	Settings	Connect the PC to other devices
Computer	Press Fn+Esc to Turn on/off Lock	

Caution:

- When not in use for a prolonged period, it is recommended that you take off the battery to lengthen the battery life.
- When the power status light flashes, it is recommended that changing the battery in 2 hours.

Energy-saving Sleep Mode

Keyboard's long life battery lasts for several months of normal use. The keyboard will go into sleep mode not being used in several minutes. Press any key and wait a second or two to bring it out of sleep mode.

4. Safety Caution

- Keep the item away from sharp objects.
- Do not place heavy object on the keyboard.
- Away from microwave items.
- Do not force or distorted the keyboard.
- Keep away from oil, chemical or other organic liquid.

5. Disposal of Waste Batteries


Insert screwdriver between plastic top and metal case at keyboard top or bottom and Pry up plastic top and remove it completely. This action destroys keyboard separate battery from circuit board. It is your responsible to hand this over to an applicable collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous in batteries and electrical and electronic equipment.

Warranty

Our company provides customers with a warranty of 24 months from the date of purchase.

Contact Us

For any inquiries or comments concerning our products, please send an email to support@artek.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a replacement or refund by submitting a request to support@artek.com.



2 Years Warranty Claim Email: support@artek.com

1

2

3

4

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:- Reorient or relocate the receiving antenna.- Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.