User Manual

Instruction Manual for Wireless Microphone

CE FC ♻ 🗑 ℗ ☑
RoHS

MADE IN CHINA

Product Introduction

Thank you for choosing our products

This product is an intelligent wireless microphone that can provide professional-level recording output. It is plug-and-play and does not require an APP. It has multiple uses and can be applied in various scenarios such as live streaming, video VLOG shooting, program interviews, interview recording, and video teaching.

This product consists of three parts: the charging case, the microphone transmitting end and the receiving end.

(As shown in the following picture, subject to the actual item)

One to Two

①Battery indicator ②Charging port

①Charging compartment digitally displays power level

②Charging interface: Type-c charging input

Important note: The product does not support fast charging, please use

5V1A power adapter to charge the product, exceeding the rated

Fixed power can easily cause malfunctions.
(The product does not come with a power adapter)

(2) Receiver function introduction

① Microphone 1: Ice blue light when the receiver and microphone are not connected

(3) Transmitter (collar microphone) function introduction, already

When connected, the ice blue light is always on

② Microphone 2: When the receiver is not connected to the microphone, the ice blue light flashes, and when it is connected, the ice blue light is always on.

③Mobile phone interface: The receiver can be directly plugged into the mobile phone for use

Type-c charging port

Lightning charging port

④Charging port: Type-c charging port

Note: If some brands of mobile phones cannot connect normally, please go to

Go to settings (search for "OTG" - turn on OTG power supply) to use it normally.

The ice blue light on the receiving end is always on, and the microphone can be used to receive sound by opening the camera, live video, and other apps on the phone.

The indicator light remains on constantly

Note: Receiver: Connected, the ice blue light is always on

(3) Transmitter (collar microphone) function introduction

② ④
③
①

① Turn on/off the machine
② Microphone clip
③ Microphone indicator light
④ Radio Microphone

Special Notes:

The usage is as follows: There is no battery in the receiving end, so it does not need to be charged during live broadcast. If the battery of the mobile phone is low during live broadcast, charge the mobile phone directly through the interface of the receiving end.

NOTE:

It is necessary to use a charging head or power bank with a capacity of 5V1A or above to charge. It is not recommended to use a fast charging head, as the fast charging head cannot power the device. Even if it can power the device, it will affect the life of the device's receiver or burn it out.

How to use

(1) How to connect to a mobile phone to record audio/video

Step 1: Long press the transmitter (collar microphone) to turn it on;

Step 2: Insert the receiver into the mobile phone to complete the connection;

Step 3: Turn on the default noise reduction mode, open the phone camera or shoot APP to record audio and video

(Note: Due to system limitations, some Android phones do not support external device recording.)

(2) How to connect to mobile phone live broadcast

Microphone Transmitter

Function/Status	button	Lighting
Power on	Long press the power button for 3 seconds to turn on the device	Ice blue light flashing
Power off	Long press the power button for 3 seconds to turn off the device	All lights off
Not connected		Ice blue light flashing
Connected		Ice blue light on

Product Parameters

Pointing Type	Omnidirectional	Rated input	DC5V-1A
Frequency range	2.4G	Standard charging time	About 1 hour
Frequency response range	20HZ-20KHZ	Working hours	About 6 hours
2.4G transmission distance	≥30 meters	Charging port	Type-c interface
Signal-to-Noise Ratio	≥75dB	Operating temperature	-5℃-40℃
Battery capacity	80mAh/3.7V	Storage temperature	-10℃-50℃

Frequently asked questions

1. Why can't I record normally when connected to a mobile phone?
. Please check whether the connection indicator lights of the microphone and the receiver are on normally
. Please check whether the microphone has sufficient power. If it is low, please charge it in time
. Some brands of mobile phones need to update the mobile phone version (Settings> My Devices> Check for Updates).
. Some brands of mobile phones need to turn on the "OTG" function and turn on the external recording device.
. If you wear a mobile phone protective case, the receiving end will have poor contact. You need to take out the protective case and try again.
Step 1: Turn on "OTG" process: Mobile phone settings> OTG> Turn on (or search for "OTG" in the search box in settings and turn it on) to use it normally.
Step 2: Some mobile phones need to turn on the external device process: Settings> Sound and Vibration> More Sound Settings>

Warranty scope: If there is no artificial damage, the whole machine will be replaced within 7 days and one year free warranty.

Product warranty card
Product Model
Purchase Date
Distributor
Maintenance records
Customer Name
Contact Number
Contact Address

Precautions

1. Please disconnect the charger and turn off the machine before cleaning it.
2. Non-professionals should not disassemble the device by themselves to avoid machine failure and loss of warranty rights.
3. Do not place the device in direct sunlight to avoid premature aging of electronic parts.
4. Avoid using it in dusty or dirty places (dust can easily cause equipment failure)
5. Do not place the device in an overly cold or overheated environment, which will cause the device to fail to operate normally.
6. It is recommended to set the ambient temperature not to exceed -10° -40° C and the relative humidity to 10%-95%.
7. Do not put any objects into the device to avoid causing mechanical short circuits or circuit damage. Do not spill any liquid on

Noise reduction level	Default noise reduction at power on	Built-in AI noise reduction
Leaking	Triple-click the button to switch between leakage and default noise reduction	Ice blue light flashes once
	Need to open manually; click three times again to exit the leak	Then the ice blue light is on
Mute	Double-click to mute, double-click again to restore	
Charge		Digital display charging

Receiver

Function/Status	Button	Lighting
Power on	Plug in the device and power it on	Ice blue light flashing
Power off	Unplug the device to cut off power	Lights out
Search for matches		Ice blue light flashing
Pairing successful		Ice blue light is always on

Step 1: Take out the transmitter charging case and turn it on;

Step 2: Insert the receiver into the phone to complete the connection;

Step 3: Switch the transmitter to the desired effect, open the live broadcast APP on the phone to carry out live broadcast and sales, etc.

Dimensions (transmitter)　　　　41×25×19（mm）

Rated power consumption　　　　0.5W(DC5V/0.1A)

Charging port: Type-c charging port Standard charging time: about 2 hours

Battery capacity: 600mAh/3.7v Working time: about 6 hours

Rated input: DC5V1A Dimensions: 69X57X34(mm)

Rated power consumption: 2.5W(DC5V/0.5A)

Default Recording Device> External Device.
2. The microphone cannot record for the camera APP that comes with the device?
. Some Android phones, generally 2% of the models have incompatible built-in cameras, and need to download Douyin Beauty Camera, etc.
Step 3: The video shooting APP can be used, but the microphone is blocked from obtaining audio permissions. This is not due to the quality of the microphone. Please contact the brand mobile phone. This product is compatible with most brands and models of mobile phones on the market

Note: Our company's products are constantly innovating, and any changes will not be notified separately

this product.
8. Avoid friction and collision between the machine and hard objects to avoid surface scratches, shedding or other hardware damage.
9. The product must not be exposed to sunlight, fire or similar overheating environments.
10. This manual contains important information, please keep it.