

# MBUDS 106 TWS EARBUDS

**User Manual** 



# **Appearance:**

- 1 Left Ear Piece
- 2 Right Ear Piece
- 3 Multi-Function Touch Area
- 4 Left Earpiece Charging Socket
- 5 Right Earpiece Charging Socket
- **6** USB Type-C Charging Port
- 7 Microphone
- 8 Charge/Storage Case
- 9 Carry Strap

## **Charging:**

## Charge/Storage Case:

 Connect the case to a charger using a USB Type-C cable to charge the Charge/Storage Case.

## **Earbuds:**

- Place the earbuds in the charged Charge/Storage Case to charge the earbuds.
- \* Note: Please take off the sticker peels attached to the earbuds before you charge them.

## To Connect:

 Charge the Charge/Storage Case and the Earbuds at least 70% before the first usage.

# **Pairing Process:**

1. Take out the Earbuds from the Charge/Storage Case and place them in your ears.

- 2. Go to the Bluetooth settings of your device and switch it on.
- 3. Scan available devices.
- 4. Connect 'Mobilla MBuds 106' to your device

After completing the pairing process, the TWS earbuds will connect to your device automatically when you take them out of the charging/storage case.

## **Smart Touch:**

# Play/Pause:

Single tap on the Multi-Function Touch Area.

## **Repeat Track:**

 Double Tap on the Multi-Function Touch Area of the left earbud.

#### **Next Track:**

 Double Tap on the Multi-Function Touch Area of the right earbud.

#### To Increase Volume:

 Triple Tap on the Multi-Function Touch Area of the right earbud.

## To Decrease Volume:

 Triple Tap on the Multi-Function Touch Area of the left earbud.

# To Answer/Hang Up Calls:

 Single tap on the Multi-Function Touch Area of either earbud.

## To Decline Calls:

 Tap and hold on to the Multi-Function Touch Area of either earbud.

## Power On/Off:

 Long press for 4 to 5 seconds on the Multi-Function Touch Area.

#### **Call Voice Assistant:**

 Tap & Hold for 2 seconds to activate the Multi-Function Touch Area of either earbud.

# **Specifications:**

- Bluetooth Version: 5.3
- Music Playtime: Up To 25 Hours
- Environmental Noise Cancellation
- Sweat and Water Splash Resistant: IPX4 Rating
- 13mm Drivers



