

Instructions-

Warning: In order to make the lamps installed correctly, when unpacking the case, please read this manual in detail, and properly keep !

Name: TRIBURST Active Blue SNR 5500L

Model: 8169

Specification: 120V~ 60Hz, 60W, IP20, E26

Product Description : TRIBURST Active Blue SNR 5500L with Lighting Equipment

MADE IN CHINA

INSTALLATION - No tools required.



Turn the power OFF using the light switch for that socket before installing the lamp

Remove the protective cap.

Screw the counterclockwise if the light socket is facing downward (ceiling).

Screw it in clockwise if light socket is facing outward (wall) or upward. DO NOT OVERTIGHTEN.

Turn the Tri Burst ON/OFF using the light switch for that socket.

Adjust the LED panels to the desired position.

Panels move up/down.

IMPORTANT SAFEGUARDS:

- Due to intensity LED bulbs, do not stare directly into the LED light.
- Risk of electric shock.
- This product is intended for dry location
- Use in open luminaire only.
- Do not use with dimmers.
- For indoor use only.
- Added weight of the device may cause instability of a free standing portable Luminaire
- this device is not intended for use with emergency exits
- This product has radar sensor function
- When this product senses a moving object, it will automatically light up.
- When no moving object is sensed for more than 30 seconds, it will automatically go out.
- There are mechanical buttons on the surface of this product, which can be used to

control the on and off of the radar sensor function.

- **Treatment of the lamp**

- Please don't drop the lamp or push against it.
- Please don't disassemble the lamp, don't make alterations.
- Be aware that stability of the mechanical parts of the lamp may be reduced when the new lamp is obviously heavier than the old one.

- **Installation**

- The lamp can not be dimmable.
- Don't install inside a recessed area in the wall.
- Don't use lids without ventilation openings.
- Don't cover with a glass bowl.
- The lamp must be installed steady in the socket.
- Don't install the lamp near to heat resource, vapor or corrosive gas location.
- The lamp is not suitable for enclosed fixture.



- Use in Dry Location only.

- **Electrical connection**

- Use only in indoor areas.
- Don't use as emergency lighting.
- To avoid electrical shock, don't install in damp or wet locations.
- When turn on the lamp, make sure no flammable material near to the lamp.
- The lamp only works with 120V~ 60Hz
- Please turn off the power supply before any replace lamp or maintenance.

- **Remarks**

- Don't touch the lamp directly with your hand or face when it is in use to avoid burns.
- If the lamp is damaged, replace it by a new one and don't try to repair it in order to avoid hazards.
- If this lamp should be replaced by a heavier one, please take care that the mechanical stability of the luminaire could be impaired by the increased weight.
- Don't look at the lamp directly.
- Keep the lamp away from children
- LED chips cannot be replaced
- When the lamp works abnormally, please cut off the electricity immediately. And contact professional electrician to repair.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

ISED Canada Statement:

This device contains licence-exempt trasnsmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada 's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment

RF Exposure Statement

To maintain compliance with IC's RF Exposure guidelincs, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter