

200MM

反面

STEP 10

Mount the switch

STEP 11

Turn on the power

12

IMPORTANT

This product needs to charge the supercapacitor at the first time power-on. The charging time will take about 5-7 minutes. It will be slightly different depending on the load power and type.

Charge time

7 mins

Flicker dure charging

The light may turn on or flicker during the charging process, this is normal situation, and the light will automatically go off after the charge is completed, the switch needs about 1 more minute to initialize, and then it will enter the normal working state.

13

STEP 8

Quick Configuration Mode

- Press and hold Switch button for 8s to reset the Switch and get into quick configure mode
- Select the Wi-Fi and enter the password then click Next
- Wait for completing the connection.

STEP 9

All added devices can be viewed in the main menu of the APP

STEP 10

Control switch with APP

14

08 Add Devices

STEP 1

Download MOES APP

STEP 2

Registration or Login in

- Download "MOES" Application
- Enter the Register/Login interface: tap "Register" to create an account by entering your phone number to get verification code and "Set password" choose "Log in" if you already have a Smart Life account.

STEP 3

Configure the APP to the switch

- Preparation: Ensure the switch has been connected with electricity/ensure your phone has been connected to Wi-Fi and is able to connect to the internet.

Note: The switch only supports 2.4G network. If you have connected 5G network, please disconnect 5G network firstly and connect 2.4G network.

15

Remark: Smart phone and device must connect to same Wi-Fi during setup mode. The device must be added to the account before it can be controlled remotely. After the device is successfully accessed, other users can obtain control of the product through the sharing function.

- Wait system to search the device, connect and configure the device will takes up to 3min.
- Once the device configure successfully, please also input preferred name and select location.

16

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

17

10 Control your home with your voice

Control your home with your voice Devices are compatible with Amazon Alexa and Google Home supported functionalities.

Please see our step-by-step guide on: <https://www.moestech.com/blogs/news/smart-voice-linked-voice-speaker>

18

11 Control your home with your voice

Control your home with your voice Devices are compatible with Amazon Alexa and Google Home supported functionalities.

Please see our step-by-step guide on: <https://www.moestech.com/blogs/news/smart-voice-linked-voice-speaker>

19

FCC Caution

FCC Compliance Statement for WS-US-US-L110
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received,

20

FCC Caution

FCC Compliance Statement for WS-US-US-L110
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received,

21

IC Caution

- This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

22

IC Caution

- This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

23

Follow US

@moessmart

@moes_smart

@moes_smart

MOES.Official

@moes_official

www.moeshouse.net

24

Follow US

@moessmart

@moes_smart

@moes_smart

MOES.Official

@moes_official

www.moeshouse.net

25

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

26

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

27

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

28

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

29

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

30

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

31

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

32

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

33

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

34

09 Reset

Press and hold Switch button for 8s to reset the Switch and get into quick configure mode

1

正面

2

正面

3

正面

折疊方式