

SAMSUNG Galaxy A13 5G

AT&T



Quick Start Guide



AT&T 5-Star
Eco-Rating 2.0
att.com/ecospace

WIRELESS
EMERGENCY
ALERTS
CAPABLE



AT&T Eco Rating 2.0 only applies to Samsung Galaxy A13 5G. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

© 2022 Samsung Electronics America, Inc. Samsung & Samsung Galaxy are registered trademarks of Samsung Electronics Co., Ltd. AT&T 5G requires compatible plan. 5G not available everywhere. Go to att.com/5Gforyou for details. Contains Lithium-ion battery - recycle or dispose of properly. © 2022 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners. Screen images simulated. Appearance of device may vary. Images shown are for reference only. If you use a screen protector, make sure it allows for use of touch-screen features.




GH68-54093A

Printed in USA

Optimize the battery

From the home screen, swipe up for **Apps**, and then tap **Settings** > **Battery and device care**



What's in the box

- Samsung Galaxy A13 5G
- SIM card
- SIM Ejector Pin
- USB-C to USB-C Cable
- Quick Start Guide
- Terms and Conditions

Useful apps*



myAT&T

Manage your account, track your usage, review and pay your bill, and update your data plan service.



AT&T ProTech

Have a question, call or chat with a live AT&T ProTech support expert.



AT&T Smart Wi-Fi

Find and auto-connect to available hotspots.



AT&T Call Protect

Tired of nuisance calls? Take more control with automatic fraud blocking and suspected spam warnings.



Device Help

Get easy to understand solutions and device-troubleshooting help

Find more information

Manage your account with myAT&T

- On your phone: Swipe up for **Apps**, and then tap the **AT&T** folder > **myAT&T**.
- On the web: att.com/myATT



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need more help?

- On your phone: Swipe up for **Apps**, and then tap **AT&T** folder > **Device Help**.
- On the web: att.com/DeviceHowTo



Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

Device Protection


Remember to protect your device against loss, theft and damage. Learn more at att.com/protectyourdevice

Samsung Care

- To access user manuals, tips, videos, and more, visit samsung.com/us/support
- For hardware or software support, call 800.726.7864 or visit samsung.com/us/support/contact
- To find a repair center, visit support-us.samsung.com/cyber/locator/asc_locator.jsp

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>

Your new phone



Need more help?


Swipe up for **Apps** > **AT&T** folder > **Device Help**

Rear cover and battery are not removable.
Do not attempt to remove.

Easily adjust settings

Settings menu


From the home screen, swipe up for **Apps**, and then tap **Settings**.



Quick settings

Drag the Status bar down to display the Notification panel.

In addition to notifications, swipe down again to display quick access to device functions such as Settings, Bluetooth and Wi-Fi.



Capture life's moments

Take a picture

From the home screen, tap **Camera** > **PHOTO**.

- Pinch the display to zoom in or out.
- Tap to take a photo.
- Tap to take selfies.
- Swipe left and select **MORE** for shooting modes.

Record a video

From the home screen, tap **Camera** > **VIDEO**.

- Tap to start recording.
- Tap to capture a picture while recording.
- Tap to pause recording.
- Tap to end recording.

Share a picture or video

1. After taking the picture, tap the image viewer at the bottom left of the screen.
2. Select the photo you want to share and then tap **Share**.
3. Select the desired option to share your photo and follow the prompts.

How to replace the SIM

Remove SIM/microSD tray

- Use the tool to open the SIM/microSD™ card tray.

Insert SIM/microSD card

- Place the SIM card and optional microSD card (sold separately) into the tray with the gold contacts facing down.

Turn on your new phone

- Press and hold the **Side** key until the device turns on.



Call family & friends

Make a call

1. From the home screen, tap **Phone**.
2. Place a call using one of the following:
 - **Keypad**: Displays the keypad, and enter a phone number.
 - **Recents**: Select from call history.
 - **Contacts**: Select from address book.
3. Tap to make a voice call or to make a video call.



Check Voicemail

1. From the home screen, tap **Phone**.
2. Tap **Voicemail**.


Visual Voicemail

1. From the home screen, swipe up for **Apps**, and then tap **Visual Voicemail**.
2. Select a message to play.

Surf & stream in no time

Connect to Wi-Fi

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Wi-Fi**.
2. Tap the Wi-Fi slider to turn it on.
3. Tap a network, enter a password if required, then tap **Connect**.



Use Bluetooth

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Bluetooth**.
2. Tap the Bluetooth slider to turn it on.
3. Tap the field next to your device name to make it visible for pairing.
4. Tap a device from the list to initiate pairing.

