

Otoscope

Instruction Manual

Safety Instructions

When using this product for the first time, you may experience some temporary discomfort in your hands or ears. To avoid any discomfort, please take a short break if needed, and resume use once you feel more comfortable and familiar with the product.

△Warning

1.If earwax impaction occurs during use, proceed with caution. It is recommended to seek professional medical treatment.

2.Individuals with ear canal inflammation can use this product, but should monitor their condition closely via the product’ s visual function.

3.This product has a built-in rechargeable battery. Do not dispose of it in fire, nor charge, use, or store it in high-temperature environments.

4.Avoid knocking or dropping the product. If it’ s damaged from impact, stop using it immediately.

5.Do not attempt to modify, disassemble, or repair the product yourself.

△Attention

1.Before use, check for any visible damage. Do not use the product if it is damaged, severely dropped, or the structure is deformed.

2.Ensure that the local power supply voltage matches the voltage specified on the product before connecting the power.

3.Do not use if the charging port or charging cable is damaged.

4.Always confirm that both the charging cable and port are completely dry before connecting to power. Do not use the product while bathing.


△Tips

△Safety Warning

1.This product is not intended for use by children.

Product Introduction

Please read this manual thoroughly before using the product and store it in a safe place for future reference.




Tip

The illustrations of the product, accessories, and user interfaces in this manual are for reference purposes only. Due to updates and upgrades to the product, there may be differences between the actual product and the schematic diagrams. Please refer to the actual product for accuracy.


Use

1.Scan the QR code to download the app, or search for 'Xiao-E' on Google Play or the App Store to install it.



2. Press the power button to turn on the visual ear otoscope. The indicator light will flash blue. Replace the rubberized protective tip as needed.

① Press the power button for 2 seconds to turn on




3.Open the 'Xiao E' app on your home screen and tap the 'Hey,click here Next' button to access the Wi-Fi connection guide.

For Android users, tap the blue button to open the Wi-Fi settings.


For iOS users, exit the app, go to your device's Settings, tap 'Wi-Fi', and then connect to the network.

① APP homepage ② WIFI connection guide interface



4 Find the Wi-Fi hotspot starting with 'Enjoy' in the list. Once connected, the blue indicator light will remain on. Return to the app interface to view the connection details. Then, tap the 'Hey,click here Next' button to enter the video interface and start using the ear otoscope.

①Mobile Wi-Fi list interface ② APP homepage APP with successful WIFI connection



Home FAQs App Version

Working voltage: 4.2V

Rated power: 0.5W

Input parameters: 5V == 0.4A

Executive standards: GB4943.1-2011

Certificate Inspected

Product Cleaning

1. During the process of use, if any ear flakes fly onto the surface of the camera lens and affect the viewing effect, the user can blow or use a cotton swab to remove the ear flakes.

2.Do not put the product in water for cleaning.

Environmental Protection

When the ear otoscope reaches the end of its service life, the internal battery may need to be removed and properly recycled or disposed of according to local laws and regulations. If the battery cannot be removed by the user, please take the product to a designated recycling center as specified by local authorities.

Product Parameters

Product Name	Otoscope
Product Model	P90
Operating Frequency	Wi-Fi 2.4GHZ
Image Transmission Rate	25-30fps
Gyroscope	5 axles
Pixel	10 million
Battery	3.7V230mAh
Duration of Continuous Use	Approx.40 min
Charging Time	Approx.1h
Input	5V—0.4A
Power	0.5W
Lens Diameter	3.6mm
Network Standard	IEEE 802.11b/g/n

FAQs

Q: When I open the "E-Enjoy Ear Otoscope" app, it asks for location and storage permissions. What does this mean?

A: The location permission is used solely to help the app connect to the Wi-Fi device more quickly and does not access your personal information. The storage permission is needed to save and share your videos and images, as it requires access to your device's SD card status.

Q: When my phone is connected to the product, I get the message "Enjoy-xxxx can't connect to the internet. Would you like to switch to an available network?" What does this mean, and can I switch?

A: The "Enjoy-xxxx" Wi-Fi is specifically designed to connect your phone to the product without internet access. If this prompt appears, select "Not Allowed." If you choose "Allow," your phone will disconnect from the product and connect to your home Wi-Fi network, making the product unavailable for use.

Q: Will the device alert me when the battery is low? How does it notify me?

A: Yes, the device will flash the blue indicator light quickly to signal that the battery is low.

Q: What is the indicator when the device is charging?

A: When charging, the light ring will glow steadily blue. Once fully charged, the light ring will turn off.

Q: What could cause a connection failure, and how can I fix it?

A: If you encounter a connection failure, it may be because the visual ear otoscope is already connected to another mobile phone. To resolve this, turn the device off and on again, then attempt the connection once more.

Q: Can I transfer videos to my phone?

A: Yes, videos are saved to both the app and phone albums automatically.

Q: How do I delete photos or videos?

A: Delete from either the app or phone album independently.

Q: How do I clean the protective tip?

A: Rinse with water and dry before reinstalling.

Troubleshooting

Issue	Possible Cause	Solution
Device does not power on	Charging issue	Unplug the charging cable
Device freezes or crashes	Interference or external disruptions	Restart the car otoscope
Device freezes or crashes	Software compatibility issue	Uninstall and reinstall the app
Image appears unclear or blurry	Dirt or debris on the lens	Blow air and clean the lens with a cotton swab
Video or app performance is slow or lagging	Excessive storage or cache usage	Clear the system cache and restart the device

Recharge Regularly

1.When the indicator light flashes quickly, it means the battery is low. Please charge the device promptly. The light will turn steady red during charging and will turn off once the battery is fully charged. A full charge takes approximately 1 hour.

2.To maintain optimal battery performance, please charge the ear otoscope periodically, even if it hasn't been used for an extended period

Attention

The included charging cable is specifically designed for the E-Enjoy ear otoscope. It does not support fast charging for other devices or data transmission.