PORODO



Porodo

Voyager Smart Watch with Rugged Design and Built-In Compass

SKU: PD-LFST011


Table of Contents

Overview	2
Charging	2
Touch and Button Instructions	3
Connection Instructions	4
Instructions for Use	5
Function Guide	5
Troubleshooting	8
Specifications	9
Wireless Data Transmission	10
Safety Precautions	10
Disposal	10
Warranty	11
Contact Us	11

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.


Overview

- 1. Open the package and remove the smartwatch.
- 2. Put on the smartwatch and press and hold the power button to turn it on.
- **3.** Scan the QR code with your phone to launch the "FitCloudPro" app and set up the device.



Charging

Align the magnetic charger with the charging port on the back of the watch, ensuring it connects securely to the watch screen. When the charging prompt appears, recharge the watch promptly if the battery is low. Please note that the device is an all-in-one unit, and the rear casing and battery are not removable.



Touch and Button Instructions

Menu Button

- 1. On the dial screen, press once to switch between dials.
- 2. On the dial page, press to access the menu.

Knob Button

- 1. On the menu page, rotate the button to navigate through the options and zoom the icon with the knob.
- 2. Press and hold the button for 5 seconds to activate the SOS signal.

On/Off Button

- 1. When the device is powered off, press and hold to turn on the watch.
- 2. On any other page, press the button to return to the watch face.

Swipe Up to see messages and notifications



Swipe Down to access the control center.

Swipe Right to access shortcut keys and weather details.

Menu Button

Knob Button

On/Off Button

Swipe Left to observe the

sports and exercise data.

Connection Instructions

Note: The watch's Bluetooth name is "PD-Voyager".

[A] Download App

Download and install the "FitCloudPro" app on your mobile phone. You can scan the QR code provided in this manual,



scan the QR code displayed on the watch, or directly search for "FitCloudPro" in the app store to download it.

[B] Connect the smartwatch

[B.1] Scanning QR Code to Connect.

1. After enabling Bluetooth on your phone, launch the app.

Note: If the app cannot be opened, please enable the location services on your phone before launching the app.

- 2. Tap on "Device". Select "Add Device".
- 3. Tap "Scan QR Code to Bind". Scan the QR code on the watch.

[B.2] Manual connection:

1. After turning on Bluetooth on your phone, open the app.

Note: If the app cannot be opened, enable location services on your phone first.

- 2. Tap "Device". Select "Add Device". Tap "Search Device".
- **3.** Find the corresponding device in the watch's "Settings" \rightarrow "System" \rightarrow "System Information" menu, which will display the Bluetooth name and MAC address of the device. Tap "Connect".

[B.3] Connecting for Wireless Calls:

- 1. By default, the wireless call feature is turned off. To enable call and music functions, swipe down to open the "Control Center" on the watch, tap the "Headphone" icon, and turn on audio mode.
- 2. Activate the wireless call feature on your phone (ensure Bluetooth is turned on). Find the corresponding wireless name and tap "Connect."
- 3. Once connected, the call and music functions will work normally.

Instructions for Use

[1] Dial Interface

Long press the screen to enter the dial selection menu. Swipe left or right to switch between available dials, and tap once to confirm your selection.

Note: The system presets multiple dials, with the last option being "Customize." The watch face can be updated with new dials through the watch dial market on the app, or by downloading custom dials.

[2] Menu Interface

From the dial screen, press the side knob to enter the menu. Once in the menu, quickly press the lower knob twice to access the menu switching interface. Press the knob to return to the main interface.

[3] Function Interface

Tap the application icon in the menu to access the corresponding function. Swipe right to return to the previous screen, or press the side knob to return directly to the main watch dial.

Function Guide



Once the smartwatch is connected to the app, you can set a single-mode alarm, a recurring alarm, or up to 5 different alarms.



Click the start button to begin the timer, click the pause button to pause it, and click the reset button to reset the timer to zero. Up to 99 data points can be saved.



For breathing training, there are 1-minute and 2-minute options.

The user can select the desired duration to begin the session.

After tapping start, follow the on-screen icons to inhale as the icon enlarges and exhale as the icon shrinks.



The intelligent assistant allows for quick software access and information retrieval, enabling hands-free operation.



Activate the "Do Not Disturb" mode during rest to block all message notifications, ensuring a more peaceful and undisturbed rest period.



Once the device is connected to the app, the weather interface will display real-time temperature and weather details.



Available sports modes include walking, running, cycling, mountaineering, swimming, yoga, elliptical machine, basketball, and more. Tap the corresponding icon to start the exercise interface.



The numerical input supports a maximum of 7 digits (negative numbers are not processed). The result of the calculation can have up to 8 digits. If the result exceeds this limit, it will be displayed as "—-".



Add contacts to the "Frequently Used Contacts" section in the app. These contacts will be automatically synced to the device, with a limit of up to 10 contacts.



The current year, month, and day are displayed. Swipe down to view the calendar.



Once the device is connected to the app, enable message push notifications in the app settings. The device can then receive and store up to 15 recent messages.



The settings menu includes options for screen display (such as dial switching, screen brightness adjustment, screen timeout, and wrist gesture to wake the screen), language, vibration intensity, menu style, battery, QR code, and system settings.



Once the device is connected to the app, it can control the mobile phone's music player, including pausing and starting playback, adjusting the volume, and switching songs.



You can enable the "Sedentary Reminder" in the app. Once activated, you can set the start and end times, as well as a do-not-disturb period.



The "Drinking Water Reminder" can be enabled in the app under 'Settings' → 'Drinking Water Reminder.' After activation, you can configure the start and end times, along with the reminder interval.



The sleep monitoring status for the day is displayed, with data updated daily. When connected to the app, the data is synced, and the device will recalculate the data for the new day.



To switch the watch dial, press and hold the main interface screen for 2 seconds to enter the dial switching menu. Swipe left or right to browse available dials, and tap to select your preferred dial.



The number of steps, distance, and calories for the day are displayed. You can set goals for steps, distance, and calories within the app.



Control Center Function Overview: Do Not Disturb, Wrist gesture to wake the screen, Brightness adjustment, Settings, Find My Phone, Power Saving Mode, and System Information.



In case of danger, press and hold the shortcut button for 5 seconds to activate the emergency alarm for help.



Once the device is connected to the app, tap to locate the mobile phone. The phone will ring to confirm the search is successful. If the watch is not connected to the app, it will display a prompt indicating no connection.



For the timing function, the system presets commonly used durations. Users can tap the desired duration for quick timing, or tap the custom button to set a specific time. Press the start button to begin timing, the pause button to halt it, and the reset button to reset the timer to zero.

Troubleshooting

[1] The watch cannot be turned on

Please press and hold the power button for more than 3 seconds. If the issue persists, the battery may be low and requires charging.

[2] Wireless is not connected or cannot be connected

- 1. Try restarting the watch and reconnecting.
- 2. Restart your phone's wireless and attempt the connection again.
- 3. Ensure the phone is not connected to other wireless devices at the same time.

[3] The measurement data of the watch is inaccurate

- 1. The sensor may not be making proper contact with the skin during the measurement.
- 2. Ensure the sensor is in full contact with your wrist when measuring.
- 3. For individuals with darker skin or more arm hair, please enable "Enhanced Measurement" under "Device" \rightarrow "Enhanced Measurement" in the app for more accurate readings.

[4] Sleep data is not accurate enough

1. Sleep monitoring simulates self-recognized sleep and wake times, and the

device must be worn correctly for accurate results.

- 2. Wearing the device too late or during sleep onset may lead to inaccuracies.
- 3. Sleep data is not tracked during the day. By default, sleep monitoring starts at 9:30 PM and ends at 12:00 PM the following day.

Note: For more frequently asked questions, please visit the app's "My" \rightarrow "FAQ" section.



Watch Case	Zinc Alloy
Screen Size	1.43"
Screen Resolution	466*466 AMOLED
Flash Memory	128MB
Battery Type	Li-Polymer
Battery Capacity	3.8V / 400mAh
Recharge Time	4H
Working Time	Up to 7 Days
Compatibility	Android 5.0 and above, iOS 10.0 and above
Application	FitCloudPro
Bluetooth Name	PD-Voyager
Waterproof	IP68
Standby Power Consumption	Min 70μA
Charger	DC 5V
Size	13.5×45.5×42.5mm

Wireless Data Transmission

When connected to a mobile phone, the device will synchronize certain data wirelessly, including weather updates, notification messages, and sports/health data. This data will not sync if the connection is lost or if wireless is turned off.

Safety Precautions

- 1. Do not charge the device in humid or wet environments.
- 2. Regularly clean the magnetic charging port on the back of the watch with a soft cloth to ensure a secure connection with the magnetic charger for proper charging.
- **3.** This product does not include a power adapter. For safety, use a computer USB port or a power adapter with a maximum output of 5V/1A when charging.
- 4. Ensure to purchase power adapters from reputable sources to avoid using low-quality or counterfeit adapters, which may pose risks such as bursting or fire.
- **5.** This app is not a medical device. The data obtained during its use is for reference only and should not be used for clinical diagnosis, medical treatment, or research purposes.
- 6. The device is water-resistant but is not suitable for diving, swimming, or prolonged exposure to water. Additionally, it should not be used in hot water or sauna environments, as steam can damage the equipment.
- 7. The company reserves the right to modify the contents of this manual without prior notice. Some functions may vary depending on the software version, which is normal.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check: porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: porodo.net

Service Support: support@porodo.net

Instagram: porodo