Amazon Alexa Voice Control Integration

Prerequisites

Users enabling voice control of the Legrand Lighting Control System through devices with Amazon Alexa require the following:

- a device with Amazon Alexa (i.e. Amazon Echo) connected to the home network
- the Legrand Whole House Lighting Control System (LC7001)
- the Amazon Alexa app installed on a mobile device
- an internet connection
- the Legrand Lighting Control app, version 2.0 or newer, installed on a mobile device
- an active Samsung ARTIK™ Cloud account integrated with the user's Legrand Whole House Lighting Controller (LC7001).

NOTE: For instruction on creating and integrating a Samsung ARTIK™ Cloud account with the LC7001, refer to "Setting up Remote Access" in the Legrand Whole House Lighting Controller User Guide or navigate to <Settings <Remote Access Info <Remote Access Setup in the Legrand Lighting Control app.

Connecting Alexa to the Legrand Lighting Control System

1. Open the Alexa App and select Skills



2. Search for ARTIK



3. Select the Samsung ARTIK Cloud Optimized for Smart Home option



4. Select Enable




5. Sign in to your Samsung ARTIK™ Cloud Account



6. After receiving a successful link message, tap X to close the window and return to the Skills page



7. Choose Discover Devices to import the Legrand Lighting Control System devices into Alexa



NOTES:

- · Device discovery can take up to 20 seconds.
- Device discovery must be performed when devices are added to the system. In the Alexa app, navigate to Smart Home.
 Under Your Devices, select Discover Devices.

Grouping Discovered Devices

Use the Alexa app to designate groups of Legrand Lighting Control System devices. Groups allow control of multiple devices using a single Alexa command.

Alexa supports both switching and dimming commands. Switching commands simply activate and deactivate devices. Dimming commands allow various levels of control to be applied to the devices.

Example: A group named "basement" can have multiple devices located in the basement assigned to the group for control at one time.

NOTE: Dimming commands only activate dimmable devices. While all dimmable and non-dimmable devices in the same group respond to switching commands, only the dimmable devices can respond to dimming commands.

Common Amazon Alexa commands to turn devices ON or OFF (choose one word from each bracketed item in the statement):

- "Alexa, turn [my/the] [device/group name] [on/off]"
- "Alexa, turn [on/off] [my/the] [device/group name]"
- "Alexa, set [my/the] [device/group name] to [on/off]"

Common Amazon Alexa commands to brighten or dim devices (choose one word from each bracketed item in the statement):

Dimming or brightening to a specific level:

- "Alexa, brighten [my/the] [device/group name] to [1-100%]"
- "Alexa, dim [my/the] [device/group name] to [1-100%]"
- "Alexa, set [my/the] [device/group name] to [1-100%]"

General dimming or brightening commands:


- Commanding "Alexa, [dim/brighten] my [device]" results in an adjustment level of 25% for dimmable devices.
- Commanding "Alexa, [dim/brighten] my [group name]" results in an adjustment level of 25% for only the dimmable devices in the group.

Create a Group


1. Open the Alexa app and select Smart Home




2. Select Create group



3. Name the group



- 4. Select the devices for control in the group
- 5. Save the group



For technical assistance on your Lighting Control app, contact On-Q Technical Support between 8 AM and 6:30 PM EST.

Phone: 717-546-5412

Email: technical.support-hs@legrand.us

Chat: www.legrand.us/on-q

(Click on the ♀ icon to open a dialogue box)

