

Screen Display / Function	Icon	Icon Description
Pair Earbuds (Left & Right)		With the lid open, press and hold the button on the back of the case for 3 seconds to pair the earbuds (left & right). If currently connected to a phone, this will disconnect the Bluetooth connection. Close and re-open the lid to reconnect to the phone.
Power Button		<div>Press once: Wake screen</div> <div>Press again: Sleep screen</div> <div>Long press: Power off (Tap ✓ to confirm, × to cancel)</div> <div>Long press: Power on charging case</div>

Troubleshooting and tips

- If the earbuds are not working correctly, turn them on/off.
- If the earbuds won't turn on, recharge the battery and try again.
- If the earbuds won't charge, make sure the power supply works DC 5V>0.25A, and is not damaged.
- If the earbuds make no sound, adjust the volume.
- If the earbuds make no sound or do not show as an available device, make sure they are not paired to another device, if so, unpair the device and re-pair to the desired device.
- This device does not have a pairing code. If prompted for one, make sure you are connecting to the correct device. If you are not, "forget" the device and re-pair.

NOTE:

- The earbuds will power off if it is not used for more than 5 minutes.
- If the Bluetooth® connection range is more than 10 meters the earbuds / charging case will disconnect with a prompt sound from earbuds/ in status bar of screen, indicating that the connection has been lost. If the connection is not re-established within 5 minutes, the earbuds will turn off automatically.

Need some help?

Can't get it to pair? Have a question or comment?



Call us 1-833-TGT-Tech

Safety

- Do not use near any water source
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth



Earbuds FCC ID: 2BAXW-TTY95

Charging Case FCC ID: 2BAXW-TTY95S

Model: TTY95 Input: 5V Max 0.25A Made in China

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct



4

the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Target Corp.Mpls.MN,55403 Phone:1-833-TGT-Tech


5

Heyday™ TWS Earbuds With Screen Case



hey! welcome to your Heyday™ true wireless earbuds.
Let's get you set up

5



Eartips Fitting Diagram



Included

- 1 x Charging case with screen
- 1 x Wireless earbuds (L, R) with 3 x eartips (S,M,L)
- 1 x USB-C charging cable

Indicators

- Ascending Tones - Power on
- Descending Tones - Power off
- Single Chime - Paired

Phone Calls

- Music will stop if there is incoming call.
- Press the left or right earbuds once to answer the incoming call, press again to hung up after the call.
- Hold the left or right earbuds for 2 seconds to reject an incoming call.

Listen To Music

- Play/Pause: Double press the Left or Right earbud Multi-functional touch control.

Pairing

- Lift the lid of the charging case / long press the earbuds Multi-functional touch control for three seconds to power on.
- Use Bluetooth® settings on your phone to pair with the Heyday Earbud 13.
- A prompt tone will sound upon successful pairing.
- Put back the earbuds and close the charging case lid / long press the earbuds Multi-functional touch control for five seconds to power off.

How to wear

- Take the earbuds out of the charging case.
 - The left earbud has an "L" and the right earbud has an "R" marked on it. Place the left /right earbud in the left / right ear and make sure the speakers are pointed upwards when placing them in your ears.
- Note: M-size eartips are pre-installed on the earbuds. Replacement of eartips (S, M, L) with different sizes to fit your ears.

Charging earbuds

- Suggest to fully charged for first use, Place the earbuds in the charging case to start charging them.
- Full charge of the earbuds requires approximately 1 hour.
- Earbuds playback time up to 3.5 hours. Up to 12 hours with charging case.

1

Recharging charging case

- Full charge of the charging case requires approximately 2 hour.
- Plug the USB-C charging cable to charge.
- Plug USB-C end of charging cable into a DC 5V>0.25A power supply.

Earbuds Press/Hold instruction

Left	Right
● VOLUME UP&ANSWER / END CALL	● VOLUME DOWN&ANSWER / END CALL
● PLAY / PAUSE	● PLAY / PAUSE
●● Reset earbuds	●● Reset earbuds
■ Hold for 2 seconds, REJECT INCOMING CALL	■ Hold for 2 seconds, REJECT INCOMING CALL
■ Hold for 3 seconds, Power on	■ Hold for 3 seconds, Power on
■ Hold for 5 seconds, Power off	■ Hold for 5 seconds, Power off

● SHORT PRESS ●● DOUBLE PRESS ●●● FIVE TIMES PRESS ■ Hold

Screen display instruction

Screen Display / Function	Icon	Icon Description
Status Bar		Earbuds not connected to case
		Earbuds connected to case
		Earbuds, case, and phone connected
		Learbud battery (Yellow when charging)
		Case battery (Yellow when charging)
Music		Automatically synchronize the time of connected devicesTime display
		AM/ PM
		Previous song
		Play/Pause
Equalizer		Next song
		EQ toggle (Selectable when enabled)
		Next option
		EQ presets: JAZZ, VOCAL, BASS, CLUB, STUDIO, NORMAL
Ambient Sound		Previous option
		ANC Mode
		Transparency Mode
		NORMAL Mode (Default)
Spatial Audio		Operable when earbuds connected to case and phone
		Spatial audio toggle (Selectable when enabled)
		Cinema audio
		Music audio
Charging mode		Gaming audio
		Operable when earbuds connected to case and phone

2

Screen Display / Function	Icon	Icon Description
Volume		Volume down
		Volume level (0-16)
		Volume up
Screen Brightness		Operable when earbuds connected to case and phone
		Previous option
		Screen brightness (Low/Medium/High)
Find Earbuds		Next option
		Operable when case only
		Locate left earbud
Take Photo		Locate right earbud
		Operable when earbuds connected to case
		When the camera is activated on the phone, Single-click the camera button to capture photos
Voice Assistant		When the camera function is not in use, Single-click the camera button to turn up the volume
		Operable when earbuds connected to case and phone
		Voice assistant activation/deactivate
Call Mode		Operable when earbuds connected to case and phone, press once to activate, then again to deactivate
		Answer Call
		Reject Call
		The microphones of earbuds are activated
		The microphones of earbuds is muted
Low Battery Alert		Hang up the calling
		Low Battery Alert Note: When the charging case powers off due to low battery, connect it to a USB charger and long-press the power button to turn it on before charging the earbuds.
Charging mode		Plug in to charge, the charging icon displays for 2 seconds.

3

FRONT

P2

P3

P4