54MM

JOURNEY

SIDI

 \mathcal{C}

SID

journeyofficial.com

SETUP WITH APPLE FIND MY APP 1. Update your iPhone to the latest version of iOS. Activate Bluetooth. 2. Press your LOC8 Finder Fob 2 button once (see arrow pointing to button in drawing below). The beeping that follows indicates your device is ready for pairing. 3. Open the Apple Find My app.

4. Tap "+": select "Add Other Item" to bring up LOC8 Finder Fob 2 on your screen for pairing.

FIND YOUR LOC8 FINDER FOB 2

1. In "Find My" app. tap "Items".



- 2. Check your fob's last known time and place.
- 3. Click and select the fob from the list. 4. To find a nearby item, tap "Play Sound"
- and listen for a chime. 5. For distant items, click "Directions". Open
- Maps to navigate to the last-known location.

LOC8 Finder Fob 2 0 0 Play Sound

Directions

 \otimes

WARNINGS

Avoid exposing it to extreme conditions that may affect its functionality.

Keep LOC8 Finder Fob 2 away from all heat and fire sour including heating equipment, heaters, ovens, open flar and direct sunlight.

Do not attempt to repair or disassemble the LOC8 Finder Fob 2 equipment by yourself. Any unauthorized modification may result in damage or malfunction. Avoid using or storing LOC8 Finder Fob 2 in env

with high humidity or temperatures exceeding 60°C (140°C) to prevent potential failures. Responsibly dispose of LOC8 Finder Fob 2 products following the local government's regulations on waste disposal to minimize environmental impact.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

regulatory standards

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of isco in the U.S. and other countries and is used under license.

AUSTRALIAN WARRANTY

Warranty Period

Warranty Terms

ALOGIC Corporation Pty Ltd warrants this product to be free from defects in materials and workmanship for the warranty period stated above from the date of purchase, provided the product is used in accordance with the accompanying recommendations and instructions.

This warranty no longer applies where any defect results from alteration, accident, misuse, abuse or neglect of the product.

How to Make a Claim

This warranty is in addition to your rights under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a najor failure and compensation for any other reasonably foreseable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights under New Zealand legislation.

ALOGIC Corporation Pty Ltd Level 14, 140 William St Melbourne VIC Australia 3000


COMPLIANCE STATEMENTS

CHARGING YOUR LOC8 FINDER FOB 2

To charge your LOC8 Finder Fob 2, plug the sleeve into a wall charger using the sleeve's USB-C port. The LED status light will glow orange if the tracker is charging and green if the tracker is fully charged.

Rechargeable battery lasts up to 6 months on a full charge.

LED Status	Device Behaviour
Orange	Charging
Green	Fully charged



CHECKING BATTERY LEVEL

When LOC8 Finder Fob 2's battery level is low, you will receive a reminder notifcation on your phone, via the Find My app. You can also check the battery level of the LOC8 Finder Fob 2 in the Find My app.

USE LOST MODE

- 1.If you can't find your wallet, open the Find My app on your iPhone.
- 2.Click the 'Items' icon at the bottom of your screen.
- 3.Tap on your LOC8 Finder Fob 2 icon displayed on your screen.
- 4.Scroll down to "Enable Lost Mode". 5.Tap "Continue" 6.Enter your required contact details to
- finalise "Lost Mode". Your LOC8 Finder Fob 2 will stay linked to your Apple ID,

unless you unpair it.

If someone finds your item while it is in Lost Mode, they can use their iPhone or any NFC-capable device to reach

TROUBLESHOOTING

This device can be reset if you have trouble pairing the wallet with your iPhone, or if you want to unpair it and give it to someone else.

To reset:

Off

- 1. Hold down the tracker button for 10 seconds.
- 2. Release the button once you hear the ringtone sound five times.
- 3. You can repeat this step in "SETUP WITH APPLE'S FIND MY APP" to pair the wallet with your iPhone.

FCC Compliance Statement

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class 18 digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to sovide reasonable protection against harmful interference to and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Recrietar or relocate the receiving antenna
- Increase the separation between the equipment and receiver.

- Connect the equipment that on a outlet on a circuit different from that

- reconsent or relocate the receiving antenna
 increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Responsible Party - U.S. Contact Information ALOGIC USA LLC 37524 Marsten DR, Newark CA 94560, USA

Hereby, ALOGIC Corporation declares that this product is in compliance with Directive 2014/S3/EU. The full text of the EU declaration of conformity is available at the following internet by clicking on the Compliance Documentation link: journeyoffi

Innovation, Science and Economic Development Canada Statement (ISED)

1) This device may not cause interference.

RF exposure statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Declaration d'Innovation, Sciences et Developpement econ Canada (ISDE)

L'emetteur/recepteur exempt de licence contenu dans le present appareil est conforme aux CNR d'innovation, Sciences et Developpement economique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisee aux deux conditions suivantes:

1) L'appareil ne doit pas produire de brouillage;