



Green Lion

GMF-54 MINI REFRIGERATOR

SKU: GN54LFRIDGBK

Model No: GMF-54

Table of Contents

Usage Guidelines	2
Unpacking Guide	2
Installation	3
Operation	3
Defrosting	4
Cleaning & Maintenance	4
Electrical Safety Instructions	5
Specifications	5
Warning	6
Disposal	8
Warranty	7
Contact Us	8

Usage Guidelines

1. This appliance is designed for household and similar applications, including:

Shops, offices, or kitchen areas in workplace environments

Farms, hotels, motels, and guest accommodations

Family hotel environments

Catering and other non-retail industry settings

2. Carefully read all instructions before using your refrigerator.

3. Do not place hot food directly inside the refrigerator.

4. Wrap all food items in plastic film to prevent dehydration and preserve flavor.

5. Always close the refrigerator door promptly after each use.

6. If the refrigerator will not be used for an extended period, disconnect the power, clean the interior, store it in a dry location, and leave the doors slightly open.

General Information

This refrigerator is suitable for use in a variety of settings, including hotels, offices, homes, and student dormitories. It is primarily intended for refrigerating and storing food items such as fruits and beverages. The appliance features a compact design, high efficiency, and low energy consumption.

Unpacking Guide

Simply cut off the packing band and pull the carton up.

Repacking

Ensure the original foam pads are placed correctly.

Moving

Always keep the refrigerator trays in an upright position while moving.

Do not tilt the refrigerator more than 45 degrees from its upright position.

Never upset it.

Avoid applying force to any external parts like pipes, condensers, doors, or shelves. Ensure the refrigerator is properly packed and secured for long-distance transportation to prevent damage from impact or excessive shock.

Installation

1. Place the refrigerator on a flat, stable surface.
2. Keep the appliance away from direct sunlight, heat sources, and humid or damp environments.
3. Ensure there is adequate space between the refrigerator and the wall to allow for proper airflow.
4. If installing the refrigerator in a cupboard, make sure the rear panel of the cupboard is removed to provide sufficient air circulation.

Operation

1. Before plugging in the refrigerator, ensure the following:

There must be no visible damage to the electric cords.

Each screw must be securely fixed.

-Wall outlet must be properly earthen

Ensure everything is in normal condition before plugging the refrigerator in.

2. When operating for the first time

Before loading food, run the refrigerator without any load until it reaches the desired temperature. This typically takes 2 to 3 hours. Then, set the thermostat to the required setting and place food inside.

3. Temperature control

The refrigerator's temperature can be adjusted by turning the thermostat knob. The closer the setting is to the "5" position, the colder the temperature will be. A medium setting is ideal for general use. Set the thermostat to the "5" position only when ice cubes are needed or when frozen foods are stored in the freezer.

Refrigerator temperatures will vary depending on the quantity of food

stored and the frequency of door openings. To maintain good cooling efficiency and save energy, avoid storing too much food and minimize opening the door frequently.

Caution: Once the thermostat is turned clockwise to the "5" position, do not attempt to turn it further, as this could cause damage.

4. Ice cubes making

After filling the ice tray with drinkable water (up to 80% of its volume), place it in the freezer compartment and set the thermostat to "5". It will take about 3 hours to make ice cubes.

Defrosting

Defrost the freezer compartment whenever the layer of frost on the evaporator reaches 3-4 mm. When defrosting, remove all food and ice cube trays. Place the drip tray underneath to collect melted water. Set the thermostat to "0" and keep the door open. After the frost has melted, discard the melted water and dry the interior of the refrigerator. The refrigerator can be restarted by turning the thermostat back to the desired setting.

Caution: Never use sharp metallic instruments (e.g., knives) to remove frost or ice from the evaporator, as this can damage the evaporator. A punctured evaporator could lead to serious issues.

Cleaning and Maintenance

To clean the refrigerator, disconnect the power supply and remove food, shelves, and trays. Use a solution mixed with 2 tablespoons of baking soda per liter of warm water to clean the interior. Then, wipe it clean with fresh water. Never use acids, chemical thinners, gasoline, benzene, or like chemicals for cleaning any part of the refrigerator. Additionally, do not use boiling water or benzene to clean plastic parts as they may deform or damage them.

Storing large amounts of food or large containers in the refrigerator can affect cold air circulation, so some free space must be left. It is recommended that about 70% of the storage volume be loaded.

Do not store volatile and/or explosive materials such as gasoline or liquefied petroleum gas in the refrigerator. Doing so presents a risk of fire or explosion caused by electric sparks.

Electrical Safety Instructions

1. Before plugging in the refrigerator, verify that your household electrical supply matches the voltage and frequency indicated on the rating plate, usually found on the back of the appliance.
2. Always connect the refrigerator to a dedicated electrical outlet to prevent overloading and minimize the risk of fire due to overheating wires.
3. Do not splash water onto the refrigerator, as this may result in electrical leakage or malfunction.
4. If the power cord becomes damaged, replace it immediately with one of the same specifications.
5. Ensure the refrigerator is properly earthed for safety.
6. The manufacturer is not liable for accidents resulting from improper operation.

Specifications

Model No.	GMF-54
Material	ABS Interior + Steel
Capacity	54L
Power	70W
Voltage	220-240V

Annual Power Consumption	120 kWh
Refrigerant	R600a
Frequency	50Hz
Temperature Range	0-12°C
Noise Level	≤ 42 dB
Power Cord	UK Plug
Weight	17 kg
Dimensions	445*450*678 mm

Warning

1. Keep all ventilation openings in the appliance enclosure or built-in structure unobstructed to ensure proper airflow.
2. Do not use mechanical devices or any other means to accelerate the defrosting process except those recommended by the manufacturer.
3. Avoid damaging the refrigerant circuit at all times.
4. Do not use electrical appliances inside the food storage compartments unless they are specifically recommended by the manufacturer.
5. The refrigerant and insulation blowing gas used in this appliance require special disposal procedures. When disposing of the appliance, consult with a qualified service agent or professional.
6. This appliance is not intended for use by individuals (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless supervised or properly instructed by someone responsible for their safety. Children should be supervised to prevent them from playing with the appliance.
7. If the internal light does not work, disconnect the power, remove the

light cover, and replace the bulb by turning it counterclockwise. Install a new bulb by turning it clockwise.

8. If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or a similarly qualified professional to avoid hazards.

9. Since this appliance uses R600a, a flammable refrigerant, always follow the manufacturer's guidelines for use and service. Repairs must be performed by authorized personnel. Do not attempt to dismantle or modify the refrigeration system, and avoid any actions that could cause a refrigerant leak.



Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: sales@greenlion.net

Service Support: Support@greenlion.net

Telegram: [@greenlion_global](https://t.me/greenlion_global)

Instagram: [@greenlion_global](https://www.instagram.com/greenlion_global)