

36" Desk Riser

DESK-V036K Series
Assembly Manual

Individual Product SKUs

DESK-V036KB	DESK-V036KG	DESK-V036KW
DESK-V036KA	DESK-V036KN	DESK-V036KWE
DESK-V036KF	DESK-V036KP	



WARNING



If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Failure to report missing parts within 30 days may result in denial of free replacement. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.




WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



DO NOT EXCEED WEIGHT CAPACITY

NEVER PLACE EXCESSIVE FORCE ON THE RISER OR EXCEED THE STATED WEIGHT CAPACITY. FAILURE TO DO SO MAY RESULT IN SERIOUS PERSONAL INJURY AND/OR DAMAGE TO SETUP EQUIPMENT.



NEVER OPERATE RISER UPSIDE DOWN

NEVER ATTEMPT TO RAISE RISER WHEN UPSIDE DOWN; DOING SO MAY RESULT IN SERIOUS PERSONAL INJURY. ENSURE RISER IS RIGHT SIDE UP ON A STABLE SURFACE BEFORE ATTEMPTING ANY HEIGHT ADJUSTMENTS.



DO NOT ROUTE CABLES WITHIN SUPPORT FRAME

NEVER ROUTE CABLES WITHIN THE INNER SUPPORT FRAME OF RISER. DOING SO MAY CAUSE SERIOUS PERSONAL INJURY AND/OR DAMAGE TO SETUP EQUIPMENT.



KEEP HANDS FREE OF SUPPORT FRAME

NEVER PLACE HANDS WITHIN SUPPORT FRAME. DOING SO MAY RESULT IN SERIOUS PERSONAL INJURY.



CHECK CABLE LENGTH

TO PREVENT ACCIDENTAL DAMAGE TO DEVICES AND/OR PERSONAL INJURY, PLEASE ENSURE POWER CABLES HAVE ADEQUATE LENGTH TO ACCOMMODATE THE CHOSEN HEIGHT OF YOUR DESK RISER.



KEEP DEVICE & DESK ITEMS AWAY FROM DESK EDGE

ALWAYS KEEP LAPTOP, MONITORS, AND OTHER DESKTOP ITEMS AWAY FROM THE EDGE OF THE DESK. FAILURE TO DO SO MAY RESULT IN ACCIDENTAL DAMAGE OF DEVICE AND/OR SERIOUS PERSONAL INJURY.




USE CAUTION WHEN ADJUSTING

NEVER STAND OVER THE DESK RISER WHEN ADJUSTING THE HEIGHT. DOING SO MAY CAUSE PERSONAL INJURY TO THE FACE OR EXTREMITIES.



Assembly Video & Product Info
www.vivo-us.com/products/desk-v000k

Package Contents



A (x1)
Desktop



B (x1)
Keyboard Tray



C (x1)
Stopper



D (x3)
Pad



E (x4)
Rubber Feet



F (x2)
Cable Clip

Included Hardware & Tools



S-A (x2)
ST4.2x12mm Screw



S-B (x4)
M5x10mm Screw

Tools Needed:



**Phillips
Screwdriver**



Scissors

Weight Capacity:



Desktop




**Keyboard
Tray**


Assembly Steps

STEP 1

Remove adhesive backing from Pads (**D**) and apply to underside of Keyboard Tray (**B**) as shown.




Assemble Stopper (**C**) to Keyboard Tray (**B**) using ST4.2x12mm Screws (**S-A**) and a Phillips screwdriver.




STEP 2

Install Rubber Feet (**E**) to the bottom of Desk (**A**). Remove shipping tie from desk and set right side up on solid surface.




STEP 3

Raise Desk **(A)** by lifting the handle on the right side of the frame.




Place Keyboard Tray **(B)** on the metal brackets on Desk **(A)**. Secure Keyboard Tray to the brackets using M5x10mm Screws **(S-B)** and tighten with a Phillips screwdriver.



STEP 4

Remove adhesive backing from Cable Clips (**F**) and apply to underside of Desk (**A**).



Desk riser is now ready for use




Press side lever to raise or lower your desk riser.

When lowering without any weight on the desktop, lightly press down on riser as you lower it to allow for a smoother lowering process. If it feels difficult to lower after placing laptop and other intended setup items, apply light pressure to lower smoothly or add additional weight.


Please note the 33lb weight capacity when adding weight.

Grommet Option

This desk riser features a pre-drilled grommet hole for installing a monitor mount directly to desk surface.




To utilize this feature, you will need to remove the plug from the top surface of the riser. Secure your mount using a grommet mounting method, using the hardware and assembly steps from your monitor mount.




Tension Adjustment

If your desk riser lifts up or down too easily, or is too difficult, the gas spring cable can be adjusted to your desired tension. The adjustment is located at the base of your riser.




Start by loosening the Upper **(1)** and Lower **(2)** Nuts using an adjustable wrench. Loosen Nuts until they are both on the opposite ends of the Gas Spring Cable.




Desk is Difficult to Lower/ Springs Up too Fast

If the desk feels difficult to lower or springs up too fast, you will need to increase the Gas Spring Cable tension. Gently pull the cable away from the Lever until the Inner Nut **(2)** is firmly pressed against the middle divider.




Tighten Upper Nut **(1)** until it firmly holds the cable in its position, as shown below.




Desk is Difficult to Raise/ Springs Up too Slow

If the desk is raising or lowering without the handle being pressed, the tension will need loosened. Gently push the cable down towards the base of the riser until the Upper Nut **(1)** is firmly pressed against the middle divider.



Tighten Lower Nut **(2)** until it firmly holds the cable in its position, as shown below.





Need Help? Get In Touch

Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com

Chat live with an agent!



309-278-5303



VIVO-us



@vivo_us

FOR MORE GREAT VIVO PRODUCTS,
CHECK OUT OUR WEBSITE AT: WWW.VIVO-US.COM