

OWS Sport Earphones with Charging Case

RBK1300 User Manual

Package Contents

- OWS Sport Earphones with Charging Case
- USB-C Charging Cable
- User Manual

Specifications:

Bluetooth Range: Up to 33 feet (10 meters)

Charging Input: DC5V 200mA


Play Time: 4 Hours**


**Applicable at 50% of maximum volume.

Results will be lower when volume is higher.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Sakar International is under license. Other trademarks and trade names are those of their respective owners

A Quick Look





--- Charging Case

Charging the Case and Earbuds

1. Insert the included charging cable's USB-C end into the charging port on the case.
2. Insert the charging cable's standard USB end into the USB port on a computer or suitable wall adapter (not included).
3. The indicator light on the charging case will flash red when it is being charged, and solid in red once fully charged.
4. Place the earbuds in the charging case in order to charge, the earbuds' indicator light will turn on white and blue when it is being charged, and turn off once fully charged.

Bluetooth Pairing

1. Remove the earbuds from the case and they will turn on automatically.
*If the earbuds are out of the charging case, put them into the case and take out again to turn on.
2. When in pairing mode, one earbud's indicator light will slowly flash white and blue, the other earbud's indicator light will turn off. You will also hear a voice "Pairing".
3. On your phone, go in the Bluetooth page in the Settings app. Make sure Bluetooth is on before connecting to the available device 'RBK1300 OWS TWS'.
4. Both earbud's indicator light will turn off once paired to your phone, you will also hear a voice "Connected".

Using Your Earbuds: Music Controls

1. Press either earbud's Multi-Function Button to pause and play music.
 2. Press and hold either earbud's Multi-Function Button for 2 seconds to activate Siri or Google Voice Assistant.
 3. Left earbud's Multi-Function Button
Double press = go back to the previous song
Triple press = decrease the volume
 4. Right earbud's Multi-Function Button
Double press = go to the next song
Triple press = increase the volume
- *Put the earbuds into charging case so it will turn off automatically, or press and hold the Multi-Function button for 5 seconds to turn it off.

Using Your Earbuds: Call Controls

1. Press either earbud's Multi-function Button to answer and end a call.
2. Press and hold either earbud's Multi-Function Button for 1.5 seconds to reject an incoming call.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.