

3-Port Portable USB Hub with Gigabit Ethernet

ST3300GU3B / HB30C3A1GE



ST3300GU3B



HB30C3A1GE

Component		Function
1	Built-in USB Host Cable USB-A (ST3300GU3B) USB-C (HB30C3A1GE)	<ul style="list-style-type: none">• Connect to a USB-A or USB-C Port on a Host Laptop• USB 3.2 Gen 1 (5Gbps)
2	3x USB-A Data Ports	<ul style="list-style-type: none">• Connect and Charge USB-A Peripherals• USB 3.2 Gen 1 (5Gbps)• Supports 5V/0.9A (4.5W) of Power
3	Gigabit Ethernet Port	<ul style="list-style-type: none">• Connect an Ethernet Cable to Establish a Network Connection• 10/100/1000 Mbps
4	DC 5V Power Input	<ul style="list-style-type: none">• Connect the USB Hub to a Power Source using the Included Power Adapter
5	Network LED Indicators	<ul style="list-style-type: none">• Indicates Link Speed and Activity• Link Activity LED Indicator (Green)<ul style="list-style-type: none">• Off = No Network Activity• Flashing Green = Network Activity• Link Detection LED Indicator (Amber)<ul style="list-style-type: none">• Off = No Network Detected• Solid Amber = Network Detected

Package Contents

- USB Hub x 1
- Power Adapter x1
- Quick-Start Guide x 1

Requirements

- Host Computer
- USB Port

For the latest drivers, manuals, product information, technical specifications, and declarations of conformance, please visit:

www.StarTech.com/ST3300GU3B
www.StarTech.com/HB30C3A1GE



Software Installation

Windows

1. Connect the **Built-in USB Host Cable** on the **USB Hub** to a **USB Port** on the **Host Computer**. The **USB Hub** should automatically install using native drivers. If the drivers do not automatically install, navigate to: www.StarTech.com/ST3300GU3B, or www.StarTech.com/HB30C3A1GE and click the **Drivers/Downloads** tab.
2. Under **Driver(s)**, download the Windows driver package, and extract the files contained within the zip folder that was downloaded.
3. Right-click the **Installer Setup File** and select **Run as Administrator**, then follow the on-screen instructions to complete the installation. The **Host Computer** may require restart during the installation process. Please save any unsaved work, before proceeding.

Note: If the Run as administrator option is not available, you could be attempting to run the Installer Setup from within the zipped Driver Package. Extract the files using the instructions in Step 2 in the Install the Driver section.

macOS

1. Connect the **Built-in USB Host Cable** on the **USB Hub** to a **USB Port** on the **Host Computer**. The **USB Hub** should automatically install using native drivers. If the drivers do not automatically install, navigate to: www.StarTech.com/ST3300GU3B, or www.StarTech.com/HB30C3A1GE and click the **Drivers/Downloads** tab.
2. Under **Driver(s)**, download macOS software package, and extract the files contained within the zip folder that was downloaded.
3. Open the folder corresponding to the macOS version installed on the **Host Computer**.

Regulatory Compliance

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit than the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device. If shielded interface cables are included with the product, or if additional components or accessories are designated for use with the installation, they must be used to ensure compliance with FCC regulations.

ISED Statement / Déclaration d'ISDE

CAN ICES-003(B) / NMB-003(B)

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Le présent appareil est conforme aux CNR d'ISDE Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

4. Run the **Installer File**, and follow the on-screen instructions to complete the installation. The **Host Computer** may require restart during the installation process. Please save any unsaved work, before proceeding.

Ubuntu (20.04 Kernel 5.15 and up - LTS Versions only)

1. Connect the **Built-in USB Host Cable** on the **USB Hub** to a **USB Port** on the **Host Computer**. The **USB Hub** should automatically install using native drivers. If the drivers do not automatically install, navigate to: www.StarTech.com/ST3300GU3B, or www.StarTech.com/HB30C3A1GE and click the **Drivers/Downloads** tab.
2. Under **Driver(s)**, download the Linux software package, and extract the files contained within the zip folder that was downloaded.
3. Follow the instructions in the accompanying **Readme file** to finish the installation.

Hardware Installation

1. Connect the **Built-in USB Host Cable** on the **USB Hub** to a **USB Port** on the **Host Computer**.
2. Connect USB Peripherals to the **USB-A Data Ports** on the **USB Hub**, using the required cabling (sold separately).
3. Connect an RJ-45 terminated network cable (CAT 5e or better) from your local area network (e.g. Router, Switch, Modem, etc.) to the **Gigabit Ethernet Port**, located on the **USB Hub**, to access a network via a wired LAN connection.

Warranty Information

This product is backed by a two-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.



StarTech.com Ltd.
45 Artisans Cres
London, Ontario
N5V 5E9
Canada

StarTech.com LLP
4490 South Hamilton
Road
Groveport, Ohio
43125
U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Rd,
Brackmills
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp