

# LUMARY SMART CEILING FAN LIGHT USER MANUAL



Lumary

# LUMARY SMART DEVICE

## User Manual

Thank you for choosing Lumary products. Ready to get started? Download the Lumary App to manage your devices from your phone and tablet. Easily connect to your home Wi-Fi and control multiple devices with touching fingertips. We are a professional, authentic smart lights producer, we are committed to provide top tier service and continuously optimize our application and products.


## Contents

---

Product & Notes	3
Installation Instructions	4-5
Application Connection	6-11
Group Control	12-14
Remote Control	15-16
FAQ	17-18
Parameter Information	20-21
App-To-App Voice Control	22-27

# Product&Notes

## What's in the Box



- Lumary Smart Ceiling Fan Light

### PACKAGE CONTENTS



M5x35mm Screws and concrete for install the hanging plate to the ceiling



M2x20mm Screws and concrete for remote holder



M4x32mm Screws and caps for install the mounting plate to J-Box(Not included)



Nuts Cap



M3x10mm Screws for secure the mounting plate



Remote and holder

## Get Ready

- Know your Wi-Fi network and password.
- Make sure your mobile device is running iOS 13.3 or higher and Android 9.0 or higher.
- Make sure you're connecting to a 2.4GHz Wi-Fi network (Lumary can't connect to 5GHz networks).

# INSTALLATION INSTRUCTIONS

## IMPORTANT:


Read all instructions before installing fixtures. Retain for future reference.

## SAFETY:


For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

## WARNING :


Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.




Please make sure turn off the power of the circuit breaker before installation.




Screw the hanging plate to the J-box. Connect the wires with Terminal Cap. (Black is positive and white is negative)




Screw the hanging plate to the Ceiling.



Rotate the lamp body to the secure the light to the hanging plate.





Tighten the screws of the mounting plate to ensure the lamp is installed firmly.




Turn on the power of the circuit breaker.

# Application Connection


1. Find and install the "Lumary" App on App Store, Google Play.



## 2. Register a Lumary account.



Enter your email address.



Log into the App.

**Note:** Please select your region and country.



### 3. Connect

**NOTE:** Lumary's products can't connect to 5GHz networks.

Steps:

1. Advised to enable Bluetooth, Enable Bluetooth to add some Wi-Fi device easily;



2. Each time the device without distribution network is powered on, confirm the light is breathing or blinking pairing mode;



3. Open the Lumary App, In the top corner of the Devices screen, click "+" and select "Add Device" to confirm that the device is paired.

**If not, you need to use the wall switch to reset: on-off-on-off-on;**

4. Find the device, choose Wi-Fi and enter password, press "Next". Click "Add", and wait patiently. After that, click "Done", and the device is successfully added to the App.

5. Other ways to add devices, Open the Lumary App>> In the top corner, click ">> Choose "Lighting">> Select "Light Source (BLE + Wi-Fi)">> Select "AP Mode" or "EZ Mode" in the upper right corner.





## 4. Troubleshooting

1. Can't connect to your Wi-Fi network.



Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

2. If you fail to bind, you will need two phones, one to set the hotspot and the other to connect the hotspot and add the device through the app. If the device is successfully added, the device is normal. The problem may be in the router, you need to check your router Settings to see if there are MAC and DHCP restrictions. Lumary's products do not support 5GHz networks.



3. If you have any questions. You can contact us via our after-sales email: [support@lumary.tech](mailto:support@lumary.tech) or leave a message on our official social media account.

# Group Control



1. Log in to Lumary App, tap the smart device and enter into, click "✎" in the top right corner.




2. Click "Create Group", then select a device and save.



3. You can reset the group name and save it, and the group can control devices.



# Remote Control





1: Turn on/off 3: Fan rotates: forward/ in reverse 5: Fan speed: 1 is the weakest, 6 is the strongest 7: Turn on white color 9: Change brightness 11: Change RGB color 13: Countdown Timing 1 Hour/4 Hours	2: Wind mode: nature/soft 4: Shaking head (Not supported yet) 6: Fan on/off, Long press 5 seconds to trigger the pairing mode 8: Turn on RGB color 10: Change color temperature 12: Change RGB mode
--	--

The remote control and the fan light are paired by default at the factory, so there is no need to pair them.

If the remote control doesn't work, please re-pair it as below.

1. Connect the fan light to the power supply and make sure the fan light works normally (the light comes on slowly);
2. Turn the fan light off for 5~10 seconds and then turn it back on by wall switch;
3. Press and hold the button "1" until the fan light blinks 3 times rapidly and then release it;
4. Remote control pairing is successful, at this time you can press the button to control the fan light.

Long press the button "6" for 5 seconds to make the fan light enter App pairing mode;

# FAQ

---

## 1. Why does the flickering occur with Lumary products?

Lumary's products are factory set to the default network configuration. If the device has not been connected to the network, it will flash for three minutes each time it is powered on. If the device has not been connected to the network, it will flash for three minutes every time it is powered on. If the device is connected to the network, it will stop flashing and will automatically connect to the network when it is switched off and on via the wall switch after 15 seconds.

## 2. What should I do if the device Appears offline or is unreachable?

Make sure your Wi-Fi router is online and in range, and check that you have the latest Lumary functionality by clicking "Check for firmware update" in your device settings. Try to turn off the device >> clear the application cache >> reboot the router >> turn on the device after one minute and check and confirm the device status after five minutes.

## 3. How do I reset the device?

- To reconnect to Wi-Fi, Reset the device through the wall switch, on - off - on - off - on
- Reset once (press switch on - off - on - off - on ) to reach Easy Mode, indicated by rapidly blinking white light. Refer to connect in Easy Mode.
  - Long press the button "6" for 5 seconds to make the fan light enter App pairing mode.

## 4. How many devices can I control?

- The maximum number of timers that can be added to a single device: 30
- Maximum number of devices that can be added in a single home: 120
- The maximum number of Tap-to-Run that a single home can create: 100
- Maximum number of Automation that can be created in a single home: 100
- The maximum number of tasks that can be added in a Tap-to-Run: 150
- The maximum number of tasks that can be added in an Automation: 150
- The maximum number of conditions that can be added in an Automation: 10
- The maximum number of mobile devices that can simultaneously log in to an account is: 200
- The maximum number of Homes that can be created by a single App account is: 20
- The maximum number of home members that can be added in a single home is: 20
- The maximum number of rooms that a single home can create is: 20
- The maximum number of devices that can be added in a single room is: 50
- The maximum number of devices that can be added in a single device group is: 100
- The maximum number of device groups that a single home can create is: 20
- The maximum number of each device group that can be shared with other users is: 20
- The maximum number of each device that can be shared with other users is: 20
- The maximum number of each App account that can be invited by other homes is: 20

## 5.What should I do,when I find a problem with the purchased product?

Please email us ([support@lumary.tech](mailto:support@lumary.tech)) with your Amazon order ID. We are dedicated to ensuring your 100% satisfaction. Rest assured if the problem is with this product, we'll be more than happy to exchange it for a new one immediately.

## Parameter information

---

Name	Lumary Smart Ceiling Fan Light
Model	L-CFL18A1
Input Voltage	100-130VAC,60Hz
Wattage	Light: Max.35W Fan: 15W
Color Temperature	RGBAI +Tunable White(2700K-6500K )
CRI	80+
Lumens	2800lm
Beam Angle	120°
Rated Life	25000h



**FCC ID:2ANDL-CB3S**

**Made in China**

## CAUTION:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



# VOICE CONTROL GUIDE

Name and Control Each Device by Voice




# Work With Amazon Alexa

1. Log in to Lumary App, tap the smart device and enter into, click "✎" in the top right corner.
2. Tap "Alexa" in Third-party Control.
3. Tap "Sign In With Amazon".



4. Tap "Allow";
5. Linked successfully, when add new device, there is no need to link again, just discover new device in Alexa.







To control your Lumary smart device, just ask Alexa. Make sure your devices are already set up using the Lumary app.

Things you can say\*:

"Alexa, discover my devices."

"Alexa, turn on the bedroom light."

"Alexa, set the bedroom light to orange."

"Alexa, turn off the coffee machine."



"Alexa, set the living room to 50%."

"Alexa, dim porch light."



\*Some commands require compatible devices.

# Work With Google Assistant

1. Log in to Lumary App, tap the smart device and enter into, click "✎" in the top right corner.
2. Tap "Google Assistant" in Third-party Control.
3. Tap "Link with Google Assistant".



4. Click "Agree and link";
5. Linked successfully, when add new device, there is no need to link again, just discover new device in Google Home.





To control your Lumary smart device, just say "Hey Google", and ask.

Make sure your devices are already set up using the Lumary app.

Things you can say\*:

"Hey Google, turn on all the lights in my bedroom."

"Hey Google, turn off the light."

"Hey Google, set the bedroom light to orange."

"Hey Google, turn off the coffee machine."

"Hey Google, set the living room to 50%."

"Hey Google, dim porch light."

\*Some commands require compatible devices.

If you have any questions about use and operation, you can contact us!

Customer Service Email:

support@lumary.tech

You can also search for our "account name" and "enter URL" on social media platforms or directly scan the following QR code to find us quickly.


- Facebook: US-Smart Home  
(<https://www.facebook.com/Lumary-Smart-Lighting-102878658675054>)
- YouTube: Lumary Official  
(<https://www.youtube.com/channel/UCcEQnWxockzsPwyPOfSppug>)
- Instagram: lumary Smart Home  
(<https://www.instagram.com/lumarysmartlights/>)
- Twitter: Lumary @Lumarysmarthome  
(<https://twitter.com/Lumarysmarthome>)
- Pinterest: Lumary Smart Home  
(<https://www.pinterest.com/LumarySmartHome/>)



Facebook



Youtube



Instagram



Twitter



Pinterest

Can't connect? Need help?



HAVING AN EASY TALK TO US BEFORE YOU RETURN  
THE PRODUCT WILL FIX A PROBLEM MORE QUICKLY

Lumary support:

[support@Lumary.tech](mailto:support@Lumary.tech)

Visit us at:

[www.lumary.tech](http://www.lumary.tech)

[www.lumarysmart.com](http://www.lumarysmart.com)