


TOTAL

One-Stop Tools Station

TOTAL

AIR SPRAY GUN

PRODUCT MANUAL




TAT10401




GENERAL SAFETY WARNINGS

Important safety instructions



1. For toxic vapors produced by spraying certain materials can create intoxication and serious damage to health. Always wear safety glasses, gloves and respirator to prevent the toxic vapor hazard, solvent and pointing paint coming into contact your eyes or skin. (see Figure 1).
2. Never use oxygen, combustible or any other bottle gas as a power source or would cause explosion and serious personal injury. (see Figure 2).
3. Fluid and solvent can be highly flammable or combustible. Please use the tool only in well-ventilated area, and avoid any ignition sources, such as smoking, open flames and decrial hazard. (see Figure 3).
4. Disconnect tool from air supply hose before doing tool maintenance and during non-operation, for emerge stop and prevention of unintended operation, a ball valve near the gun to air supply is recommend.
5. Use clean, dry and regulate compressed air rated at 3.0-4.0bar, never exceed maximum permissive operating pressure 8.3bar (120psi) (see Figure 4).
6. Never use homogenate hydrocarbon solvent, which can chemically react with aluminum and zinc parts and chemically compatible with Alum. and zinc pats.
7. Never point gun at you and others at any time.
8. Before operating the tool, make sure all the screws & caps are securely tightened in case of leaking;
9. Before painting, make inspection for free movement of trigger and nozzle to insure tool can operate well.
10. Never modify this tool for any other applications. Only use parts, nozzles and accessories recommended by manufactures.

SPECIFICATIONS





- | | |
|-----------------------------|---------------------|
| 1. Aluminium cup | 4. Air inlet plug |
| 2. Needle, nozzle & air cap | 5. Pattern adj.knob |
| 3. Trigger | 6. Fluid Adj.knob |

Technical specifications

Model No.	TAT10401
Air inlet	1/4 "
Type of feed	Gravity
Standard dia of nozzle	1.5mm
Optional dia of nozzle	1.2-1.8mm
Recommended air pressure	3.0-4.0bar (43.5-58psi)
Max. Pressure of air	8.3 bar (120psi)
Paint capacity	400cc
Avg. Air consumption	119-200 L/min (4.2-7.1cfm)
Pattern width	180-250mm (7-1/8 " -10 ")
Weight	0.5kgs (1.1 lbs)
A-weighted sound pressure level	95.6 dB(A)
Sound power level	87.7 dB(A)

OPERATION PICTURE



OPERATION

Instructions for operation

Preparation

1. After unpacking the product, inspect carefully for any damage that may have occurred during transit. Make sure to tighten fittings, bolts, etc., before putting unit into service.
2. Thoroughly mix and thin paint in accordance with the paint manufacturer's instructions. Most materials will spray readily if thinned properly.
3. Strain material through filter, cheese cloth or a paint strainer.
4. Fill the canister about $\frac{3}{4}$ full and start the air compressor.

⚠Warning:

Do not exceed maximum pressure of spray gun or any other parts in the compressor system.

5. After Connect the gun to air supply, please make sure that the fluid cap, container and air hose have been connected tightly with spray gun.
6. Set up a piece of cardboard or other scrap material to use as a target and adjust for best spray pattern.

⚠Warning:

Never aim or spray at yourself or anybody else which would cause serious injury.

7. Test the consistency of the material by making a few strokes on a cardboard target. If material still appears too thick, add a small amount of thinner.

Thing with care!

Do not exceed paint manufacturer's thinning recommendations.

Operation

1. Begin spraying. Always keep the gun at right angles to the work.
2. Keep the nozzle about 6 to 12 inches from the work surface. Grip the gun keeping perpendicular with spraying area then move it parallel for several times, stopping gun movement in mid-stroke will cause a buildup of paint and result in runs. Do not fan the gun from side to side while painting. This will cause a build-up of paint in the center of the stroke and an insufficient coating at each end.
3. Trigger the gun properly. Start the gun moving at the beginning of the stroke before squeezing the trigger and release the trigger before stopping gun movement at the end of the stroke. This procedure will blend each stroke with the next without showing overlap or unevenness.
4. The amount of paint being applied can be varied by the speed of the stroke, distance from the surface and adjustment of the fluid control knob.
5. Overlap strokes just enough to obtain an even coat. NOTE: Two thin coats of paint will yield better results and have less chance of runs than one heavy layer.
6. Use a piece of cardboard as a shield to catch overspray at the edges of the work to protect other surfaces.

MAINTENANCE

Incomplete cleaning could cause function failures and a degradation of the fan form.

1. Remove any remaining paint by pouring it into another container.
2. Disassemble the spray gun making sure to remove the needle before disassembling the nozzle to avoid damage to the housing of the nozzle closure.
3. Clean all the paint passages and the nozzle. Clean the other components using a brush soaked in solvent.
4. Reassemble the spray gun and spray a small quantity of solvent to eliminate all the residues in the paint passages.
5. After the product is broken, it should be sent to a special recycling agency, not discarded at will.

Warning:

Never use metal or other objects that could damage the holes in the nozzle and cap. never immerse the spray gun completely in solvent. never use components or parts that are not manufacturer originals.

Storing

1. When not using spray gun, turn the fluid adjustment knob counter-clockwise to open which will reduce spring tension on needle fluid tip.
2. Spray gun **MUST BE** well cleaned and lightly lubricated.

TOTAL

One-Stop Tools Station

www.totalbusiness.com

   TOTAL TOOLS WORLD
MADE IN CHINA TO723.V08



TOTAL TOOLS CO., PTE. LTD.

No. 45 Songbei Road, Suzhou Industrial Park, China.

