# loffee

# **TOUCH**

Triple Mode Connection Mechanical Keyboard

Product name: **TOUCH 68 Triple Mode Connection** Mechanical Keyboard


Model: OE902, OE912 SHENZHEN LOFREE CULTURE CO., LTD


### **SPECIFICATIONS:**

Number of keys:68(hot-swappable Mechanical Switch) Number of Multimedia Keys: 12 Materials: ABS Body, PBT Keycaps Interface: Type-C Mode: 2.4G & Bluetooth & Wired Device Name: Touch68@Lofree


#### FEATURE DESCRIPTION:

Dimensions:310mm\*109mm\*5L5mm









#### 1 Battery Indicator Wired Mode

- the indicator light is steady white.
- Bluetooth Mode/2.4G Wireless USB mode. When the power is lower than 20%, the indicator light flashes
- slowly in red; When the power is lower than 3%, the indicator light flashes
- quickly then automatically turn off; ② Status indicator (white light)

## Caps Lock Indicator

Multimedia sign Mac

Solid LED light = The uppercase mode is turned on; LED light off= The uppercase mode is turned off;

## •Bluetooth Pairing Indicator(white light)

- Flashing LED light = The device is in Bluetooth pairing mode; When successfully paired, the Pairing Indicator turns on for 3 seconds, and then turns off again;
- During each switch to a new device, the Pairing Indicator flashes quickly for 3 seconds, and then turns off again

#### •2.4G Wireless USB Pairing Indicator

- When the 2.4G receiver is started for pairing, the Pairing indicator flashes quickly for 3 seconds
- When successfully paired, the Pairing Indicator turns on for 3 seconds, and then turns off again

# 3 Status switch

2.4G / Bluetooth mode / ON: Wired mode / OFF: Off


# Type-C interface

(5) Battery cover




## Detailed user guide

#### 2.4G Wireless USB mode






2 Take out the 2.4G receiver








Note:MAC/IOS system devices do not support multimedia functions under 2.4G USB connection

#### **5** Switch the status to 2.4G/BT gear

6 Press and hold Fn+R to start 2.4G connection mode




7 The status indicator flashes 8 This light turns on for 3 quickly for 3 seconds then seconds then turns off again





Bluetooth mode:






3 Turn on the Bluetooth function of your device, search for "Touch68@Lofree"




4 When successfully paired,

2 Long press Fn+Q/Fn+W/

Fn+E until the status





#### System Switch

Fn+N in the upper right corner is the key to trigger the corresponding system function of windows Fn+M in the upper right corner is the key to trigger the corresponding system function of Mac

# Multimedia and function keys

Fn+l in the upper right corner...= the

function k	eys	
Function sign	Мас	Windows
♠ +Shift+ESC	`~	`~
Fn +1	F1	F1
Fn +2	F2	F2
<b>Fn</b> +3	F3	F3
Fn +4	F4	F4
<b>Fn</b> +5	F5	F5
Fn +6	F6	F6
<b>Fn</b> +7	F7	F7
Fn +8	F8	F8
<b>Fn</b> +9	F9	F9
Fn +()	F10	F10
Fn +	F11	F11
Fn ++-	F12	F12
Fn +\	PrtSc	PrtSc
Fn +Del	Ins	Ins
₱ +Pgup	Home	Home
₱ +Pgdn	End	End

#### Fn Fn+1 in the Bottom left corner...= the 🗇 multimedia keys

Windows

		0		
	FN+1!	⇔	Reduce brightness	Reduce brightness
	FN+2@	*	increase Brightness	increase Brightness
	FN+3#	60	Multi Screen	Multi Screen
	FN+4\$	Q	Search	Search
	FN+5%	<b></b>	/	ON/Cortana
	FN+6^	G		Sleep Mode/ON
	FN+7&	◁	Previous Track	Previous Track
	FN+8*	00	Play/Pause	Play/Pause
	FN+9(	$\triangleright$	Next Track	Next Track
	FN+0)	∢x	Mute	Mute
	FN+	Φ	Volume Down	Volume Down
	FN+=+	(1)	Volume Up	Volume Up
	FN+Opt/Ctrl	⊒	Menu Button	Menu Button

Note: Multimedia key FN+5%/FN+6^: Some models of Mac system devices may not support the triggering of this multimedia key due to the problem of matching the connected device model

#### NAME AND CONTENT OF HAZARD-OUS SUBSTANCES IN PRODUCT:

Harmful	Hazardous substances					
Elements	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr, VI)	Polybrominat- ed Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)

This table is prepared in accordance with the provisions of SJ/T

The classification and marking of this product was performed in accordance with the EU directive 2011/65/EU and the revised

O:Indicates that the said hazardous substance contained in all the homogeneous materials for this component is below the limit

X:Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

#### ENVIRONMENTAL PROTECTION INSTRUCTIONS:

this product will not leak or change under normal use conditions fora period often years. Duringthesame period, the electronic components of this product witl not cause serious environmen-tal pollution orserious.damage to human health or property white the products are being used by the consumer.

According to the Chinese electronic industry standard SJ/T 11364-2014 and retated Chinese government regulations, this have an environmentally friendly use period mark, depending on the component and component manufacturer, the mark lifespan on the product and its components may vary. The expiration

date on the component takes precedence over any conflicted or different UFUP [abelson the product.

•If the battery is not replaced properly, there may be leakage or explosion and personal injury hazards.• Do not use the battery when there is leakage, discoloration, deformation, or any other

 Do not leave the battery in a discharged or unused state for a long time.

•Do not short-circuit the product •Battery life varies with usage. Used batteries should be disposed of in accordance with local laws or thrown away in trash cans for recycling electronic devices.

•If any liquid accidentally enters the product, please immediately disconnect the power supply and remove the product. Continue to use the product may cause fire or electric shock. Please contact the agent or the nearest customer service center for inspection and maintenance.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. cations. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can

be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

responsible for compliance could void the user's authority to operate the equipment

# LOFFEE

202-F8, F518 Idea Land, 1065 Bao Yuan Road, Shenzhen

Service Hotline: 4006002083 www.lofree.com.cn www.lofree.co ■ lofree.co lofree.co