

#### THE FOLD-AWAY WORK SURFACE

### INSTRUCTION MANUAL & ASSEMBLY INSTRUCTIONS

Thank you for choosing The Quick Bench. This product will be an integral part of your life with an array of applications in garages, laundry rooms, kitchens, and anywhere you need extra space.



#### TO REDUCE THE RISK OF SEVERE INJURY OR DEATH:

- READ AND FOLLOW ALL DIRECTIONS
- Never apply more force than the products published load limit
- Do not make any modifications to the product
- Never operate unless bench is properly installed and secured to wood studs
- Never allow children to operate or play on or around bench
- Never operate bench under the influence of alcohol or drugs



THE QUICK BENCH'S CAPACITY IS 500 LBS. OF STATIC LOAD EVENLY DISTRIBUTED OVER THE TOP OF THE BUTCHER BLOCK COUNTERTOP.

THE BRACKETS MUST BE ANCHORED TO 2" STUDS TO PERFORM CORRECTLY AND BE ABLE TO SUPPORT THE RATED CAPACITY.



THIS PRODUCT MUST BE SECURELY MOUNTED TO WOOD STUDS ON A FLAT WALL. THE WOOD STUDS MUST HAVE THE ABILITY TO HOLD THE WEIGHT OF THE QUICK BENCH AND ITS CONTENTS. ANY MISAPPLICATION OF THIS PRODUCT TO NON-STUDS WILL VOID THE WARRANTY AND THE PRODUCT WILL BE DEEMED UNSAFE DUE TO OWNER'S INSTALLATION ERROR.

If you do not feel comfortable installing this bench, contact a licensed professional.



ASSEMBLY TIME SHOULD TAKE AROUND 20-MINUTES WITH ONE PERSON TO ATTACH THE BRACKETS TO THE STUD WALL AND TWO PEOPLE TO LIFT THE BUTCHER BLOCK TOP AND FASTEN IT IN PLACE.



#### WARNING:

Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the State of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection.

For more information go to www.P65Warnings.ca.gov/wood.

DV | QBIM-10202020

## **TOOLS & MATERIALS NEEDED:**

### TOOLS (NOT INCLUDED)

- Drill
- 1/8" Drill Bit
- 8 mm Socket
- Stud Finder
- Tape Measure

#### Level

- Pencil
- Phillips
  - Screwdriver

### HARDWARE (INCLUDED)

QTY DESCRIPTION


- 1 Wood Top
- 2 Mounting Brackets
- 7 1" Screws
- 7 2-3/8" Lag Bolts
- 7 Washers


## **ASSEMBLY INSTRUCTIONS:**








- 1. Determine and mark the desired height of the workbench on the wall with a pencil. (NOTE: The bench is designed to operate at a height of 30" to 72".)
- 2. Use a stud finder to find the closest stud and mark the location. Then measure 2-1/4" down from your predetermined workbench height and predrill a hole with the 1/8" bit.
- 3. When hole is predrilled, fold down spring support plate and secure top bolt and washer using your 8 mm socket through bracket and into stud behind wall. Make sure support plate is all the way down so it does not create a pinch point.














10. Center wood top between the brackets.

(NOTE: If the brackets are placed 16" apart, the ends of the bench will be 16" from the outside of the brackets. If the brackets are placed 24" apart, there will be 12" from the ends to the outside of the brackets.)

11. Have a second person hold the board in place to make sure it does not move or fall. Mark the desired screw locations and predrill holes not more than 1" deep with 1/8" bit. Screw the 6 - 1" screws into the underside of the countertop to fasten the board in place.









# **OPERATING INSTRUCTIONS:**

PLEASE NOTE: AFTER THE ASSEMBLY IS COMPLETE AND BEFORE USING YOUR BENCH, IT IS IMPORTANT TO UNDERSTAND LOCATIONS IN AND AROUND YOUR HINGES WILL CREATE PINCH POINTS.

- 1. Ensure bench is clear of all items that could interfere with the bench's range of motion and that all bolts and screws are securely fastened to the studs and the countertop.
- 2. To raise the bench, lift the bench upward until you hear the brackets click and lock into place.
- 3. To lower the bench, stand in front of the bench and use your fingers to locate the release on the end of both brackets. Slightly lift then press the releases and lower the bench to the wall. When you lower the bench it will fit flush against the wall.

