

INSTALLATION INFORMATION

The Wolf convection microwave oven can be set up as a free-standing unit or set into a built-in wall installation.

This section of the manual covers some of the installation issues that a service technician may need to know when servicing a Wolf convection microwave oven. If additional installation information is needed after reviewing this section of the manual, please refer to the installation guide or contact the Wolf Appliance Customer Service Department.

Electrical Requirements

- 110 to 120 Volts AC, 60Hz, 15 ampere fused electrical supply
- Separate electrical circuit serving only this appliance
- A properly grounded 3-prong receptacle

⚠ WARNING

THE INSTALLATION SITE MUST BE EQUIPPED WITH A PROPERLY GROUNDED 3-SLOT RECEPTACLE TO MATCH THE 3-PRONG (GROUNDED) POWER SUPPLY CORD PROVIDED ON THE APPLIANCE. IF THE ELECTRIC RECEPTACLE OR POWER CORD ARE NOT PROPERLY GROUNDED, THIS COULD CAUSE A SHOCK HAZARD AND THE APPLIANCE MAY NOT FUNCTION.




Figure 2-1. Electrical Receptacle & Power Cord

⚠ WARNING

TO AVOID SHOCK HAZARD, NEVER REMOVE THE GROUND PRONG FROM THE PLUG OF THE POWER SUPPLY CORD.

⚠ WARNING

- **EXTENSION CORDS ARE NOT RECOMMENDED.**
- **IF AN EXTENSION CORD IS NECESSARY, USE ONLY A 3-WIRE CORD WITH A 3-PRONG PLUG AND A 3-SLOT RECEPTACLE, RATED FOR 115 - 120VOLTS, 15 AMP OR HIGHER.**
- **DO NOT DRAPE EXTENSION CORD OVER COUNTERTOP OR TABLE WHERE IT CAN BE PULLED ON OR TRIPPED OVER ACCIDENTALLY.**

Free-Standing Installation

With the convection microwave free-standing on the countertop, it is recommended to have counter space on at least one side of the appliance. At least 2 inches of clearance must be allowed on the sides, top and at the rear of the appliance for air circulation. (See Figure 2-2)



Figure 2-2. 2" Clearance on Sides, Top & at Rear