


# Mini Projector

# Product User Manual

Model: D3-H700

## Product and interface description



(1) Lens

(2) Heat sink

(3) Power

(4) USB

(5) HDMI IN

(6) Indicator light

(7) Infrared probe

(8) Earphone port

(9) Air inlet

(10) Bracket

(11) On-off key

(12) Focusing roller

(1) Red light indicates standby or shutdown state, green light indicates power on state.


(2) Do not place other objects within 30cm near the cooling hole.

(3) If a bracket is required, use the specified screw and suitable bracket.

(4) Be sure to use the power adapter equipped with the product (adapter input:  $19\text{v} = 3.42\text{A}$ ).

(5) The interface of the bottom fixed external support is 1/4 inch nut (depth 5mm), which is compatible with the universal triangular bracket in the market.

## Remote control



(1) Trapezoidal correction button: Short press on the home page to quickly pop up the trapezoidal correction page settings.

(2) Video signal key: press the key on the home page to quickly switch the HDMI input source.

(3) Display mode key: forward projection, rear projection, lifting forward projection, lifting rear projection, a total of 4 modes.

(4) Please pay attention to the positive and negative poles when changing the remote control battery.

(5) No charging of attached battery.

(6) The best distance of remote control is within 5 meters.

## Operating instructions

(1) **Power on operation:** after connecting to the power supply, press the power key to power on.

(2) **Standby operation:** in normal use mode, short press the power key to enter the standby mode. In standby condition, short press the power button to wake up the device and display normally.

(3) **Shutdown operation:** in normal use state, long press the

( 4 ) **Safe shutdown mode (applicable to battery version):**


under normal use conditions, long press the power key for more than 6 seconds, and the device enters the protection mode (to prevent false touch). Long press the power key for more than 3 seconds before starting.

(5) **Focusing operation:** if the picture is blurred, you can adjust the picture focusing by rolling the focusing wheel left and right (the effective projection distance is 1-3m).

**Trapezoid correction instructions**

**Corrective operation process:**

- (1)Click OK to select the vertex.
- (2)Adjust the correction angle through the direction button.
- (3)Confirm and switch through OK, and finally press the return key to exit the setting; This setting is valid for the next boot.



### Product specifications

<b>Model</b>	D3-H700	<b>Name</b>	Mini projector
<b>Display</b>	LCD	<b>DisplaySize</b>	1920 x 1080
<b>Light</b>	LED	<b>LED Life</b>	20000H
<b>Size</b>	30-100inch	<b>Distance</b>	1-3m
<b>Input</b>	19V $\approx$ 3.42A	<b>Power</b>	64W

### Product component list

Name	Number
Master	1
Power adapter	1
Remote Control	1
HDMI	1
User manual	1
Battery	2

## Name and content of harmful substances in products

Name	Harmful substances					
	Pb	Hg	Cd	Cr(VI)	PBBs	PBDEs
Power	X	O	O	O	O	O
PCBA	X	O	O	O	O	O
Shell	O	O	O	O	O	O
Opto Mechanical	X	O	O	O	O	O
Fan	X	O	O	O	O	O
Speaker	X	O	O	O	O	O
Antenna	O	O	O	O	O	O
Remote control	X	O	O	O	O	O
Other metals	X	O	O	O	O	O
Internal wiring	O	O	O	O	O	O
Battery	X	O	O	O	O	O

This form is compiled according to SJ / T 11364.

O: It means that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB / T 26572.

10: It indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB / T

26572.

Note: some of the components marked with "X" above contain harmful substances, which exceed the limit value due to the limited technical level of the industry, and can not be replaced or reduced temporarily.

## Safety precautions

Thank you for purchasing and using this projector. For your safety, please read this manual carefully before using this projector. If you do not follow the instructions or precautions caused by any personal injury, as well as property or other losses, the company will not be liable.

- ◆ Before using this machine, please check the local voltage, and pay attention to whether the input voltage of the adapter is consistent. Do not use other adapters that are not matched by the manufacturer.
- ◆ Please use the standard No.7 battery for the remote control. Pay attention to the direction of battery electrode. If used incorrectly, the remote control may be damaged and cannot be used.
- ◆ Please do not direct the lens at people's eyes to avoid eye injury caused by strong light.



- ◆ Do not block the radiator and air inlet, and do not place anything within 30cm of the radiator and air inlet, so as to avoid the damage of internal components or the impact on the service life of the product due to the failure of normal heat dissipation.
- ◆ Do not place this product on flammable materials (such as bed, blanket or quilt).
- ◆ Do not knock, scratch, throw or strongly vibrate the product to avoid damage.

## Q & A

- ◆ Remote control failure or no response.

Please confirm the use distance, whether there is a shelter, or the battery contacts and replace the battery

- ◆ Black screen or abnormal picture display of projector after power on

Please confirm HDMI input format (720p 50 / 60Hz and 1080p 50 / 60Hz only) and projection setting.

- ◆ Does it support screen casting。

It can be used with the projector and connected to the HDMI input port of the product through the HDMI cable.

## Product warranty card

User			
Tel			
Address			
Order			
Date			
Scope of Three			
Product issues			
Three guarantee s type	Repair	Return Goods	Exchange Goods

If you need to return or exchange products, please contact the customer service of the store in time. Please fill in this card and send it back with the product.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.