

物料名称:	E31手表快速指南 (Letsfit App)	成品尺寸:	70 x 105mm	V2	
时 间:	2024-01-23	材 质:	128g哑粉纸, 风琴折	V3	
设 计:		工 艺:	四色 双面印刷	V3	
料 号:	202-02-SH-E31-V1	备 注:		V4	

正面

E31 Smart Watch

Quick Start Guide



This quick start guide will support you getting started using your smart watch.


If you're looking for a more detailed user manual, please open the Letsfit App, go to the "more" page and tap "help".

All pictures in this guide are for illustration purposes only. Actual product may vary due to product firmware and app upgrades.

PACKAGE CONTENTS



Smart watch with bands x 1



Charging cable x 1




Quick start guide x 1

USING YOUR WATCH


Charging 1

Please fully charge your watch before initial use.

1 Insert the USB plug of the charging cable into a USB charger.



2 Attach the other end to the charging contacts on the back of the watch.



Install the Letsfit App 2

You can download **Letsfit App** from Apple Store / Google Play or scan the QR codes below to download.



iOS 12.0 & above



Letsfit




Android 6.0 & above

Note: The App is only compatible with smartphones, not tablets or PCs.

Pair the Watch with Your Phone 3




1 Turn on the Bluetooth of your phone.



3 Two pairing methods


2 Open the **Letsfit App**. Go to the "**Device**" page and tap "**Pair device**".



Tap "**Pair by model**" -> "**E31-XXXX**" to pair.

OR

Tap "**Scan QR Code**" and scan the QR code on the watch to pair.



Bluetooth Pairing Request

Pair with "E31-XXXX" ?

Cancel Pair

Note: "Bluetooth Pairing Request" will pop up twice on your phone, please click "**Pair**" both times.

4 Tap  on the watch to confirm the connection.



反面

Controls 4



Function Button

Press

- Wake the screen.
- Return to the home screen.
- Go to the **Function List**.
- Pause / resume the sport.

Hold

- Power on / off, Reboot, Reset the watch.



Touch Screen


- Swipe to go to different interfaces.
- Tap to enter the function.
- Swipe the screen to the right to return to the previous interface.
- Press and hold Home Screen to change watch face.

Watch Interfaces 5

Notifications

MESSAGE 12:30 PM
Tejas Menon
Hi, have you completed the deckwe have to present on Monday?

Note: If your phone is an Android phone, only when your watch is connected to the Letsfit App, the App is running on your phone, and "Notification Alerts" is enabled in the App, will messages be notified.




Heart Rate 12:30 PM
Max 112 Avg 90 Min 68
68 bpm

Blood Oxygen 12:30 AM
Max 98% Min 94%
98%

Stress 12:30 PM
Max 56 Min 44
45 Relax

Sleep 12:30 PM
87
Sleep Stages

Quick Settings



Tips:

Quick Settings



Find My Phone: Your phone and watch are connected via Bluetooth, you can use the watch to locate your phone by making your phone vibrate or ring.

Note: This feature is not available on Android phones if the Letsfit app is not running on your phone.

Do Not Disturb (DND) mode:

- When the DND mode is enabled, the watch won't ring or vibrate when it receives incoming call alerts, SMS, app notifications. And Raise to Wake function will be disabled.
- DND mode does not affect Alarms.

How to Connect the Bluetooth Call function

- DND mode must be disabled before using Bluetooth Calling.
- On your phone, go to "**Settings**" -> "**Bluetooth**", tap "**E31-XXXX(Connected for calls)**" to connect.

Notes:

- To use the Bluetooth Calling feature on the watch, please keep the watch connected to your phone via Bluetooth.
- When the **DND** mode is enabled on the watch (Quick settings bar -> ) , the watch will not receive incoming call reminders, but you can use the watch to make calls.
- Ring or vibration switching can be modified in "**Setting**" -> "**Sound Vibration**".
- This feature will reduce the watch's battery life.

Important Safety Instructions

The device contains electrical equipment that may cause injury if not used properly. For example, prolonged contact may contribute to skin allergies for some users. To reduce irritation, please read the safety guidelines on the following pages to ensure proper use and care.

- Do not expose your device to liquid, moisture, humidity or rain while charging; do not charge your device when it is wet, as this may result in electrical shock and injury.
- Consult your doctor before use if you have any preexisting conditions that might be affected by using this device.
- Never try to abuse, crush, open, repair or disassemble this device. Doing so will void the warranty and can result in a safety hazard.
- If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
- Do not use your device in a sauna or steam room.
- Dispose of this device, the device's battery and its package in accordance with local regulations.
- Do not check any notifications, GPS, or any information on your device's display while driving or in other situations where distractions could cause injury or hazard. Always be aware of your surroundings while exercising.

Battery Warnings

A lithium-ion battery is used in this device. If these guidelines are not followed, batteries may experience a shortened life span or may cause fire, chemical burn, electrolyte leakage, and/or injury.

- Do NOT disassemble, modify, remanufacture, puncture or damage the device or batteries.
- Do NOT remove or attempt to remove the non-user-replaceable battery.
- Do NOT expose the device or batteries to fire, explosion, or other hazards.

Health Warnings

- If you have a pacemaker or other internal electronic device, consult your physician before using a heart rate monitor.
- The optical wrist heart rate monitor emits green light and flashes occasionally. Consult your physician if you have epilepsy or are sensitive to flashing lights.
- Always consult your physician before beginning or modifying any exercise program.
- The device, accessories, heart rate monitor, blood oxygen level measurement and related data are intended to be used only for recreational purposes and not for medical purposes and are not intended to diagnose, monitor, treat, cure, or prevent any disease or condition.

FCC ID: 2BAS2-E31

NOTE: This equipment has been tested and found to comply with the limits for Class B digital devices, in accordance with section 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

202-02-SH-E31-V1

Important Safety Guide

Some people with allergic skin may react when their skin is exposed to materials used in watches for a long time. This may be caused by allergies, environmental factors, prolonged exposure to irritants such as sweat and soap, or other factors. If you have known skin allergies, please pay special attention when wearing the watch.



Please do not wear your watch too tight.



If your watch gets wet (for example after sweating or showering), clean and dry it thoroughly before putting it back on your wrist.



Make sure your skin is dry before you put your watch back on.



Prolonged rubbing and pressure may irritate the skin, so give your wrist a break by removing the watch regularly.