磁吸光学自行车灯

用

产品使用前指南

请在使用产品前仔细阅读本指南 请阅读"注意事项"以正确使用产品 请将仔细阅读本指南并将保存在容易找到的地方

【安装方式】

【步骤一】

1.灯体与磁吸座连接、安装好后、检查灯与座子是否扣 紧, 防止虚扣假扣。



[步骤二]

2.通过M5螺丝把磁吸座和支架连接固定。



【 步骤三】

安装方式

3.开灯,调整好合适的骑行角度后,把螺丝锁紧,防止 光通量/Luminous flux 骑行过程中, 灯体角度摆动。



远光/High beam

产品参数

尺寸/Size

防水/Waterproof

功能/Function

智能/Intelligence

恒温/Constant temper

反充/Countercharge

续航/Running time

控/Drive-by-wire

无线控制/Wireless con

安装方式/Mounting

电池容量/Battery

充电电流/Charging co

光/Low beam

注明:

重量/Weight

蓝牙/Bluetooth

照射距离/Distance

有此功能符合: ● 此功能可选: ○ 无此功能: /

充电和透镜类别

AL+PC


低亮/中亮/高亮/呼吸/快闪

200-1600LM

Gopro磁吸

18W 支持QC和PD快充

1.打开USB盖,连接上TYPE-C,请使用TYPE-C的充电器充电。 2.充完电后,请把USB盖好。



RS天使之眼



注意事项

- ●本产品可生活防水,但在暴雨环境中长时间暴露或浸泡使 用时会导致故障。
- ●如果水或液体流入产品内部, 请立即关闭电源, 完全干燥, 然后重新启动。 ●请勿丢弃本产品或进行强烈冲击,如果反复冲击,可能会
- 导致内部故障。 ●可拆卸电池版本,长时间保存产品时,请将电池卸下,避免 阳光直射和高温多湿环境。
- ●如果您对本产品进行任何改造或维修,本产品可能会出现故 障并且您将无法获得本公司的服务,即使你不在保持期内。
- ●充电完成后,请拔掉充电线。 ●请勿将本产品加热或放入火中,可能会引发爆炸和火灾。
- ●不要将光线直接照射到人或动物的眼睛, 会引起视力下降或
- 使用或保管时,请不要让幼儿接触。
- ●请在60℃~-20℃环境下使用。
- 不要在地毯或被子等防火材料上使用。
- ●如果液体从主机流出, 沾到身体上, 千万不要揉到眼睛上, 如果粘到眼睛上, 请使用干净的水立即冲洗或找医生及时
- ●如果因充电发热导致产品出现异常或变形,请立即停止充 电并联系我们的客服中心。
- 如果废弃随附的电池,请按相应分类放置。 对于在使用过程中发生的不遵守注意事项的故障,即使未 . 超过质量期限,将无法为您提供服务。
- 请将本说明书保存在于易于查找的地方,以便日后参考。

无线按健功能图



- :无线配对: 开灯情况下, 快速连续三击按键, 指示灯变为黄色, 再 按下无线按键开关机键, 主灯亮起, 则配对成功。
- :开关按键🕲 ;此按键开有四个功能。
- 1、长按0.5S为开关机。 2、快速双击为警示模式切换。
- 3、快速三击,为配对模式。
- : 远光按键**(層**, 此按键为远光开关功能切换。
- g:若选择四按键遥控器,左右按键**()**,此按键为亮度递增或递减 操作方式为长按,可自定义亮度(选配按键功能)。
- 1: 不同遥控器使用电池不一样,常规规格为CR1620、CR1632、CR2032 的规格,续航时间大约为5-12月,更换电池后,需要重新配对。

操作说明

- :开关机操作,长按0.5S秒开机或关机,开机默认保持上一次关机存
- :常亮功能: 开机后轻触功能为档位变化, 顺序为低亮、中亮、高亮。
- 警示功能: 开灯后, 通过快速双击来切换模式, 警示档位有闪烁 和呼吸,通过轻触按键调节,再次双击切换常亮模式。
- 国:电量指示,开灯后,指示灯为绿色时,表示电量充足,当指示灯 变为红色,则提醒电量低于30%,请及时充电。
- 丘:请使用TYPE-C充电器,可支持QC和PD,最大可达18W功率,充电过 程,红色指示灯呼吸,充满指示灯灭。
- 六:支持手机反充,通过TYPE-C TO TYPE-C连接,芯片自动识别。
- 长时间点亮, 灯体铝合金发热属于正常现象, 长时间点亮, 芯片 自动检测外壳温度,芯片根据温度自动调温,防止过热烫伤,请 放心使用,当极速骑行时,对流有良好散热,芯片自动释放功率

电池容量	100%	30%	5% -0%
指示灯	绿灯	红灯	关闭

Bicycle headlight

Operating instructions

Product pre-use guide

Please read the guide before using the product Please read "Precautions" to use the product correctly Please read the guide and keep it somewhere easy to find

[Installation method]

[Step 1]

1. Connect the lamp body to the magnetic base. After installation check whether the lamp and the base are securely fastened to prevent false or false buckles。



Installation method

Step 2


2. Connect and fix the magnetic suction seat and bracket with M5 screws.



The image is for reference only

Step 3

3. Turn on the lights, adjust the appropriate riding angle, and tighten the screws to prevent the angle of the light body from swinging during cycling.



product information	MF900	
Material	AL+PC	
Colour	black	
Size	L41*W44*H65	
Waterproof	IP65	
Function	Low, medium, higy, slow flash, fast flash	
Intelligence	1	
Constant temperature	•	
Countercharge	/	
Running time	2.5-12	
Drive-by-wire	/	
Bluetooth	0	
Distance	220M	
Luminous flux	200-1600LM	
Wireless control	/	
Mounting	Gopro+Magnetic attraction	
Battery	5000mAH	
Charging current	18W	
Weight	175g	
Light source	LED	
Color temperature	6000-7000K	
Low beam	•	
High beam	•	
Certification	CE ROHS	

Having this function:


Selection function: : Without this function: /

Battery replacement and mounting



1. Open the USB cover and connect TYPE-C. Please use a TYPE-C

charger to charge. 2.After charging, please cover the USB properly.





RS Series lens

Precautions

- This product is waterproof, but it will cause malfunction wher exposed to heavy rain for a long time or soaked for use.
- If water gets inside the product, turn off the power immediately dry it completely and restart it. Do not discard the product or perform strong impacts, as this
- may cause internal malfunctions. Detachable battery version, remove the battery when storing the product for a long time, avoiding direct sunlight and high
- temperature and humidity environments . If you make any modifications or repairs to the product, it may malfunction and you will not be able to access our services.
- even if you are not within the warranty period. After charging, please unplug the charging cable.
- Do not heat or place the product in a fire as it may cause an explosion and fire. Do not direct light into the eyes of humans or animals, as there
- is a risk of vision loss or blindness. • Please do not let young children come into contact when using
- Please use in an environment between 60°C and -20°C. Do not use on fireproof materials such as carpets or blankets.
- If the liquid flows out of the host, do not rub it onto the eyes. If it sticks to the eves, rinse immediately with clean water or seek medical attention in a timely manner.
- If the product experiences abnormalities due to heating during charging, please immediately stop charging and contact our customer service center.
- If discarding batteries, please place them according to their classification. For faults that do not follow the precautions during use, even if the quality period is not exceeded, we will not be able to provide you with services.
- Please keep this manual in an easily searchable place for future

Wireless button function diagram


Switch button (; This button has four functions.

1. Press and hold for 0.5 seconds to turn on and off the device.

: If you choose a four button remote control \bigcirc , press the left and right buttons. This button can crease or decrease the brightness by long pressing, and the brightness can be customized (Optional but

CR2032, with a battery life of approximately 5-12 months. After replacing the battery, it needs to be re pai

te controls use different batteries. The standard specifications are CR1620, CR1632, and



4: Battery level indicator: When the light is turned on and the indicator light is green, it indicates that the battery level is sufficient. When the indicator light turns red, it reminds you that the battery level is below 30% and you need to charge it in a timely manner.

Operating instructions

of low light, medium light, and high light

5: Please use TYPE-C charger, which supports QC and PD, with a maximum power of 18W. During the chargin process, the red indicator light will breathe and the fully charged indicator light will turn off.

: Power on/off operation, press and hold for 0.5 seconds to turn on or off, and the last stored gear will be

onstant light function: After turning on, the light touch function changes the gear position in the order

warning gear will flash and breathe, which can be adjusted by lightly touching the button. Press and hol again for 3 seconds to switch to the constant light mode.

- Support phone reverse charging, connected through TYPE-C to TYPE-C, automatically recognized by the chi
- : When lit for a long time, the aluminum alloy of the lamp body heats up, which is a normal phenomenc When lit for a long time, the chip automatically detects the temperature of the outer shell, and the chip adjusts the temperature automatically according to the imperature to prevent overheating and burns Please use it with confidence. When riding at high speed, there is good heat dissipation through conve and the chip automatically releases power to provide you with a better riding experience.

30% 100% green red

correct the interference by one or more of the following measures

Reorient or relocate the receiving antenna

Connect the equipment into an outlet on a circuit different from that to which the receive

onsult the dealer or an experienced radio/TV technician for help.

ne device has been evaluated to meet general RF exposure requirement. The device can be