



# ***PRECISION 2***


## **USER MANUAL**




CopyRight @ 2023.08

## CASE SPECIFICATION


Model No.	Precision 2 COC(MFG. T808)
Materials	Chassis 0.6/0.8mm SPCC, tempered glass on left side panel
Motherboard support	EATX(282*305mm)、ATX、M-ATX、ITX
PSU type	ATX PSU (Bottom located)
TOP panel I/O ports	USB3.0*1+USB2.0*2+Type C*1, HD Audio
HDD bay	3.5" HDD*2 , 2.25 SSD*2
Expansion Slots	7 slots , Support up to 360mm (Max.) VGA card
CPU Cooler Height	170mm
Fan Cooling	Front: 3*120/2*140mm Fans(Optional)
	Top: 2*120/140mm Fans(Optional)
	Rear: 1*120mm fan(Included)
	M/B Plate: 1x COC Turbo Fan(Included)
Liquid cooling	Front: 120/140/240/280mm water cooling Radiator
	Top: 120/140/240/280mm water cooling Radiator
	Rear: 120mm water cooling Radiator
Chassis size	(L)390 x (W)210 x (H)470mm
Case size	(L)443 x (W)210 x (H)493mm




Front




Top



Rear




Left side




Right side

## CHASSIS BREAKDOWN DRAWINGS

- ① Chassis
- ② Front panel
- ③ Left tempered glass side panel
- ④ Right side panel
- ⑤ PSU cover
- ⑥ Dust-proof filter on bottom panel
- ⑦ Magnetic dust filter on the top
- ⑧ SSD bracket
- ⑨ Cabel management box
- ⑩ Fan control board box
- ⑪ VGA card bracket
- ⑫ HDD bracket
- ⑬ COC turbo fan
- ⑭ 1\*120mm fan on the rear
- ⑮ Magnetic dust filter on the Right
- ⑯ Top panel




## I/O PORTS INSTRUCTION




- 1 USB2.0      2 USB2.0      3 HDD LED      4 Microphone jack      5 Power SW      6 Headphone jack
- 7 Reset SW      8 USB3.0      9 Type C

## SIDE PANEL INSTALLATION INSTRUCTION




1) Loose the drop-proof screws A




2) Pull up the side panel as the arrowhead direction.

## TOP PANEL INSTALLATION INSTRUCTION




1) Loose the screws B




2) Pull up the top panel as the arrowhead direction.

## POWER SUPPLY INSTALLATION




1) Remove the right side panel, then put into the PSU according to the arrowhead direction.




2) Fix the screws

## MOTHERBOARD INSTALLATION



Pre-installed 6 motherboard screws in factory setting



Put the motherboard into the right position according to the arrowhead direction, then fix the screws