
Nightstand

Assembly Instructions

Note: There is also a more detailed installation video on the product detail page on Amazon.







Made in China





General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product is screw.
- V. Power tools should not be used to assemble this product.
- VI. Please keep children and animals away from the work area, or swallowing a small portion may cause suffocation.




Parts List **(5)**

Hardware List


Λ Ο	D 0	CD 1
A x 8	B x 8	CR x 1
Ø15*9.5 mm	Ø6*32 mm	L=250 mm
CL x 1	DR x 1	DL x 1
L=250 mm	L=250 mm	L=250 mm
E x 12	F x 8	G x 1
	(a) [b]]]]]]]]]]	
∅6 * 30 mm	Ø5.5*48 mm	m4*15 mm
H x 1	I x 4	J x 4
		Antitution (
		Ø4*30 mm
K x 32	L x 4	M x 4
		(})
∅3.5*12 mm	15*15*10 mm	Ø3*16 mm
N x 4	0 x 1	P x 1
Ø25 ∗ 1.5 mm	M4 mm	**

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.







Step 1: Connect (1) 1) parts to (1) from the left and right sides with P to J.




Step 2: Insert part ③ into Step 1 notch and install B to part ⑨ with P.




Step 3: Use P to attach the A to the Step 2 hole to connect the part ⑨.





Step 5






Step 5: Use P to install the H into Step 4 with G.






Step 7: Install E to 4 5 parts, then use F to connect 3 to 4 5 parts through O.




Step 9




Step 9: Insert ⑥ ⑦ parts into Step 8 notch.


Step 10




Step 10: Install B to ① part with P.




Step 11: Install E into the corresponding hole of Step 9, then attach the ① part to Step 9 with P.





Step 12: Attach the I to the pin hole of Step 11 with K through P.



Step 13: Attach the ® part to the corresponding hole of Step 12.







Final Assembly

