



WIRELESS KEYBOARD

BY-KB-WS-113-AC

- (One) Wireless Keyboard 1 (One) USB receiver
- 1 (One) User Manual

FEATURES

- Wireless connection: automatic linking, plug & play via USB receiver.
- Responsive buttons for ultimate productivity and efficiency Ergonomic design for maximum performance and comfort.
- Customize your working angle with the flip-out stand.

OPERATING INSTRUCTIONS

1. Power ON/OFF:

The keyboard is powered by 2 (Two) AAA 1.5V Alkaline Batteries. The ON/OFF switch is I located on the top side panel of the keyboard.

- USB RECEIVER The USB receiver can be found (and stored) in a slot on the bottom of the keyboard
- under the battery compartment cover. Flin the keyboard over. Open the battery compartment door. You will see a small
- rectangular object embedded in a slot in the bottom of the keyboard, imprinted with the FCC ID number this is the USB receiver unit, and it can be stored in this slot when not in use so that it doesn't get lost or damaged. The keypad will not work without the LISB Receiver
- Remove it carefully by hooking a fingernal into the groove along the metal side surface. and lift it up slowly to free it, being very careful not to damage or lose it.

- HOW TO USE 1 • Place 2 (Two) X AAA 1 5V Alkaline Battery (not Included) into the battery compartment on
- the back of the keyboard
- Insert the USB receiver into one of your computer's USB ports.
- Turn the keyboard ON (the switch is located on the top side panel) Your computer should recognize the keyboard instantly. Be sure to check your computer's
- settings if it is not detected.
- Remove the USB receiver from your computer's USB port when the unit is not in use.

NOTE: If your computer lost connection to keyboard, unplug the USB receiver first, press and hold the ESC+Q buttons for about 3 seconds, the indicator light will flash, reinsert the USB receiver into the USB port of the computer (the keyboard will automatically connect to the receiver, and the keyboard can be used). This method can also be used if you are using new USB receiver that doesn't come with this keyboard

INSTALL THE BATTERIES IN THE KEYBOARD:

Step1: Remove the battery compartment cover on the bottom of the keyboard by squeezing the cover in from the



Step2: Insert batteries in the hattery compartment Step3: Replace the cover

tab to release it.

After 10 minutes of no button action, keyboard will enter sleep mode; If a button is pressed while the keyboard is in sleep mode, it will automatically return to its original state.

CAUTION

- This is not a toy. Please keep away from small children.
- Please keep the unit away from water and heat.
- This unit is for indoor use only. Interface compatibility: USB 2.0/3.0
- Working range: up to 33 feet (10 meters) Sleep mode: after 10 minute of inactivity, keyboard will go into sleep mode
- Sleep wake-up: press any button to wake up Operation Voltage: 3V DC±5%
- Operation Current: <100ma
- Operating Temperature: $0{\sim}45{\degree}$
- Storage Temp: -20~+60C° Forced Pairing: ESC+Q
- Storage Humidity: ≤93% (40C°

LED Light Indicators Caps Lock Num Lock —

MULTIMEDIA HOTKEYS FUNCTIONS:

- Brightness+
- Select All

Brightness-

- Volume + Previous Track

 - Paste Paste



Next Track

F1-F8 is universal to Windows® and Mac OS®; F9-12 is not workable on Mac OS®

two conditions; (1) This device may not cause harmful interference, and (2) this device

This device complies with part 15 of the FCC Rules. Operation is subject to the following

must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital. device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turnin the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help
- Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

For Wavy Wireless Keyboard-ASST This equipment complies with FCC radiation exposure limits set forth for an uncontrolled

environment.

For Wavy Wireless Keyboard-dongle: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled

FCC ID: 2AHN6-KBWS113 FCC ID: 2AHN6-DE9

2.4GHz wireless keyboard

SPECIFICATIONS

 Working range: up to 33 feet Battery: 2 (Two) X AAA 1.5V Alkaline Battery (Not Included).

COMPATIBILITY

Windows® 7/8/10/11 & Mac OS®

©2025 BYTECH NY INC BYTECH™ is a registered trademark of Bytech NY INC

- *All Trademarks and copyrights are the property
- of the respective companies
- *Mac OS* is a registered trademark of Apple Inc
- *Windows* is a registered trademark of Microsoft Corporation
- *Bytech NY Inc. has no affiliation to Apple Inc. or Microsoft Corporation, Inc.
- *Photos are for illustration purposes only.

WARRANTY- 12 MONTH

Contact Info:

2585 West 13th Street

Brooklyn, NY 11223

BYTECH intl.com

© 2025 BYTECH NY INC

MADE IN CHINA

Please visit our website Bytechintl.com/warranty

in their mouths. If they are swallowed, promotly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222)

A WARNING: TO AVOID BATTERY LEAKAGE

1) The batteries used with this product are small parts and

should be kept away from small children who still put things

- 2) Always purchase the correct size and grade of battery most suitable for intended use.
- Do not mix old and new hatteries, alkaline, standard
- (Carbon Zinc) or rechargeable (Nickel-cadmium) batteries. 1) Clean the battery contacts and those of the device prior to
- hattery installation
- 5) Ensure the batteries are installed correctly with the regard to
- 6) Always remove hatteries if consumed or if product is to be left
- unused for a long time.

