

ELECTRIC KETTLE

USER MANUAL

WWW.KOIOSSHOP.COM

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.



www.koiosshop.com



support@koiosshop.com



1-855-888-2111



m.me/KOIOSus

CONTENTS

| | |
|--------------------------------|----|
| Important Safeguards | 01 |
| Plug & cord | 02 |
| Product Introduction | 03 |
| Before First Use | 04 |
| Using Your Kettle | 05 |
| Cleaning and Maintenance | 06 |

IMPORTANT SAFEGUARDS

WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:




WARNING

- Do not touch hot surfaces. Do not touch the base or stainless steel parts during kettle heating or just finish boiling.
 - Do not fill jug above the "MAX" line. This may result in The water boils and overflows the jug, which may cause scalding.
 - Always handle with care when there is hot water inside the kettle to avoid scalding.
-
- Do not immerse the kettle, base, cord, or plug in water or other liquids.
 - Closely supervise children near the kettle. Do not allow children to use or play with the kettle.
 - Unplug the kettle when it is not being used and before cleaning. This will avoid electric shock and prevent moisture from causing a circuit in the power base while it is plugged in.
 - Allow to cool before putting on or taking off parts, and before cleaning.
 - Do not use the kettle if it is malfunctioning, broken or chipped, or if the power cord or plug is damaged in any way. Do not try to repair the kettle. Please contact our Customer Support, we will reply you within 24 hours.
 - Using accessory attachments not recommended by the manufacturer may result in fire, electric shock, or injury.
 - Do not use outdoors.
 - Place the kettle on a dry, flat surface. Do not place the kettle on or near heat sources such as stove top, ovens, radiator, etc.
 - Always make sure the lid is closed while the kettle is operating. Do not cover the spout opening while the kettle is operating.
 - To disconnect, use the On/Off Switch to turn the kettle off, then remove the plug from the wall outlet.
 - Only use the kettle as directed in this manual.
 - Household use only.

PLUG & CORD

- Do not let the cord hang over the edge of a table or counter. Do not allow the cord to touch hot surfaces.
- Your kettle has a polarized plug (one prong is wider than the other), which fits into a polarized outlet only one way. This is a safety feature to reduce the risk of electric shock. If the plug does not fit, reverse the plug. If it still does not fit, do not use the plug in that outlet. Do not bypass this safety feature.
- A short power-supply cord is provided with your kettle to reduce the risk of becoming entangled in or tripping over a longer cord.
- Extension cords may be used if care is exercised in their use.
- If an extension cord is used:
 - a. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
 - b. The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

PRODUCT INTRODUCTION



A: Spout

B: Kettle

C: Thermometer

D: Heating Plate

E: Power Base

F: Lid

G: Handle

H: Visible Water Level

I: On/Off Switch

J: Indicator Light

BEFORE FIRST USE

Water Test:

Perform the Water Test before using your kettle to make sure it's working properly. Do not drink the water that is boiled during this test.

1. Remove all packaging from your kettle and its accessories, including any temporary stickers.
2. Completely unravel the power cable and place the power base on a flat, level surface.
3. Open the lid and fill the kettle with water to the "MAX" line, then close the lid. [Fig 1]
Place the kettle onto the power base and plug in. [Fig 2]



Fig 1




Fig 2

4. Press the On/Off Switch. The blue indicator light will turn on. [Fig 3]
5. The kettle will automatically turn off once it has finished boiling the water. Allow it to cool for at least 5 minutes, then pour out the water.




Fig 3

USING YOUR KETTLE

Boiling Water:

This kettle should only be used for boiling water. Do not boil other liquids in this kettle.

1. Open the lid and fill the kettle to the desired level. Do not fill above the "MAX" line. [Fig 4]
2. Close the lid and place the kettle on the power base and plug in. [Fig 5]
3. Press the On/Off Switch. The blue indicator light will turn on. [Fig 6]
4. The kettle will automatically turn off once it has finished boiling the water.



Fig 4




Fig 5




Fig 6




Fig 7


⚠ Note:

- Always fill the kettle with water to at least the "MIN" line to prevent overheating. [Fig 7]
- You can stop the heating process by flipping the On/Off Switch back up while the kettle is operating.
- This kettle has a dry-run safety feature. If there is no water inside the kettle, it will automatically turn off to prevent the heating plate from overheating.
- If the kettle overheats, fill it with cold water and wait for 2 minutes before using again.

CLEANING AND MAINTENANCE

Cleaning:

1. Unplug the kettle and allow it to cool before cleaning.
2. Wipe the kettle and base with a soft, damp cloth. Make sure that the electric socket on the underside of the kettle is kept dry.
3. Dry all parts after every use.

 **Caution:** Never immerse kettle or power base in water.

Descaling the Kettle

You should descale the kettle at least once a week if you use it frequently. Descaling removes any mineral deposits that have built up inside the kettle. Always descale the kettle before and after storing for long periods of time.

1. Unplug the kettle and pour out all water. Make sure the kettle is cool.
2. Squeeze half a lemon into the kettle, or add ½ cup / 120 ml of distilled vinegar into the kettle.
3. If the kettle has thick scale buildup, scrub the kettle's inner walls with a non-scratch scrub sponge.

Note: Do not use steel wool, as this can scratch the kettle.

4. Add 2 cups / 475 ml of water. Boil the mixture.
5. Pour out the mixture, then wipe off any remaining scale with a non-abrasive cloth, sponge, or cleaning brush.
6. Repeat as needed.

Note: For quick descaling, add 3 tbsp / 44 ml of baking soda to ½ cup / 118 ml of vinegar into the kettle. Swirl the mixture around until it coats the walls of the kettle, wipe with a non scratch sponge, and pour the mixture out. This method will only work for a thin layer of scale

KOIOS

 www.koiosshop.com

 support@koiosshop.com

 1-855-888-2111

 m.me/KOIOSus



Made in China