

# **USER MANUAL**




XSY-299


#### BELIEF INTRODUCTION:

This Emergency Radio has FM/AM/WB stations that keep you up-to-date and connected in any situation while the powerful battery charges your smartphone and more.It's equipped with Li-ion Battery,which is not only sufficient for satisfying daily need but also can be used as power bank to charge external device.And it has multiple powered methods—solar panel, hand crank and USB input port. Furthermore, it's equipped with bright flashlight, reading lamp and SOS siren. Various survival methods prevent you far from peril.



# LINE DRAWINGS:





#### OPERATION:

• "Volume" Dial

Turn the "Volume" Dial clockwise to initiate radio and adjust volume.

• "Turning" Dial

Turn the "Turning" Dial to select stations, and the pointer indicator indicates specific stations. "TUN" indicator in pointer indicator turns on when the station selected is completely engaged; Extend the antenna to get better signal reception.

• "Band" Switch

Shift the "Band" Switch to select bands, including AM/FM/WB;

• "SOS" Button & "SOS" Function

Long press this button to turn on siren function, and press again to turn off,  $% \left( 1\right) =\left( 1\right) \left( 1\right) \left($ 

• "Flashlight" Button

Press the "Flashlight" button (on the top of radio) to turn on the flashlight;

• Reading Lamp

Flip the solar panel and reading lamp will automatically turn on;

### POWER METHODS:

The "BATT" (in pointer indicator) indicates the level of electricity, and one light presents 25% of electricity.

Solar Panel

Expose the solar panel under sunlight to generate electricity, and when it's powering the "\$\sigma" indicator will light up;


This power method is designed for maintaining daily operation, instead of a major power method.

Hand Crank

Unfold the hand crank from backside of radio and wind it in clockwise or anti-clockwise direction to charge radio. And when it's powering the "\varphi" indicator will light up, too,

• USE


Connect the supplied USB cable to the USB Input port on the right side of radio to charge the battery inside,The built-in battery is Li-ion battery.



# CHARGE EXTERNAL DEVICE:

The USB Output and Input port are covered by dust cap on the right side of radio:

Insert USB cable to the USB Output Port in the right side of radio, and connect the external device.



## WARRANTY:

This radio has a 12-month warranty against any manufacturing defect, and the warranty period begins from the date ordering.

#### SPECIFICATION:

Frequency Range	AM: 520-1710KHZ
	FM: 87-108MHZ
	WB: 162.400-162.550MHZ
Dimension	16*8*6cm
Weight	340g
Water-resistant	IPX-3
Power Source	Li-ion
Working Voltage	5V
Earphone Jack	3.5mm
Flashlight Power	3 W
Reading Lamp Power	0.8 W

# Q&A:

Q: Why the radio doesn't hold the battery?

A: The battery will run out when the radio idled for a long time. Please wind the hand crank for few minutes to activate the built-in battery, then charge it by USB cable. Periodically charge the built-in battery to extend battery life.

Q: Is this radio water-proof?

A:The radio is water-resistant (IPX3), it can be used reliably in adverse weather conditions,aboard water craft, etc.

Q: Why solar panel doesn't charge the built-in battery?

A: There are many factors affect solar charging, such as angel, sunlight and so on. The charging indicator will light up. It is difficult to fully charge this radio by solar panel, because it is mostly designed for maintain the battery.

# CORRECT DISPOSAL OF THIS PRODUC

I

(Waste Electrical & Electronic Equipment ) This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible narm to the environment or numan neath from uncontropled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contact. This product should not be mixed with other commercial wastes for disposal.

#### FCC STATEMENT

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.