## **BT Calling Setup**

(Compatible with both iPhones and Android phones)

Once the watch is connected to the App, tap 'Pair' in the App to enable BT calling.





# **OTA Update**

Open the App and go to My > My Device > Firmware Update to download the latest firmware version.





## **Technical Specifications**

Frequency	2402-2480MHz BeiDou, GPS, GLONASS, GALILEO ,QZSS, NavIC
Power (EIRP)	BT: 5.94dBm BLE: 7.85 dBm

## **Warranty Policy**

KOSPET provides a two-year warranty for products purchased from our official online store (http://www.kospet.com). For more details, please visit:

https://kospet.com/pages/warranty-policy

If you have any further questions, feel free to:

Email: support@kospet.com

Call: +1 (507) 668-8466 (Service hours: Monday to Friday, 9:00 AM - 6:00 PM EST)
For purchases made on Amazon, please contact: smartwatch.amz@amail.com.

### **Safety Precautions**

- Do not expose the watch to high temperatures or place it near heat sources, such as heaters, ovens, microwaves, or water heaters, as excessive heat may cause battery explosion and other safety hazards.
- · This product uses a non-removable polymer battery. Disassembly by unauthorized personnel is strictly prohibited to prevent potential risks.
- While the watch passed waterproof testing before leaving the factory, wear and tear during daily use may affect its sealing performance. Please use the watch carefully while swimming or diving, and avoid wearing it in saunas or during hot showers.
- This product is not a professional medical device and cannot be used for medical purposes, or as basis for diagnosis of any medical condition. All detection results are provided for reference purposes only.

## FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **Important Notice:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part I5 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- $\cdot$  Consult the dealer or an experienced radio/TV technician for help.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

### Manufacturer:

Shenzhen Amazwear Technology CO., LTD.

#### Address:

34/F, Changjiang Center, Intersection of Renmin Road and Jianshe Road Jingxin Community, Longhua Subdistrict, Longhua District, Shenzhen, Guangdong, China.

#### Made in China

This user manual is published by KOSPET. The company reserves the right of final interpretation and may make adjustments to this manual anytime if necessary. Feature descriptions on the foregoing pages are provided for reference only.




User Manual

The E-label information
To access the e-label information, in the device
1.Go to the main interface as follows



2. Enter the setting interface, as follows



3. Select About, as shown in the following interface

