

**TREK**




# 2022 TOP FUEL

SERVICE MANUAL SUPPLEMENT  
Rev 1 October 2023


# Contents




[Safety](#)



[Active Braking  
Pivot \(ABP\)](#)




[Shock mounts](#)




[Routing with AXS  
shift](#)




[Down tube storage](#)




[Headset with Knock  
Block](#)




[Rocker pivot](#)



[Adjust the  
geometry](#)




[Frame guards —  
carbon frame](#)




[Specifications](#)




[Derailleur hanger](#)




[Main pivot](#)



[Routing with  
mechanical shift](#)



[Frame guards —  
aluminum frame](#)



[Suspension](#)

## Safety



### WARNING

#### Properly tighten hardware

Always tighten hardware to the specified torque. Over-tightening hardware could deform or break the hardware or components. Under-tightening hardware could cause hardware or components to become loose. Either situation could damage the bicycle and result in injury to the rider.



### WARNING

#### Reapply threadlocker

All reused-fasteners with pre-applied threadlocker must be cleaned with isopropyl alcohol and have new threadlocker applied before re-assembly. If threadlocker is not applied, the fasteners may loosen which could damage the bicycle and result in injury to the rider.

## Legend



Apply grease



Do not apply grease



Apply threadlocker

Nm


Torque



Zip tie

# Headset with Knock Block

**Notice:** To operate the bicycle without a Knock Block chip, a non-block chip must be installed.




- |                             |           |
|-----------------------------|-----------|
| ① Upper bearing cover       | — 5252161 |
| ② Chip bolt                 |           |
| ③ Knock Block chip          |           |
| ④ Compression ring          | — 5252160 |
| ⑤ Upper bearing             |           |
| ⑥ Lower bearing             |           |
| ⑦ Crown race                |           |
| ⑧ Non block chip — W1048249 |           |

## Tools

- 2.5mm hex tool
- Torque wrench with 2.5mm hex bit
- Grease

# Deraillieur hanger



- |   |                    |           |
|---|--------------------|-----------|
| ① | Deraillieur hanger | — W583423 |
| ② | Washer, 30mm       |           |
| ③ | Bolt               |           |

## Tools

- 8mm hex tool
- Torque wrench (left-hand thread) with 8mm hex bit



## WARNING

Do not apply grease to the derailleur hanger or bolt.

This bicycle frame is designed to use a Universal Derailleur Hanger (UDH).

**NOTICE:** The thru axle must be compatible with a UDH and must be M12x1.0 with a 12.7mm thread.


**NOTICE:** The washer is frame-specific. Install only the washer size specified.

**NOTICE:** Do not over-tighten. Over-tightening the bolt could cause the hanger to break.


For additional information about the UDH, refer to the SRAM user manual at [www.sram.com](http://www.sram.com).

# Active Braking Pivot (ABP)

## Carbon frame



## Aluminum frame



- ① Thru axle – W583469
- ② Non-driveside dropout – W5251141
- ③ Retaining ring – W5251279
- ④ Bearing – W5256340
- ⑤ Dropout – W5269707
- ⑥ Spacer – W583422  
(for use with carbon frame only)

– W5272776

### Tools


- Bearing press
- Cassette lockring tool
- Grease

**NOTICE:** The thru axle must be compatible with a UDH and must be M12x1.0 with a 12.7mm thread.

### Apply grease to:

- Threads of the thru axle (1)
- Shoulders of non-driveside dropout (2) and the dropout (5)

# Rocker pivot



- ① Bolt – W600629
- ② Hat-style washer (2mm hat height) – W5257190
- ③ Bearing – W5257592
- ④ Rocker axle – W600627
- ⑤ Spacer – W290057
- ⑥ Bearing – W5256341
- ⑦ Seat tube pivot sleeve – W310155
- ⑧ Nut – W311582

## Tools

- Bearing press
- 5mm and 6mm hex wrenches
- Torque wrench with 5mm and 6mm hex bits


## Apply grease to the :

- Seat tube bearing bore
- Rocker pivot seat stay bearing bores
- Rocker pivot non-driveside seat tube pivot
- Do not apply grease to rocker pivot drive side seat tube pivot.

## Seat tube pivot

**Important:** Press in driveside bearing first.

# Main pivot



- ① Nut — W584134
- ② Spacer — W440921
- ③ Bearing — W5256338
- ④ Main pivot sleeve — W500592
- ⑤ Main pivot axle — W601376

## Tools


- Bearing press
- 8mm hex tool
- Torque wrench with 8mm hex bit
- Grease

## Apply grease to:

- The bearing bores as shown above.

**Important:** Press in the driveside bearing first.

# Shock mounts



- ① Bolt – W5257188
  - ② Bearing – W5257592
  - ③ Hat-style washer (4mm hat height) – W5257189
  - ④ Lower shock Mino nut
  - ⑤ Lower shock Mino spacer
  - ⑥ Socket head cap screw – W5251046
- ] – 5280295

## Tools

- Bearing press
- 5mm and 6mm hex wrenches
- Torque wrench with 5mm and 6mm bits


## Apply grease to:

- The bores as shown above.

## Adjust the geometry

Flip the lower shock mount Mino nut and spacer to change the bike's geometry to fit your riding style or the terrain.


### Steeper head tube angle



Mino nut and spacer in the high position

- Pulls in the front fork for quicker steering
- Raises the bottom bracket for improved climbing

### Slacker head tube angle



Mino nut and spacer in the low position


- Pushes the head tube angle back 0.5° and pushes out the front fork for slower steering that is more stable at high speed
- Lowers the bottom bracket up to 9mm for more stability

## Tools

- 6mm hex tool
- Torque wrench with 6mm hex bit

1. Remove the lower shock bolt. For the location, see the [Shock mounts on page 7](#).
2. Flip the lower shock Mino nut and spacer to the desired position.
3. Re-install the lower shock bolt and torque to 10Nm.

# Routing with mechanical shift



- ① Dropper cable
- ② Rear brake cable
- ③ Derailleur cable
- ④ Rubber housing guide
- ⑤ Exit guide
- ⑥ Bolt — W532763

★ Zip tie

— 5275988

## Route cables

### Notes

- All models feature cable routing tunnels.
- Route cables first, then install seat tube cable exit guide components (4, 5 and 6).

### Route cables:


- Rear brake: back to front
- Derailleur: back to front
- Dropper: head tube to seatpost

## Aluminum frame derailleur and brake routing

To improve access to the cable entry holes located behind the chainstay bridge:

1. Remove the upper shock mount bolt.
2. Rotate the rear triangle up.

## Routing with AXS shift



- ① Dropper cable
- ② Rear brake cable
- ③ Plug — W600649
- ④ Rubber housing guide
- ⑤ Exit guide
- ⑥ Bolt — W532763
- ★ Zip tie

— 5275988

### Route cables

#### Notes

- All models feature cable routing tunnels.
- Route cables first, then install seat tube cable exit guide components (4, 5 and 6).

#### Route cables:


- Rear brake: back to front
- Dropper: head tube to seatpost

### Aluminum frame brake routing

To improve access to the cable entry holes located behind the chainstay bridge:

1. Remove the upper shock mount bolt.
2. Rotate the rear triangle up.

## Frame guards — carbon frame




- ① Chainstay guard — W5257206
- ② Button head screw — 1042535
- ③ Button head screw — 327526
- ④ Downtube guard — 5280104
- ⑤ Shuttle guard — W5257546
- ⑥ Frame protection decal — W326986

### Shuttle guard

Use isopropyl alcohol to clean the frame surface where the guard (4) attaches. Wait for the alcohol to dry before applying the guard.

**Notice:** Do not clean the entire frame with isopropyl alcohol. Isopropyl alcohol could damage the paint.

## Frame guards — aluminum frame



- ① Chainstay guard — W5259518
- ② Button head screw for chainstay guard — 1042535
- ③ Downtube guard — W5258504
- ④ Frame protection decal — W326986
- ★ Zip tie


### Downtube guard

Use isopropyl alcohol to clean the frame surface where the guard (3) attaches. Wait for the alcohol to dry before applying the guard.

**Notice:** Do not clean the entire frame with isopropyl alcohol. Isopropyl alcohol could damage the paint.


# Down tube storage

## Carbon frame



- ① Storage door
  - ② Button head screws – 547053  
(includes nuts, not used on carbon frames)
- W583862


## Aluminum frame



- ① Storage door
  - ② Button head screw
  - ③ Nut
- 1042535
- W583862

# Specifications

## Chainline (1x only)



## Chainring (1x only)

| Minimum | Maximum   |
|---------|-----------|
| 28T     | 36T round |
|         | 34T oval  |

## Rear brake mount



| Minimum             | Maximum            |
|---------------------|--------------------|
| 160mm, direct mount | Adaptable to 180mm |

## Maximum tire size

**Notice:** Measurements of actual tires may vary. Always verify there is sufficient clearance between the tire and the frame. Improper tire size could damage the bicycle frame. Trek recommends 6mm clearance above and on the sides of the tire.


| Wheel set                         | Maximum tire size |
|-----------------------------------|-------------------|
| 29"                               | 29" x 2.5"        |
| 27.5"<br>(Extra small frame only) | 27" x 2.5"        |

## Seat post



### WARNING


Always follow the seatpost manufacturer's minimum insertion recommendation. Failure to follow the recommendation could cause damage to the seatpost and result in injury to the rider.



| Item | Measurement                         | Frame  | Carbon | Aluminum |
|------|-------------------------------------|--------|--------|----------|
| 1    | Maximum insertion                   | XS     | 205mm  | —        |
|      |                                     | S      | 245mm  |          |
|      |                                     | M      | 270mm  |          |
|      |                                     | M/L    | 285mm  |          |
|      |                                     | L      | 300mm  |          |
|      |                                     | XL     | 320mm  | 350mm    |
|      |                                     | XXL    | —      | 390mm    |
| 2    | Minimum insertion                   | 75mm*  |        |          |
| 3    | Seat tube inside diameter           | 34.9mm |        |          |
|      | Seat tube post clamp outer diameter | 39.5mm |        |          |

\*Follow the seatpost manufacturer's guidelines.

## Bottom bracket /ISCG tabs



| Bottom bracket | ISCG tabs |
|----------------|-----------|
| BSA73          | ISCG 05   |

# Suspension

The first step in suspension setup is to determine the sag. All other settings should be adjusted after determining the sag.

Refer to the suspension setup card included with your bike or the suspension calculator at

[Trekbikes.com/suspension-calculator](https://trekbikes.com/suspension-calculator).


For recommended rebound settings refer to the suspension calculator at [Trekbikes.com/suspension-calculator](https://trekbikes.com/suspension-calculator).

## Fork



### WARNING


Exceeding the recommended maximum fork length could damage the bicycle and result in injury to the rider.



| Frame/<br>Wheel Size               | Axle to Race (mm) |     | Travel<br>(mm) | Sag<br>(15%)<br>(mm) |
|------------------------------------|-------------------|-----|----------------|----------------------|
| XS<br>27.5" wheels                 | Recommended       | 512 | 120            | 18                   |
|                                    | Maximum           | 522 | 130            | 19.5                 |
| S, M, ML, L, XL, XXL<br>29" wheels | Recommended       | 531 | 120            | 18                   |
|                                    | Maximum           | 541 | 130            | 19.5                 |

## Shock

| Mount       | Width                |
|-------------|----------------------|
| Upper mount | 54mm x 10mm Trunnion |
| Lower mount | 30mm x 8mm           |



| Description     | Dimension  |
|-----------------|------------|
| Eye-to-eye      | 185mm      |
| Stroke          | 50mm       |
| Recommended sag | 28% (14mm) |