

Guide to Using Your Minismus Milk Frother

Thank you for choosing our MINISMUS Milk Frother for creating delightful frothy beverages!
Follow these steps for the best frothing experience.

Battery Installation

Insert Batteries: Place 2X AAA batteries as shown in the diagram below and tighten the cap securely.



How to Use

Step 1

Pour the desired amount of milk into a container, ensuring not to fill more than one-third of the vessel. Adjust the milk temperature based on your preference for hot or warm frothed beverages.



Step 2

Carefully position the frother above the milk, allowing only the frother's head to be submerged. Avoid going too deep; just the tip of the frother should be in the milk.



Step 3

Start the frother, and within seconds, observe the formation of froth. Experienced users may tilt the container slightly, ensuring the frother's position remains undisturbed.



Step 4

When the desired froth consistency is achieved, switch off the frother. Use different milk types and experiment with alternative frothing recipes for diverse frothy delights. Enjoy!



How to Clean

1. Place the end of the frother whisk under a gentle stream of water to rinse.
2. Then wash with a mild cleaning solution and rinse again.
3. Do not immerse frother body in water nor place it in the dishwasher.



Milk to Use

	Cold	Warm	Hot (>60°)
Works Well	2%, Skimmed Oat, Soy Milk	Almond, Oat, Coconut, Soy	2%, Skim, Whole Milk; Half-and-Half, Oat, Soy Milk
Doesn't Work Well	Whole Milk, Half-and-Half	2%, Skim Whole Milk, Half-and-Half	Almond, Rice, Cashew, Walnut Milk

For Tips & Tricks Visit



minismus.eu/milkfrother-instructions

MINISMUS