



Model: LT604

ASSET TRACKER 4G

Included in box

- 1 x GPS battery powered tracker
- 1 x Charger lead
- 1 x basic set up guide
- 1 x GPS Device sticker

This product requires a mobile SIM card (not included).

Data only SIM cards are not compatible.

Responsible use of GPS products

GPS tracking devices need to be used responsibly, with disclosure and consent of drivers and not breach any privacy rights. Mongoose GPS trackers are not for covert use. You must disclose to any driver/user that you are using a GPS tracking system.

All customers need to ensure that they install and use GPS tracking devices in accordance with all applicable laws, regulations, standards and industry code of conduct.

Always check and update your APP to latest version

V.T. 12.24

1

STEPS FOR BASIC INSTALL AND SET UP

1. Charge LT604
2. INSERT active SIM CARD into LT604
3. Turn on Switch for LT604
4. Download Mongoose 4G GPS APP
5. Log on to APP using 10 Digit ID number and default password
6. Enter Tracker Phone number in TRACKER info
7. Placement of LT604 on Asset.

STEP 1 BATTERY & CHARGER

DO NOT LEAVE CHARGING UNATTENDED.

Only use the charger lead supplied.

Charging time varies according to the battery state.

First charge Allow log charge time of upto 12 hours.

NOTE: Do not use the USB lead connected to other equipment such as a computer to charge - charging may not occur or be considerably extended.

STEP 2 and 3 SIM CARD INSTALL and ON/OFF SWITCH



Lift the rubber cover Insert the SIM card & turn on Close the cover

TEST SIMCARD voice, text, data function in phone for
activation before use in GPS TRACKER

The LEDs flash when searching for signal and light solid once it has mobile and GPS signals. After a short while, the LED's will turn off to preserve battery life. The tracker must be outdoors or very close to a window to receive GPS signals. Observe the LED's.

BLUE & GREEN LEDs

Unlit ---Reception is off (No power or unit asleep)

Lit solid---Working normal

Flashing once every 3 sec's ---Searching for signal (Green – Mobile) (Blue – GPS)

Red LED ---Charger connected and internal battery charging

STEP 4 DOWNLOAD THE MOBILE APP

Go to App Store for Apple IOS

Go to Play Store for Android

Search for :- **4G MONGOOSE GPS**



NEW UPDATE AVAILABLE

WEB ACCESS TO TRACKER

www.mongoosegps4g.com

Note: For this tracker to function accurately, ensure your mobile phone GPS location services are switched on.

STEP 5 LOG ONTO TO APP OR WEBSITE

1. Enter the trackers 10 DIGIT ID (serial number) and default 222444 password then PRESS LOGON

2.You can check now to see if your TRACKER is reporting correctly to the APP.

If your tracker is not reporting its Location or you also want to access more features of the APP follows the steps below.

3

Press MENU at bottom and select TRACKER INFO

STEP 6 ENTER tracker phone number in TRACKER INFO

Once in **Tracker INFO** you can set up details for your unit.

Press the Write ICON at top right of the screen and select **Device phone number** section.

ENTER the phone number of the SIM card put inside the Tracker.

CHECK Your DEVICE phone number is correct

You can also personalise the tracker info details here.

Once complete press Save icon at the top right of the screen

You can press the Back button at top of screen to go back to Main menu



In Menu choose TEXT COMMANDS

Choose MASTER USER NUMBER.

You can then enter your personal MOBILE number that will be the main user of the tracker.

The app will go to SMS sending function of phone, Send the SMS and tracker should reply.

In this section you can set up and communicate via SMS With your tracker.

You can change your SMS password here for extra security of your tracker. KEEP A RECORD OF THIS NUMBER

Once completed go back to Main menu

In Menu choose SET APN

If you traker is not online yet, You can enter the SIM PROVIDERS APN to make sure the tracker is send data via the right TELCO.

Below are some of APN that you can enter, the APP will go to SMS, please ensure you send SMS and TRACKER will reply

4

In Menu choose SET APN

If you have started your car and it did not show trackers ONLINE location on the APP, You can enter the SIM PROVIDERS APN to make sure the tracker is sending data via the right TELCO APN.
Below are some of APNs that you can enter, the APP will go to SMS, please ensure you send SMS and TRACKER will reply

Australia APN		New Zealand APN	
Telstra	telstra.internet or telstra.wap	Vodafone	vodafone.net.nz
Vodafone	live.vodafone.com	Spark	internet
Optus	connect or yesinternet or connectme	2 Degrees	
Aldi	mdata.net.au	Kogan	live.vodafone.com
Boost	telstra.mms	The Warehouse	warehouse
Moose	yesinternet	Skinny	wapaccess.co.nz
AmaySim	internet	Slingshot	

You can move the LT604 to wake it up and get update of so it sends location then allow a few minutes and check location which should now be correct

You can now go back to MAIN MENU

Select Change Password

You can enter your current password for LOG IN then choose enter your own 6 digit password

NOTE: It is important that you change the Default passwords to your own chosen password. Also to protect your location data, only reveal your logon details to trusted persons.

5

CONTROL COMMANDS AVAILABLE VIA THE MOBILE APP

Command	Function
Arm / Disarm	Turns text alerts on or off. When ON, text alerts can be sent for, shock(vibration) sensor or GPS position change.
Get Location Data	Provides latitude/longitude as a text message – click on blue text to open your phones Google maps to show location
Tracking Frequency	Sets how often the tracker updates its location when moving.
Time Zone	Set hours ahead of GMT your tracker is located. Adjust for daylight saving when applicable.
Vibration Sensitivity	Set vibration (shock) level 1~9. 1 is most sensitive. See full manual for explanation and on/off command
Speed Alert	Sets a max'permitted speed. Speeding sends a text alert
Move Alert	Sets a radius of permitted movement. Beyond this limit sends a text alert
Master User Number	The main users mobile phone number
Authorised Number	2 other permitted users
Text Command Password	Choose your own 6-digit number (default 123456). This does not change your logon password. If you change TEXT COMMAND password please ensure you keep record of new password.
Geo-Fence	A permitted radius of travel. alerts are sent to APP and website when exiting or entering a geo-fenced area
Factory Reset	Resets settings to factory default

6

Commands are sent from the APP to the tracker as a password protected text messages from your mobile phone. The APP opens your phones text messages showing the text code being sent to the tracker..... Just press send. A reply text will be received confirming the action.

7



For Full MANUAL and other details go to below websites

Australia

www.mongoose.com.au

New Zealand

www.mongoose.co.nz

GPS tracking website: **www.mongoosegps4g.com**

Mobile APP:- **4G MONGOOSE GPS**

8