# 使用說明

# 

技術支援 vortexkeyboard.ts@gmail.com

顧客服務 vortexkeyboard.cs@gmail.com

> 官方網站 www.vortexgear.store



# 連接方式

藍牙/USB/2.4Ghz

Fn

+



配對藍牙裝置 (長按3秒)

藍牙裝置 1 LED下指示燈閃紅燈

藍牙裝置 2 LFD下指示燈閃綠燈

藍牙裝置3

## 切換連接方式

2.4 Ghz LFD下指示燈閃黃燈

藍牙裝置 1 LFD下指示燈閉紅燈

藍牙裝置 2 LED下指示燈閃綠燈

藍牙裝置3 LED下指示燈閃藍燈

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any

device must accept any interference received, including interference that may cause undesired operation. Or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This reasonable protection against harmful interference in a residential installation. This reasonable protection against harmful interference in a residential installation. This reasonable protection against harmful interference in a residential installation. This remains and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no instructions may cause harmful interference to radio communications. However, there is no interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

USB

LED下指示燈閃藍燈

## 電池規格: AA電池 / 電壓: 1.5V \*2

(建議使用鹼性電池) 工作電流:9mA——鬆開按鍵5秒將進入待機模式 待機電流:3.5mA——待機5秒將進入休眠模式

休眠電流:3mA——待機30分鐘將進睡眠電流:0.7mA (藍牙將中斷連線) 一待機30分鐘將進入睡眠模式

額定輸入:5V-500mA

# Macro說明 (支援藍芽模式Macro)

F12

1. Fn + R Shift選擇編輯層(共三層) LED上指示燈分別顯示(第一層紅燈/第二層綠燈/第三層藍燈)。

- 2. Fn + Ins (絕對位置) 進入編輯, 黃燈恆亮。
- 3. 選擇要編輯的鍵,該層指示燈閃爍。
- 4. 輸入內容,該層指示燈閃爍(每個按鍵編輯長度32鍵)。 5. Fn + Enter (絕對位置)確認,該層指示燈再次恆亮。
- 6. Fn + Ins (絕對位置)離開編輯,黃燈熄滅。

### **IFD**

指示燈(上/下) (於Caps Lock鍵右側)

## 上指示燈

切換layer

(第一層紅燈/第二層綠燈/第三層藍燈)

# F10 Shift 🛈

ScrLk Pause

PgUp

## 下指示燈

Caps Lcok 紅燈 Scrol Lock 終燈 macOS 紅燈

> 產品名稱:機械鍵盤 產品型號: VTK-8000

產品尺寸:

I\*W\*H: 38.5\*16.5\*3.5 cm + 0.3

### Fn 切換

同時按住Capslock、L\_Ctrl、R\_Win進入Fn設定模式 (LED上指示燈閃白燈)。這時第一個按的鍵爲Fn鍵。

(Ins / Enter / Shift 不能使用為Fn, 並且Fn層無法 進行Macro)

# Fn組合鍵

(Windows OS)



(F1) = (螢幕亮度 - )

F2) = (螢幕亮度+)

(F4) = (搜尋)

(F5) = (語音輸入)

(F6) = (休眠)

F7) = (上一首)

F8) = (播放/暫停)

F9) = (下一首) (F10) = (静音)

(F11) = (音量-)

(F12) = (音量+)

A = 切換爲 macOS

(Print) = (螢幕截圖) (ScrLk) = 表情選單

(Pause) = (切換語言)

(Windows) = (Windows lock)

(R\_Alt + R) = (回復當層鍵値(絕對位置)

當前層的LED上指示燈亮

(R\_Alt + L\_Alt) = (按住5秒 重置爲出廠預設値)

(LED上指示燈閃白燈)

# (macOS)

F1 = (螢幕亮度 - ) = (螢幕亮度+)

F3 = Mission Control

F4 = (Spotlight)

F8 = (播放/暫停)

F10 = (静音)

F11 = (音量-)

M = 切換爲 Windows OS

(Print) = (螢幕截圖) 全螢幕截圖

當前層的LED上指示燈亮

R\_Alt+R = 回復當層鍵値(絕對位置)

(R\_Alt + L\_Alt) = (按住5秒 重置爲出廠預設値)

(LED上指示燈閃白燈)

Fn

= (聽寫/Siri)

= (勿擾模式)

= (倒轉)

F9 = (快轉)

F12 = (音量+)

(ScrLk) = (ScrLk) 表情選單 (Pause) = (Pause) 切換語言

公司名稱:沃特斯有限公司

公司地址:台北市內湖區舊宗路二段181巷14號4樓

> NCC警語

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使 用。前述合法通信,指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

# Inde

Fn

# Guide



TECHNICAL SUPPORT

CUSTOMER SERVICE vortexkeyboard.cs@gmail.com

OFFICIAL WEBSITE



Battery : AA / 1.5V \*2 (Alkaline battery) - Release the key for 5 Working Current : 9mA Standby Current: 3.5mA — Release the key for 3 seconds will enter into standby mode Standby Current: 3.5mA — Standby for 5 seconds will enter into hibernation mode

Hibernation Current: 3mA — Hibernate for 30 minutes will enter into sleep mode Sleep Current: 0.7mA (Bluetooth will be disconnected) Rated Input Power: 5V = 500mA

Indicator light (Top / Bottom) (to the right of the Caps Lock key)

Top Indicator light

Switch layer (First layer red light / Second layer green light / Third layer blue light)

**Bottom Indicator light** 

Caps Lcok (red light) Scrol Lock (green light) macOS (blue light)

Product Name: Mechanical Keyboard

Model Name: VTK-8000

Product Size:

L\*W\*H: 38.5\*16.5\*3.5 cm ± 0.3

# Connection

Bluetooth / USB / 2.4Ghz

Pairing Mode (Press for 3 seconds)

Device 1 LED flashes red light

Device 2 LED flashes green light

Device 3 LED flashes blue light

# Switch connection mode

2.4 Ghz LED flashes yellow light

Device 1 LED flashes red light

Device 2 LED flashes green light

Device 3 LED flashes blue light

**USB** 

Turn on the power switch, then press and hold Fn + 2 / 3 / 4 for three seconds to enter pairing mode. The device will display 'Model M#1/2/3' and once confirmed, the pairing is complete. During this process, the LED indicator lights (Bluetooth device 1: red light / Bluetooth device 3: blue light) will flash sequentially.

### Macro instructions (support Bluetooth mode macro)

- 1. Fn + R\_Shift selects the editing layer (three layers in total). The LED indicator lights on top will respectively show (first layer: red light / second layer: green light / third layer: blue light).
- 4. Input the content, and the indicator light for that layer will flash (each key edit can hold up to 32 keys).
- 5. Fn + Enter (Absolute position) confirms the input, and the indicator light for that layer will remain steady again.

- Fn + Ins (Absolute position) enters editing mode with a steady yellow light.
   Choose the key to edit, and the indicator light for that layer will start flashing.
- 6. Fn + Ins (Absolute position) exits editing mode, and the yellow light turns off.



# Fn switch

Press and hold Fn while simultaneously holding Caps Lock, L\_Ctrl, and R Win to enter the Fn setting mode (LED indicator lights on top will flash white). The first key pressed in this mode is the Fn key. (Ins / Enter / Shift cannot be used as Fn, and Fn layer cannot be used for macro)

# **Fn Key Combos**

Windows OS

F1) = (Screen Brightness -)

= (Screen Brightness +)

(F4) = (Search)

(F5) = (Voice input)

(F6) = (Sleep)

(F7) = (Previous)

(F8) = (Play/Pause)

(F9) = (Next)

(F10) = (Mute)

(F11) = (Vol -

(F12) = (Vol +)

A = Switch to macOS

(Print) = (Screenshot)

(ScrLk) = (Emoji menu)

Pause = Switch language

(Windows) = (Windows lock)

 $(R_Alt + R)$ 

Restore current layer key values (absolute position)

The LED indicator light on the current layer is lit

(R\_Alt + L\_Alt) =

Hold for 5 seconds to reset to factory default settings

The LED indicator light on top flashing white light

(macOS) This function can be used without the need to press Fn

F1 = (Screen Brightness -)

= (Spotlight)

Rewind

**10** = (Mute)

= (Screen Brightness +) = (Mission Control)

= (Dictation/Siri)

= Do Not Disturb

Play/Pause

= (Fast-forward)

F11 = (Vol -

= (Vol + M = (Switch to Windows OS)

(Print) = (Screenshot)

(ScrLk) = (ScrLk) Emoji menu

Pause = Pause Switch language

 $(R_Alt + R) =$ 

The LED indicator light on the

(absolute position)

Restore current layer key values

current layer is lit

 $(R_Alt + L_Alt) =$ 

Hold for 5 seconds to reset to factory default settings

The LED indicator light on top flashing white light

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. operation.
Any changes or Any Change

Company Name: Vortexgear Co., Ltd. Company Address: 4F., No. 14, Ln. 181, Sec. 2, Jiuzong Rd., Neihu Dist., Taipei City, 114709, Taiwan