# 封面封底底色色值C:5 M:0 Y:0 K:50








获取最新品牌动态

使用教程、新品上新

官方微博 关注参与抽奖



# 目录指南



6.耳机触控区操作

11. 商家信息

1.包装清单 2. 充电仓功能介绍 3. 耳机功能介绍

5.佩戴步骤

7.产品参数 8.故障排除

9.注意事项 10.保修服务

# 包装清单



主机



# 充电仓功能介绍




充电仓	指示灯
充电仓充电	充电仓红灯闪烁
充电仓充满电	充电仓满电红灯长亮
充电仓给耳机充电	充电仓绿灯长亮

## 耳机功能介绍



中仓指示灯				
在电仓红灯闪烁 红蓝灯交替闪表示并始组配 红蓝灯交替闪表示并始组配 左右耳配对成功 配对成功后,主机红蓝灯同时闪烁(主副耳随机) 有电仓满电红灯长亮 耳机手机连接成功 主副机指示灯熄灭 耳机充电 耳机红灯长亮	+ 0 + - W	中1761日 小 八		
充电仓红灯闪烁     左右耳配对成功     配对成功后,主机红蓝灯同时闪烁(主副耳随机)       充电仓满电红灯长亮     耳机手执连接成功     主副机指示灯熄灭       耳机充电     耳机红灯长亮	电包指示灯	耳机开机	红蓝灯交替闪表示开始组配	
充电仓满电红灯长亮     耳机手机连接成功     主副机指示灯熄灭       充电仓绿灯长亮     耳机充电     耳机红灯长亮	充电仓红灯闪烁			
充电仓绿灯长亮 耳机充电 耳机红灯长亮	充电仓满电红灯长亮			
耳机充满电 耳机灯全熄灭	充电仓绿灯长亮			
		耳机充满电	耳机灯全熄灭	



	耳机指示灯	
l	红蓝灯交替闪表示开始组配	
已对成功	配对成功后,主机红蓝灯同时闪烁(主副耳随机)	
1连接成功	主副机指示灯熄灭	
3	耳机红灯长亮	
		1

## 连接指南



开机: 开盖取出耳机自动开机, 自动配对 耳机开机后自动进入配对状态(与手机待连状态),主耳灯闪 关机: 耳机放入充电仓内自动关机

配对: 1.耳机进入蓝牙模式,手机搜索蓝牙配对名"i3",点击连接即可。 2.耳机默认回连上一次设备。

Shut off:

By the right:

Bluetooth disconnection:

the Bluetooth pairing mode.


Bluetooth can return normally.

pairing name "i3", click the connection.

2. The headset is back to the last device by default.

1.手动关闭手机蓝牙端,耳机进入蓝牙配对模式。 2.耳机与设备超距后蓝牙断开,4分钟内回到有效距离范围,蓝牙能正常回连。 3.蓝牙断开5分钟后会自动关机。

# 佩戴步骤







3 佩戴完成

## 耳机触控区操作



	音乐模式				音乐模式	;
(M)	播放/暂停	双击		(FII)	播放/暂停	双击
<b>&gt;&gt;</b>	下一曲	三击		44	上一曲	三击
	通话模式	;			通话模式	;
0	接听/挂断	双击		0	接听/挂断	双击
6	拒绝来电	长按2秒		6	拒绝来电	长按2秒
普通模式					普通模式	;
•	语音助手	长按2秒		•	语音助手	长按2秒

## 产品参数



USB输出接口 : Type-C接口 电池容量 300mAh/3.7V 充电时长 ≤2h 充电电流 : 250mA

充电仓基本参数

输入电压 : DC5V

## 耳机基本参数 蓝牙名称 : i3

有效距离 : ≥10m(无障碍) 蓝牙版本 : Bluetooth 5.3 充电电流 : 30mA 充电时间 : ≤2h 电池容量: : 35mAh/3.7V

1.查看耳机指示灯状态是否已连接其他设备,或被其他设备连接, 2.清除手机蓝牙其它设备,关闭蓝牙后重新搜索。

漏音・査看是否佩戴正确 适当调节音量输出。 本产品的耳机部分具有防水功能,可用于非水上运动和锻炼。 (不同手机型号和不同音乐软件有不同的蓝牙发射功率,因而音量输出大小也会有 但本产品并不具有完全防水功能, 请不要将且机浸泡在水中, 本产品的充电盒部分不具备防水功能,请不要将充电盒暴露在任何液体。 长时间存放后 请在使用前再次充电。

## 耳机充电问题: 查看耳机充电位置与仓充电位置是否有异物。

Failure exclusion

Unable to connect the problem

Headphone charging problem:

the warehouse have foreign bodies.

1. View whether the status of the headset indicator has been connected to

2. Clear other Bluetooth devices, turn off the Bluetooth and then search

Check whether the charging position of the headset and the charging pos

other devices, or is connected by other devices,

故障排除

无法连接问题

声音问题

长时间未使用导致亏电需要较长时间才能充满属于正常现象

## 仓充电问题: 查看充电指示是否正常 查看充电线是否插到位

# 注意事项

请让产品远离热源、可燃气体或其他清洁性/腐蚀性液体,避免长时间的阳光暴晒,

过高音量下听音乐可能会损伤您的听力,声音也可能会失真。

电池组承受极低气压,可能导致爆炸或泄漏可燃液体或气体。

将电池组放置在极高温度环境中,可能导致爆炸或泄漏可燃液体或气体。

耳机放入充电盒前请确保耳机处于干燥状态,且充电前请保持充电口干燥

请仅使用经过相关部门批准目符合本地监管要求的电源适配器

(如UL、CSA、VDE、CCC),不建议使用电压较高的电源为耳机充电。

使用第三方充电线为充电盒充电可能需要更长时间。

用错误型号的电池组替换,可能会使安全防护失效。

若出现严重鼓胀,请勿继续使用!

存储与维护

听力损伤

电池使用

充电安全须知

反应。为减少皮肤刺激风险,请不要将产品穿戴在皮肤有伤的身体部位。 本产品应当存放在阴凉干燥处。工作温度在0-38℃。 如果您的皮肤出现发红 肿胀 发痒或任何其他刺激反应 请您立即停止佩戴 并向医生咨询!

### 电磁干扰提示 如果本产品的任何部件受损、冒烟、发烫,或释放出烧焦的味道,请立即停止使用本产品。

有明文规定禁止或不宜使用无线设备的场所(例如,可能是您所在地区的机场 医疗场所等),请勿使用本产品,否则会干扰其它电子设备或导致其它危险。 部分电子设备可能因本产品的无线电干扰而出现故障(如,部分汽车电子设备)。 请联系该电子设备制造商咨询详细信息。

有少数人会对特定材质产生特殊反应,当暴露于特定环境下,或与肥皂、汗液、防紫外线 产品或乳液等对皮肤有潜在刺激性物质及其他物质长期接触时,可能会引起皮肤过敏

## 保修服务

尊敬的金运用户: 非常感谢您选择我们的产品,请您认真填写并妥善保管您的保修卡 将电池组投入火中或加热炉中,或对电池组进行机械挤压或切割的处理可能导致爆炸 本公司保留对该产品售后服务条例的解释权。

佩戴使用须知

## 1 保修政策

1. 如在线上购买签收之日起7天无理由退货,15天免费包换(如:天猫,京东等)。 非质量问题的退换货邮费需要由消费者承担,再次发货的邮费由商家承担。 如有发票和赠品,请您一并寄回。

### 2. 如在线下门店购买,您可到当地售后服务中心享受本公司提供的自购买之日起, 15天包换服务,如当地无售后服务中心,可委托经销商进行包换服务。

3. 您所购买的产品,经本公司检测确定后,可以按照下列售后服务承诺时间表享受

Warranty service

## 商家信息



## Fa 非保修条例

- 未经授权的维修、误用、碰撞、疏忽、滥用、事故、改动,或撕毁、涂改标站、防伪标记;
- . 产品没有序列号,质保凭证上的产品型号、编号与产品实物不相符的; 产品超出本公司规定的质保期限:
- 5. 非正常使用产品导致外表破损:
- 6 外旬装及内附的赠品 销售人品承诺的产品之外的服务及附加的配置和测品 7. 不当存储:如产品长时间暴露在非正常湿度、温度环境中造成的性能损害: 8. 未按操作说明,人为滥用谋用,覆自改装造成产品损坏的,因不可抗力造成的损坏

## ∰ 保修记录表

生产企业 : 东莞市全鼎辰智能科技有限公司 生产地址 : 东莞市塘厦镇东兴大道南221号 执行标准 : GB 4943.1-2022 服务热线 : 400 0755 962

## 中国制造 Made in China ( 🕻 FC 必 🗵 😷

检验员

2024/10

产品电池为内置可充电电池,请勿自行拆开更换,应使用正确的方法对设备进行充电, 不要将设备靠近火源或受到阳光折射,电池发热会毁坏安全装置导致电池爆炸或燃烧。

# KINYO金运®

# Scan code for brand information



Official public account Use tutorials, new products on new



□ % 1 % 6 %

Official Weibo Focus on participating in the sweepstakes

# 1. Packing list

2. Charging bin function introduction

5. Wear steps

Directory guide

7. Product parameters

8. Failure exclusion


10. Warranty service

11. Merchant information

Packing list

Charging case

Charging cable





6. Headset touch area operation guide


9. Note

IS UKUSHS UKUSH MANAH

Earphone

Instruction manual

# Charging bin function introduction




Charging bay indicator light			
Bin charging	The charging bay's red light is blinking		
The charging bay is fully charged	The charging bay is full, the red light keeps on		
Charging case cover (discharge to charge headphones)	The charging bay has a green light		



## Headset function description



Charging bay indicator light				
ging	The charging bay's red light is blinking			
ging bay is fully charged	The charging bay is full, the red light keeps on			
g case cover (discharge e headphones)	The charging bay has a green light			



	Headphone indicator
Earphone on	The red and blue lights blinking alternatelyindicate the start ofpairir
The left and right ears are paired	After the pairing is successful, the red light of the main engine flashes at the (the primary and secondaryears are ro
The headphone connection is successful	The main and secondaryindicators (
Earphone charging	The headset's red light keeps on
Headphones fully charged	All headphone lights are off

## Connection Guide

Headset automatically shuts off when placed in the charging compartment

1. The headset enters the Bluetooth mode. The mobile phone search Bluetooth

1. Manually turn off the Bluetooth end of the phone, and the headset enters

2. After the headset and the device are over -distance. Bluetooth is

disconnected. Back to the effective distance range within 4 minutes,

3. Bluetooth will automatically shutdown after 5 minutes of disconnection.









effect The clearest position.






Wear steps





Music mode

# The operation of the headset touch zone



sion	Double click		Play/suspension	Double click		
	Three blows		Last song Three blows			
Call mode			Call mode			
g up	Double click		Answer/hang up Double click			
II	Press 2s		Refuse to call Press 2s			
eneral mode		General mo	de			
ant	Press 2s		Voice assistant Press 2s			

## Product parameters




click	Play/suspension	Double click		
ows	Last song	Three blows		
	Call mode			
click	Answer/hang up	Double click		
2s	Refuse to call	Press 2s		(
	General mo	de		(
2s	Voice assistant	Press 2s		



Battery capacity : 35mAh/3.7V

## Basic parameters of charging bin



tive distance	:	≥10m(无障碍)	ı
ooth version	:	Bluetooth 5.3	
ging current	:	30mA	
ging time	:	≤2h	



ctive distance	:	≥10m(无障碍)	
tooth version	:	Bluetooth 5.3	
rging current	:	30mA	
raina time		≤2h	

# Bluetooth name : i3

# Input voltage : DC5V

# Farphone basic parameters

e distance	:	≥10m(无障碍)	Charging warehouse charging problem:
h version	:	Bluetooth 5.3	Check whether the charging indicator is normal
g current	:	30mA	Check whether the charging cable is inserted in place Check whether the charging head is 5V security rules

## Charging warehouse charging problem: Check whether the charging indicator is normal

phenomenon.

# Note

### Storage and maintenance This product should be stored in a cool and dry place. The working temperature is 0-38 ℃. Please use a soft dry cloth to clean the headset with daily cleaning

### Please allow the product to stay away from the thermal source, combus gas or other clean/corrosive liquids to avoid long -term sunlight Avoid use or placement in any high temperature places. If any component of this product is damaged, smoked, hot, or releases the

The headset of this product has a waterproof function and can be used non -water sports and exercise. But this product does not have a complete waterproof function. Do not soak the headset in water. The charging box of this product does not have a waterproof function

## Please do not expose the charging box to any liquid. After long -term storage, please charge again before use.

burnt taste, please stop using this product immediately.

Listening to music at high sound may damage your hearing, and the sound may be distorted.

# Battery use

Replacement with a battery pack of error models may fail the safety protection. The treatment of the battery pack into a fire or heating furnace, or a mechanical squeezing or cutting of the battery pack may cause explosion. Placing the battery pack in a very high temperature environment may cause explosion or leakage of flammable liquid or gas. The battery pack is extremely low pressure, which may cause explosion or

leakage of flammable liquid or gas.If severe bulging, do not continue to use it!

## Instructions for charging security Before the headset is put in the charging box, make sure that the headset is dr

and keep the charging port dry before charging. Please use the power adapter approved by relevant departments and meet the requirements of local regulatory requirements (Such as UL, CSA, VDE, CCC), it is not recommended to use a higher voltage power supply to charge the headset. It may take longer to charge the charging box with a third -party charging cable.

A few people will have a special reaction to specific materials, when exposed to specific environments, or with soap, sweat, and ultraviolet rays When products or lotion, such as potential irritating substances on the skin and long -term ontact with other substances, may cause skin allergies reaction. To reduce th risk of skin stimulation, do not wear the product on the body where the skin is injur If your skin appears red, swollen, itchy or any other stimulus reactions, please stop wearing immediately, And consult the doctor!

## Electromagnetic interference tips

There are places where wireless equipment is prohibited or should not be used (for example, maybe the airport in your area, Medical places, etc.), do not use this product, otherwise it will interfere with other electronic equipment or cause other dangers. Some electronic equipment may fail due to the radio interferen f this product (such as, some automotive electronic equipment). lease contact the electronic equipment manufacturer for details

## Merchant information

# Dear users, thank you very much for using our products. In order to effectively

Dear users, thank you very much no rusing our products. In orace to effectively protect your rights and interests, it is clear that the distribution agents and the company should undertake the maintenance, replacement and return of products (hereinafter referred to as "three guarantees") responsibilities and obligations, please read the matters:

1. The Product Warranty Card is the necessary proof for our company to provide free after-sales service within the warranty period.

2. According to the principle of "three guarantees", if there is a product quality problem, contact the distributor with the "Product warranty card", and the distributor will provide service to the customer, and our company will provide service to the customer, and our company will provide

vice support to the distributor; he company promises that if any quality problem occurs within 7 days from he date of sale (subject to the date of valid bill, the same below), the customer an return the product now for replacement or repair; From the date of sale rom 8 days to 15 days of quality problems, customers can choose to replace and repair; From the date of sale. Within one year quality problems, customers an free maintenance; The product will enjoy lifelong maintenance if quality troblems occur after the warranty period (all after-sales service points only harge for components and materials); Please fill in the "Product Warranty Card"

# with the dealer carefully. 4. The following circumstances do not enjoy the three-guarantee service: Damage caused by disassembly by the repairman who is not responsible for

C € F© ② 🗵 👶 Made in China







Production address : No. 221, No. 221, Donaxing Avenue, Tanaxia Town, Donaguan City

Execution standard : GB 4943.1-2022 Service Hotline : 400 0755 962



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Recrient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.