

## Table of Contents

### Safety Instructions

#### Overview

What's in the Box

Product Overview

Specifications

#### Getting Started

Charging and Powering in the Monitor

Placement of the Baby Monitor

Wall mount installation

#### Work with Smartphone

#### Customer Service

Warranty policy

Contact Us

FCC-SAR/Exposure

## Safety Instructions

01

### WARNING :

03

- STRANGULATION HAZARD-Children have STRANGLED in cords . Keep this cord out of the reach of children (more than 3 ft (1m) away).

03

- NEVER PLACE THE CAMERA OR CORD IN OR NEAR CRIB OR PLAYPEN. Secure the cord at least 3 ft away from crib or playpen.

05

- CHOKING HAZARD-This product contains small parts which may cause choking.

06

- SHOCK WARNING-To prevent electric shock, NEVER use the transmitter or receiver near water, including near a bathtub, sink, laundry tub, wet basement, etc.

07

- CAUTION-Only insert a battery pack of the same type. Risk of explosion if battery is replaced with an incorrect type.

08

- Use only the DC adapters provided.

12

- Adult assembly is required. Keep small parts away from children whenyou are assembling.

14

- This product is not a toy. Do not allow children to play with it.

14

- This product is NOT intended to replace proper adult supervision of children.

- You MUST check your child's activity regularly, as this product will not alert parents to silent activities of a child.
- Before using this product, read and follow all instructions and warnings contained in this booklet.

- Do not allow water damage to the camera unit, monitor unit, power adapter, or charging cable which cause overheat of the charging components.



- Do not use unofficial third party charging cables to charge the device. This may result in overheat of the charging port. Only use the charging cables provided in the box.
- Do not use unofficial third party power adapters, especially high wattage adapters. This may result in overheat of the cable and/or charging port. Only use the adapter provided in the box.

### FCC Statements

- These devices, including Baby Camera and Baby Monitor, comply with Part 15 of the FCC rules. Operation is subject to the following two conditions:

These devices may not cause harmful interference. These devices must accept any interference received, including interference that may cause undesired operation. Class B Digital Device. These equipments have been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. These equipments generate, use, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If these equipments do not cause harmful interference to radio or television reception, which can be determined by turning the equipments off and on, the user is encouraged to try to correct the interface by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an experienced radio / TV technician for help.
- Warn user. The Federal Communications Commission warns the users that changes or modifications of the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipments.

## Overview

### What's in the Box



1 x Baby Camera





1 x Power Adapter



1 x User Manual

**NOTE:** Power adapter varies by region.

### Product Overview



- ① CMOS Sensor
- ② Power LED
- ③ Microphone
- ④ Speaker
- ⑤ SD Card
- ⑥ DC-Jack
- ⑦ Pair Button
- ⑧ WiFi OFF Switch
- ⑨ Temperature Sensor

### Specifications

#### System General


Model Number:	U2se
RF Frequency:	2400 ~ 2483.5MHz
Operating Temperature Range:	0°C - 50°C
Origin:	Made in China
Wireless Communication:	WiFi

#### Camera Unit

Input Voltage:	5V
Operating Power:	<300mA
IR/Night Vision:	YES
Operating Temperature:	0 C - 50 C
Power Adapter:	5V,1A
Charging Cable:	78.74 in
Exposure Control:	Auto
White Balance Control:	Auto
Vertical Turning Angle:	Manual 360
Horizontal Turning Angle:	Tittle down 90
Other Special Feature:	Built in Microphone/speaker
Camera Dimensions (L x W x H):	2.48X 2.48 X 4.47 in

## Getting Started

### Charging and Powering in the Baby Monitor



#### Turn on the Camera Unit

Only use the DC adapter included in this package.


Use the provided DC adapter to connect the wall outlet with the camera unit.Once the adapter is connected, the unit will turn on automatically and the power LED will light up.

**NOTE:** Only use the enclosed camera Power Adapter.


#### Placement of the Baby Monitor

This camera can be placed on a tabletop or hung on the wall. Place the baby monitor in a place where the air can circulate freely. Do not place on soft quilts or blankets or in the corners of cupboards, shelves, etc.

- Place the baby monitor away from heat sources such as radiators , chimneys, cookers and direct sunlight.
- Place the camera unit away from TV sets, microwave oven and radios. The intense radio signals generated by these elements could cause noise or even deteriorate sounds and images which appear on the monitor. If this occurs, move the camera to another location.




Place the camera within 15 feet of the area being monitored for best picture result.




Baby monitors and cameras with power cords should never be hung on or near the crib as it can cause strangulation hazard. Power cords should be kept no less than 3 ft away from the crib and the baby's reach at all times.

07


## Wall mount installation



Position the crib against the preferred wall in the nursery.




Using the Measuring Tape, find the center of the crib and mark the wall with a pencil.




Lift the tape up 60 inches and mark at the "Mark Here" indicator.


08



Push the Large Plastic pipes into each hole and screw them until they are flush.




Slide the base of the Simyke camera device into the Wall Mount until it clicks.




Plug the Power Supply into the back of the Simyke camera device.

09




One by one, Stick cable clamps onto the wall between 30 cm



Plug the Power Cord into the nearest outlet.

10




11

## Work with Smartphone


### 1.Download & Register

Download the App and follow the onscreen instructions to complete your initial registration



### 2.Pair Device


Tap 'Pair Device' to pair your phone with Simyke baby monitor



12

### 3. Ready to begin

Now start your journey with Simyke camera!



13

## Customer Service

### Warranty policy

We guarantee 12 months warranty and professional after-sale service within 24 hours.

### Contact Us

If you have any questions, please feel free to contact us via our official email address:  
info@simyke.net

### FCC-SAR/Exposure

The Baby Monitor in the box is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.098W/kg. The Baby Camera in the box complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

14