




1 Component List













Step 1



Attach Side Frame (3) to the side of the Frames (1&2) with Screws (B)*4. Repeat the same installation steps to get Two installed Frames.


Note: Fully expand the frame before installing the screws. Otherwise the screw cannot be twisted in.

The screws are tightened by 50% first.



Align the head and tail of the Middle Frame (4) with the two installed Frames, and secure them completely with Screws (A)*4.


Note: The screws are tightened by 50% first.



Align the screw holes on the legs of the two Frames, and secure them completely with Screws (C)*2 and Nut (E)*2.


Note: The screws are tightened by 50% first.

Step 4



Insert Center Slat (6) into the Center Slat (5). After fixing both, insert them onto the **groove** in the middle of the Side Frame (3)*2, and fix the Center Slats (5&6) to the Middle Frame (4) with Screw (D)*1. Finally, the Central Slat (5) and the Central Slat (6) are fixed with a Nut (E)*2.

Note: Once installation is complete, tighten all screws 100%. Tighten the screws again every 3 months.



Insert Slats (7)*24 evenly onto each groove of the Frames (3&4).

