


Elite™ Android Quick Start Guide for Wave PTX

For the most up-to-date app settings and configurations, check support.motorolasolutions.com.



1. Ensure your **Elite™** speaker-microphone (SM) is charged before use. Before plugging your SM into the Android device, set the configuration to **5** by pressing the rear button for 4 seconds. The SM will then beep twice in quick succession.



4. Google Assistant can interfere with Zello and wired accessories, so it should be disabled. In the **Settings** app, select **Google > All Services > Search, Assistant & Voice > Google Assistant > General**, and disable the **Google Assistant** toggle.


Innovation... Quality... Passion

Designed, Assembled, Tested and Supported with Pride in the USA, at Stone Mountain we strive to provide our customers with innovative products of the highest quality, reliability and value. We welcome and appreciate your input - Feel free to contact us.

Stone Mountain, Ltd.
1597 Eagle Point Road
Huddleston, VA 24104


2. The SM will beep and flash a red LED a number of times equal to the current configuration.

- **If the SM indicates configuration 5**, don't do anything. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.
- **If the SM indicates some configuration other than 5**, press the rear button **5** times. The SM will then beep and flash the LED **5** times as confirmation. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.



5. Navigate to the previous menu and select **Devices**. Select **Wired headphones** and disable **Get Help From Google**.

Note: This setting may only appear after the SM has been connected for the first time.



3. Launch the Wave App. Navigate to **Settings** Select **In-Call Tones** and enable **Floor Grant Tone**.

Recommended:

- **Enable Call From Lock Screen:** This allows the SM to be used while the paired device is locked or asleep.
- **Enable Background Mode:** This allows the SM to be used when the app is running in the background with other apps in the foreground.
- If PTT does not function, go to the app's setting and select **Advanced Settings > Accessory Compatibility**. The required compatibility mode is device dependent.