




RAYCHEM

RayClic Connection System

Installation Instructions



DESCRIPTION

nVent RAYCHEM RayClic-S Splice Kit

nVent RAYCHEM RayClic-T Tee and End Seal Kit

nVent RAYCHEM RayClic-X Cross and End Seal Kit

These kits are for use with nVent RAYCHEM IceStop, XL-Trace Edge and HWAT heating cables. The connection is designed to be strapped to the pipe, or wall mounted.

These installation instructions should be used in conjunction with the IceStop, XL-Trace Edge, and HWAT System Installation and Operation Manuals. For technical support, contact your nVent representative or call nVent (800) 545-6258.

TOOLS REQUIRED

- TORX T20 screw driver
- Utility knife
- Wire cutters

OPTIONAL ACCESSORIES

(NOT INCLUDED IN THIS KIT)

- nVent RAYCHEM RayClic-SB-02 Wall mounting bracket
- nVent RAYCHEM RayClic-SB-04 Pipe mounting bracket

APPROVALS



718K Pipe Heating Cable



877Z De-Icing and Snow Melting

Not UL Listed with XL-Trace Edge heating cable for buried piping



For HWAT and IceStop only
Hazardous Locations: For IceStop (GM-XT) only
Class I, Div. 2, Groups A, B, C, D

⚠ WARNING:

This component is an electrical device that must be installed correctly to ensure proper operation and to prevent shock or fire. Read these important warnings and carefully follow all the installation instructions.

- To minimize the danger of fire from sustained electrical arcing if the heating cable is damaged or improperly installed, and to comply with the requirements of

nVent, agency certifications, and national electrical codes, ground fault equipment protection must be used. Arcing may not be stopped by conventional circuit breakers.

- Bus wires will short if they contact each other. Keep bus wires separated.
- Keep components and heating cable ends dry before and during installation.
- The black heating cable core is conductive


and can short. It must be properly insulated and kept dry.

- Component approvals and performance are based on the use of nVent-specified parts only. Do not use substitute parts or vinyl electrical tape.
- Leave these instructions with end user for reference and future use.

KIT CONTENTS


RAYCLIC-S SPLICE KIT

Item	Qty	Description
A	1	Splice
B	2	Plastic cable ties
C	2	Clips
D	3	Labels (1 splice, 2 warning)
E	1	Cable lubricant




RAYCLIC-T TEE KIT

Item	Qty	Description
A	1	Tee
B	2	Plastic cable ties
C	3	Clips
D	1	End seal
E	3	Labels (1 splice, 2 warning)
F	1	Cable lubricant





RAYCLIC-X CROSS KIT





Item	Qty	Description
A	1	Cross
B	2	Plastic cable ties
C	4	Clips
D	2	End seals
E	3	Labels (1 splice, 2 warning)
F	1	Cable lubricant



If you experience difficulty during installation, refer to the "Troubleshooting Guide" on page 8.




Splice, Tee, and Cross Installation






HWAT Only

5A



IceStop and XL-Trace Edge Only

5B



8

Tighten the screws until the metal top surface is at the same height as the inner clear plastic module.

- Securely tighten the two connection screws, alternating as they are being tightened.

⚠ WARNING: Fire hazard. Loose screws can cause excessive heating. Be sure screws are fully tightened.

9

- Repeat steps 2 through 7 for all remaining heating cable entries.

10

- Close the lid and snap the lever shut. Do not force lid closed. If lid does not close, check the connection to ensure all screws are fully tightened.
- Tighten the nuts on the heating cable entries until grommets are compressed.

11A

SPLICE

- Using glass cloth tape, attach heating cable to pipe.
- Apply insulation, cladding, warning labels and yellow splice identification label.

11B

TEE (insulation not shown)

- Using glass cloth tape, attach heating cable to pipe.
- Apply insulation, cladding, warning labels and yellow splice identification label.


11C

CROSS (insulation not shown)

- Using glass cloth tape, attach heating cable to pipe.
- Apply insulation, cladding, warning labels and yellow splice identification label.

Roof Installation


1



RayClic-SB-02

- Mount flat (wall-mounting) bracket by installing screws through the center holes.
- Mount bracket above water line. **Do not mount in gutter or where it may be immersed in water.**

2




RayClic-S

RayClic-T and RayClic-X

- Position attachment clips on mounting bracket based on the type of connector being installed.


3



- Prepare and attach heating cables as detailed in steps 2 through 9 (pages 3–5).

4A

SPLICE




Drip loops

- Attach connector to mounting bracket by pressing until it snaps into place.
- Complete heating cable installation and install drip loops as shown.
- Protect heating cable from sharp edges.

4B

TEE




Drip loops

- Attach connector to mounting bracket by pressing until it snaps into place.
- Complete heating cable installation and install drip loops as shown.
- Protect heating cable from sharp edges.


End Seal Installation

1



- Score down and around outer jacket 1 inch from the end.
- Remove the outer jacket.
- Do not cut or damage inner jacket.

2




- Remove exposed braid.

HWAT

IceStop, XL-Trace Edge and RaySol


2A

- Using wire cutters, cut away aluminum wrap close to braid and outer jacket.



3

- Push end seal completely onto heating cable.



Note: The end seal can be installed only once; it cannot be removed from the heating cable. Do not use until ready for final installation.

PROBLEM	SOLUTION
Braid clips are missing.	The braid clips are attached to the cardboard packing insert under the lid. The braid clips must be used to ensure a ground connection. If clips are missing or lost, call nVent at (800) 545-6258.
Mounting bracket is missing.	A mounting bracket is not included in the splice, tee and cross kits. One can be ordered using one of the catalog numbers listed under "Optional Accessories" on the front page of these instructions when you place your order.
Connector does not snap onto bracket.	The bracket has two sets of attachment clips. Fold up the four outer clips for the splice kit. Fold up only the center clips for the tee and cross kits.
Heating cable type not mentioned.	nVent RAYCHEM RayClic connection kits are approved for use only with HWAT, XL-Trace Edge and IceStop heating cables. Do not use with other heating cables.
Braid clip does not fit.	Be sure the clip is installed on the metal braid, not on the outer jacket.
Heating cable does not have aluminum wrap.	Only HWAT heating cables have the aluminum wrap under the braid. Skip the aluminum wrap removal step for XL-Trace Edge and IceStop heating cables.
Heating cable cannot be inserted into connector.	Check for the following: <ul style="list-style-type: none">• Apply cable lubricant to the heating cable primary (white) jacket.• Outer jacket strip length is 3 1/8 inches.• Braid clip is installed on top of the metal braid, not on the outer jacket.• Braid is pulled back over braid clip.• For HWAT, 1 inch of braid is removed.• Sealing nut is loose (but not removed).• Connection screws are loose.
Lid does not close.	Be sure all screws are fully tightened before closing the lid.
Heating cable cannot be inserted into end seal.	The outer jacket must be removed from the heating cable before the end seal is installed (see the "End Seal Installation" instructions on page 7). Make sure 1 inch of the outer jacket, braid, and aluminum wrap (HWAT only) are removed.
Heating cable cannot be removed.	The connection and end seal are designed to be installed only once; the heating cable cannot be removed once installed. Additional nVent RAYCHEM RayClic-E end seals can be ordered from nVent.



Heating Cable Circuit Testing

The RayClic-T now includes test ports in the blank module. Voltage can be measured at these points to confirm continuity or power to the installed heating cable circuit. For detail heating cable operation refer to the appropriate installation and operating manual.

Instructions:

1. Open the RayClic cover.
2. Set multimeter to AC voltage function.
3. Insert multimeter test probes into the two test ports.

⚠ WARNING: To avoid shock do not cross the test probes or touch them to the metal pressure plate when measuring voltage.



North America

Tel +1.800.545.6258
Fax +1.800.527.5703
thermal.info@nVent.com

Europe, Middle East, Africa

Tel +32.16.213.511
Fax +32.16.213.604
thermal.info@nVent.com

Asia Pacific

Tel +86.21.2412.1688
Fax +86.21.5426.3167
cn.thermal.info@nVent.com

Latin America

Tel +1.713.868.4800
Fax +1.713.868.2333
thermal.info@nVent.com



nVent.com/RAYCHEM

©2021 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners.
nVent reserves the right to change specifications without notice.

RAYCHEM-IM-H55388-RayClicConnectionKits-EN-2111

PN 473303-000