

xiaomi Bluetooth Speaker User Manual



Xiaomi HyperOS
Connect


Model: ASM02G



Read this manual carefully before use, and retain it for future reference.

Product Overview

Note: Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.



Package Contents



Speaker



Lanyard



Charging Cable



User Manual

How to Use

Power button

- Press to turn the speaker on or off.
 - Double press to check the current battery level.
 - Press and hold for 10 seconds to force restart the speaker.
-

Volume +

- Press to increase the volume.
 - Press and hold to keep increasing the volume.
 - Press and hold the button "+" and the button "-" at the same time for 10 seconds to restore factory settings.
-

⦿ Multi-function button

- Press to play or pause music.
 - Double press to play the next track.
 - Press three times to play the previous track.
-

— Volume -

- Press to decrease the volume.
 - Press and hold to keep decreasing the volume.
-

⌘ Bluetooth button

- Press to enable or disable the Bluetooth pairing status.
 - Double press:
Before combination: Enable or disable the combination pairing status
After combination: Exit the combination mode
 - Press and hold for 2 seconds to disable the Bluetooth connection.
-

Note: "Combination" refers to stereo play or group play.



Ambient light strip description

- White: Turning on or off/voice notification/stereo play or group play/charging at a normal battery level
- Blue: Bluetooth pairing/restoring factory settings/system updating
- Orange: Low battery level/charging at a low battery level



Charging

- Before first use, open the port protective cover from the slot on top of it. Then use the charging cable and a qualified power adapter (sold separately) to fully charge the speaker.



Bluetooth connection

- Press  to enable the Bluetooth pairing status, and select the speaker on the audio source device to complete Bluetooth pairing. Then, the speaker can be used to play the audio content on the audio source device.
- When the Bluetooth is connected, press and hold  for 2 seconds to disable the Bluetooth connection.

Answering a call

- Press  to answer an incoming call, and double press the button to reject an incoming call. During a call, press  to end the call.


NFC function

- Enable the Bluetooth and NFC functions on the phone, and touch the icon  on the speaker with the NFC sensor area of the phone to automatically complete the Bluetooth connection between the phone and the speaker.
- When the phone and the speaker are connected, touch the icon on  the speaker with the NFC sensor area of the phone to relay the audio from the phone to the speaker for playing.

Notes:

- The NFC function mentioned above is only available for Xiaomi or Redmi phones with the NFC function. For more information about the models supporting the NFC function, visit the official website. This function is subject to actual use.
- Functions may vary among phones of different models and are subject to actual use.

Stereo/group play

- Double press  to enable the combination pairing status of each speaker.
- Two speakers of the same model can be automatically paired for a stereo play. They play music in the left and right channels separately for a more stereoscopic sound effect.
- Three to eight speakers of the same model can be automatically paired for group play. All the speakers play music synchronously to bring a richer music experience.

Notes:


- Two speakers of the same model can be paired for stereo play, and three or more speakers (up to eight speakers) of the same model can be automatically paired for group play.
- When multiple speakers are used in combination, it is recommended to keep the speakers within 1 meter of each other.
- The combination feature is mainly used for playing music. When playing videos, it will be affected by the device and network conditions, resulting in the audio and video being out of sync at varying degrees.

Turning off automatically

- If no operation is performed or no audio is played on the speaker for 15 minutes, it will be turned off automatically.

Note: This function can be disabled or customized in the app.

Restarting/restoring factory settings

- In case of errors or other special circumstances, press and hold  for 10 seconds to restart the speaker. Or press and hold the button "+" and the button "-" at the same time for 10 seconds to restore factory settings.

Notes:

- After the speaker is restored to factory settings, all connection and combination records and settings will be cleared.
- If the speaker has been connected to the app before, it has to be manually deleted from the app after being restored to factory settings to reconnect to the app. Besides, the speaker deleted from the app can be reconnected to the app only after the speaker is restored to factory settings.

Updating the system

- Update the system in time as prompted in the app. During the update, make sure that the speaker remains on and connected to the app.
- The speaker cannot be used during the update. Once updated, the speaker will restart automatically.

Connecting with the Mi Home/Xiaomi Home App

This product works with the Mi Home/Xiaomi Home app*. Control your device with Mi Home/Xiaomi Home app.

Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search for "Mi Home/Xiaomi Home" in the app store to download and install it. Open the Mi Home/Xiaomi Home app, tap "+" on the upper right, and then follow the instructions to add your device.



6AA9DA9B

Install the Mi Home/
Xiaomi Home app to
access smart features

* The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

Note:

The version of the app might have been updated, please follow the instructions based on the current app version.

Specifications

Name: Portable Bluetooth Speaker	Model: ASM02G
----------------------------------	---------------

Bluetooth: 5.3	Input: (Type-C) 5 V $\overline{=}$ 3 A / 9 V $\overline{=}$ 2.5 A
----------------	---

Battery Nominal Energy: 17.28 Wh

Operating Frequency and Radio Frequency Power

BT	2402 MHz–2480 MHz (≤ 20 dBm)
----	------------------------------------

BLE	2402 MHz–2480 MHz (≤ 20 dBm)
-----	------------------------------------

The serial number of the speaker can be checked on the packaging box or by scanning the QR code on the Type-C port protective cover of the speaker.

Important Safety Information

Read all safety information below before using your device:

- Use of unauthorized cables, power adapters, or batteries can cause fire, explosion, or pose other risks.
- Use only authorized accessories which are compatible with your device.
- This device's operating temperature range is 0°C to 40°C.
- If your device is provided with a built-in battery, to avoid damaging the battery or the device, do not attempt to replace the battery yourself.
- Charge this device only with the included or authorized cable and power adapter. Using other adapters may cause fire, electric shock, and damage the device and the adapter.

- After charging is complete, disconnect the adapter from both the device and the power outlet.
- The battery must be recycled or disposed of separately from household waste. Mishandling the battery may cause fire or explosion. Dispose of or recycle the device, its battery, and accessories according to your local regulations.
- Do not disassemble, hit, crush, or burn the battery. If the battery appears deformed or damaged, stop using it immediately.
 - Do not short circuit the battery, as this may cause overheating, burns, or other injury.
 - Do not place the battery in a high-temperature environment.
 - Overheating may cause explosion.
 - Do not disassemble, hit, or crush the battery, as this may cause the battery to leak, overheat, or explode.
 - Do not burn the battery, as this may cause fire or explosion.
 - Do not place the battery to extremely low air pressure that may can result in an explosion or the leakage of flammable liquid or gas.
- User shall not remove or alter the battery. Removal or repair of the battery shall only be done by an authorized repair center of the manufacturer.
- Keep your device dry.
- Do not try to repair the device yourself. If any part of the device does not work properly, contact the after-sales service team.
- Connect other devices according to their instruction manuals. Do not connect incompatible devices to this device.
- For AC/DC adapters, the socket-outlet shall be installed near the equipment and shall be easily accessible.
- Refer to the detailed product specifications on the label at the bottom of the device.

WARRANTY NOTICE

As a Xiaomi consumer, you benefit under certain conditions from additional warranties. Xiaomi offers specific consumer warranty benefits which are in addition to, and not instead of, any legal warranties provided by your national consumer law. The duration and conditions related to the legal warranties are provided by respective local laws. For more information about the consumer warranty benefits, please refer to Xiaomi's official website <https://www.mi.com/global/support/warranty>. Except as prohibited by laws or otherwise promised by Xiaomi, the after-sales services shall be limited to the country or region of the original purchase. Under the consumer warranty, to the fullest extent permitted by law, Xiaomi will, at its discretion, repair, replace or refund your product. Normal wear and tear, force majeure, abuse or damage caused by the user's negligence or fault are not warranted. The contact person for the after-sale service may be any person in Xiaomi's authorized service network, Xiaomi's authorized distributors or the final vendor who sold the products to you. If in doubt please contact the relevant person as Xiaomi may identify. The present warranties do not apply in Hong Kong and Taiwan. Products which were not duly imported and/or were not duly manufactured by Xiaomi and/or were not duly acquired from Xiaomi or a Xiaomi's official seller are not covered by the present warranties. As per applicable law you may benefit from warranties from the non-official retailer who sold the product. Therefore, Xiaomi invites you to contact the retailer from whom you purchased the product.

EU Declaration of Conformity:

EU Declaration of Conformity



Hereby, Beijing Xiaomi Electronics Co., Ltd. declares that the radio equipment type ASM02G is in compliance with Directive 2014/53/EU, Directive 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.mi.com/global/service/support/declaration.htm>

WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

The product is in compliance with UK PSTI regulations, the full text of declaration of conformity is available at the following internet address:
<https://www.mi.com/global/service/support/declaration.html>

FCC Regulations:

- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Caution!
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Manufacturer's authorized EU Representative

Name: Xiaomi Technology Netherlands B.V.

Address: Prinses Beatrixlaan 582, 2595BM, The Hague, The Netherlands

Manufacturer: Beijing Xiaomi Electronics Co., Ltd.

Address: Room 802, Floor 8, Building 5, No.15 KeChuang 10th Road,
Beijing Economic and Technological
Development Zone, Beijing City, China

For further information, please go to www.mi.com

User Manual Version: V1.0

