


# *ProBreeze*®

## Instruction Manual



### **PB-P07**

**Air Purifier with UV, Ionizer and 3-Layer Filtration System**

**IMPORTANT INSTRUCTIONS  
- RETAIN FOR FUTURE USE**

## CONTENTS

Safety Instructions .....	Page 2
Symbols Explained .....	Page 4
Specifications .....	Page 4
Parts .....	Page 5
Before You Use .....	Page 6
How It Works.....	Page 7
Display and Indicators .....	Page 8
PM2.5 .....	Page 8
Controls.....	Page 8
Replacing the Filter Instructions .....	Page 9
Cleaning and Storage .....	Page 10
Recycling and Disposal .....	Page 10

# ProBreeze®


**AIR PURIFIER**  
**MODEL PB-P07**


Thank you for choosing to purchase a product from Pro Breeze. Please read the entire manual carefully prior to first use and keep in a safe place for future reference.

## SAFETY INSTRUCTIONS

### PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

 **WARNING: TO AVOID THE RISK OF ELECTRICAL SHOCK, FIRE OR INJURY TO PEOPLE, ALWAYS MAKE SURE THE APPLIANCE IS UNPLUGGED FROM THE ELECTRICAL OUTLET BEFORE RELOCATING, SERVICING, OR CLEANING IT.**

 **WARNING: THIS APPLIANCE CONTAINS A UV-C EMITTER. DO NOT STARE AT THE LIGHT SOURCE.**

- Do not cover the appliance whilst in use.
- Use this appliance only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to person.
- Always unplug the appliance when not in use.
- Keep the appliance out of reach of children and pets.
- Do not leave children alone or unattended in the area where the appliance is in use.
- Children must be supervised not to play






- with the appliance.
- Cleaning and user maintenance shall not be made by children unless continuously supervised.
- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- The appliance must have a minimum 50cm clearance around all sides.
- Never leave the appliance unattended while in use. Always turn the appliance off and disconnected from the power supply when not in use.
- Avoid placing the power cord in areas where it can become a tripping hazard. Do not place the power cord under carpeting or cover it with rugs, runners or similar.
- Place the appliance on a flat, stable and dry surface and always keep the appliance in an upright position. Operating the appliance in any other position could cause a hazard.
- Never place anything on top of the appliance.
- Ensure that the mains supply (including voltage, frequency and power) complies with the rating label of the appliance.
- There may be trace of odour during the first few minutes of initial use. This is normal and will quickly disappear.
- Do not cover the appliance or restrict the air flow of the inlet or exhaust grills whilst in use.
- Do not cover, obstruct or push objects into the vents and opening of the appliance as this may cause an electric shock, fire or damage the appliance.

- Do not operate the appliance with wet hands.
- Do not use this appliance near water or in the immediate surroundings of a bath, shower or a swimming pool. Never place the appliance where it may fall into a bathtub or other water container.
- Do not allow water or other liquids to run into the interior of the appliance, as this could create a fire and/or electrical hazard.
- This appliance is intended for indoor household use and similar applications. Do not use outdoors.
- Do not use the appliance near petrol, paints, flammable gases, ovens, or other heating sources.
- The mains cable should not hang down from the surface on which the appliance is placed in order to prevent the appliance from being pulled down.
- To avoid a circuit overload when using this appliance, do not operate another high-wattage appliance on the same electrical circuit.
- Always plug the appliance directly into a wall socket. Avoid using extension leads where possible as they may overheat and cause a risk of fire.
- Do not use this appliance with an external programmer, timer switch or any other device which would switch the appliance on automatically unless this has already been pre-built into the appliance by the manufacturer.
- Do not pull on the power cord. Never move, carry, or hang the appliance by the power cord.
- Do not kink or wrap the power cord and plug around the appliance, as this may cause the insulation to weaken or split, particularly where it enters the appliance.
- Ensure the mains cable is fully extended before use and arrange it so that it is not in contact with any part of the appliance.
- Do not operate the appliance with any safety guards removed.
- Do not operate the appliance if there are

any signs of damage to the appliance or accessories supplied.

- Do not attempt to repair or adjust any electrical or mechanical elements in the appliance. Doing so may be unsafe and will void your warranty.
- The appliance is only to be used with the power adapter provided. Do not use other chargers or power adapters as this may damage the appliance.
- Do not operate the appliance without the air filter.
- Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may even in little doses, cause harm to the eyes and skin.
- Appliances that are obviously damaged must not be operated.
- Do not attempt to replace or repair the UV-C emitter in the appliance. The UV-C emitter must only be repaired or replaced by the manufacturer.

## SYMBOLS EXPLAINED

	Class II Double Insulated / Reinforced Insulation Equipment.
	Please read instruction manual and retain for future use.
	Equipment complies with the applicable UK safety requirements and regulations.
	Equipment complies with the applicable EU safety requirements and regulations.
	For indoor use only.


## SPECIFICATIONS

- Voltage: 220-240V~
- Frequency: 50-60Hz
- Power: 50W
- Size: 26 x 26.3 x 52.7cm
- Net Weight: 5.2Kg
- Gross Weight: 6Kg
- Clean Air Delivery Rate (CADR): 450m³/h

## PARTS


### Top

1. Air outlet
2. Control panel



### Front

3. Air intake
4. Display
5. Main body




### Back

6. Filter
7. Power Cord
8. Filter Cover
9. Ionizer
10. UV-C

9,10 are inside and well-hidden in the device.


To purchase additional filters, visit [www.probreeze.com/PB-P07](http://www.probreeze.com/PB-P07). If you have any questions or struggle to find the specific filter you need, please contact our customer care team for friendly and efficient help by emailing [help@probreeze.com](mailto:help@probreeze.com).



## BEFORE YOU USE

Prior to first use, please ensure you follow the steps below:

- A. Open the filter cover
- B. Remove the filter from air purifier and remove its PE bag
- C. Insert the filter back into the air purifier
- D. Re-attach the filter cover



## HOW IT WORKS

Your Pro Breeze Air Purifier removes up to 99.95% of dust, bacteria, and allergens from the air. A 5-way purification system includes 3-layers of filtration, built-in Ultraviolet (UV) LED sterilisation technology, and a negative ion generator to help you to create an invigoratingly clean living or working space.


- **3-Layer Filtration:**

1. **Fine Preliminary Layer:** for large airborne particles, and to help protect the lifespan of the HEPA filter.
2. **True HEPA 13 Filter Layer:** HEPA captures airborne particles as small as 0.3 microns such as dust, pollen, mould spores and airborne mites.
3. **Micro Granular Activated Carbon Layer:** Removes pet odours, smoke odours and harmful gases such as formaldehyde and benzene. With 98% Total Volatile Organic Compounds (TVOCs) and 99% Formaldehyde removable rate, the micro granular activated carbon is evenly distributed and will purify air 5-10 times more thoroughly than traditional large granular activated carbon filters.


- **Deep Ultraviolet (UV) LED Sterilisation Technology:** Our UV LED sterilisation technology adopts wavelengths of between 260 and 280nm of UV-C light. This technology can be used for killing 99.9% of odour causing bacteria, certain moulds and other allergens by destroying DNA & RNA. This is non-toxic, non-residual, and odourless, and can effectively kill most bacteria in 1-40 seconds. Our UV light is installed inside the air purifier to reduce exposure and does not need replacing unlike more traditional UV lights.






Deep UV LED vs. Traditional UV mercury lamp: UV LED is more than 1,000 times more effective than a traditional UV-C mercury lamp. Unlike the traditional mercury lamp, UV LED does not contain any toxic substances and is more environmentally friendly.

- **Negative Ion Generator:** Releases negative ions into the air to eliminate airborne bacteria and contaminants. The negative ions bind to and neutralise airborne pollutants for a cleaner environment. The ultra-powerful Pro Breeze negative ion generator generates more than 2 million negative ion outputs.



## DISPLAY AND INDICATORS



1.  Child Lock
2.  Ionizer
3.  UV LED
4.  Change Filter Indicator
5.  Air Quality Light Indicator
6. PM2.5 PM 2.5 Standard

### PM2.5

1. **PM 2.5 Standard** - PM 2.5 is a scale for measuring the number of particles smaller than 2.5 microns in the air (a human hair measure 50-70 microns in diameter). This is converted into an air quality index whereby the lower the number, the better the air quality.
2. **Air Quality Light Indicator** - The Air Quality Index will be displayed on the screen. The appliance will also light up based on the following scale:

- **Green** (Excellent Air Quality)  
-  $PM2.5 < 75 \mu g/m^3$
- **Yellow** (Medium Air Quality)  
-  $76 < PM2.5 < 150 \mu g/m^3$
- **Red** (Bad Air Quality)  
-  $PM2.5 > 151 \mu g/m^3$

## CONTROLS



- **ON/OFF Button:** Press ON/OFF button once to turn the device on or off.



- **UV Button:** UV mode will activate the invisible UVC light. For more information on how it works, please see the HOW IT WORKS section above or visit [Probreeze.com](http://Probreeze.com)



1. The device will automatically start with UV mode off.
2. Press the UV button to turn the mode on/off. The indicator light will illuminate on/off.



- **Timer Button:** Timer mode can be used to turn the device off automatically (after 1, 2, 4, or 8 hours).

1. When the device is on, press the timer button until the desired time appears on the screen.
2. The device will automatically turn off when the time is reached.



- **Speed Button:** There are four speed options: Sleep, Low, Mid and High. When Sleep Mode is selected, the device will continue to run, but all lights will turn off.



1. The device will start in low speed mode - I
2. Press the SPEED button to manually change the speed. The indicator light will illuminate on your selected speed.
3. To select Sleep Mode - ☾, press the SPEED button until Sleep Mode is illuminated. The device will continue to work in sleep mode. All lights will turn off apart from the sleep mode indicator light.
4. To turn off sleep mode, press the SPEED button again.



- **AUTO Button:** When under auto mode, the device will adjust the fan speed automatically, according to the air quality.
1. Press the AUTO button once to turn on auto mode.
  2. To turn off the auto mode, press the speed button.



- **ON/OFF + Speed Button = Child Lock Button**
1. Press and hold the ON/OFF and SPEED buttons simultaneously for 5 seconds to activate or deactivate the child lock mode.
  2. When in child lock mode, all other buttons will be disabled.



- **UV + Timer Button = Filter Reset Button**
1. After 2,000 hours of use, the filter indicator light flashes and the device will

- beep as a reminder to replace the filter.
2. If the filter needs replacing, press and hold the UV and TIMER buttons simultaneously for 5 seconds after you have replaced the filter to reset the device.

**Note:** For your safety, the device will automatically stop working and show "E1" on the display, if the filter cover is opened.



- **Timer + ON/OFF Button = Negative Ion Generator Button**
1. The device will start in with the negative ion generator on.
  2. Press and hold the TIMER and ON/OFF buttons simultaneously for 5 seconds to turn the Negative Ion Generator on/off. The indicator light will illuminate on/off.

## REPLACING THE FILTER INSTRUCTIONS

**⚠ WARNING: ALWAYS TURN THE APPLIANCE OFF AND UNPLUG THE POWER CORD FROM THE ELECTRICAL OUTLET BEFORE HANDLING AND REPLACING THE FILTER.**

We recommended cleaning the filter with a vacuum cleaner once a month and replacing the filter every 6 to 12 months, or after 2,000 hours of use. After 2,000 hours of use, the filter indicator light will flash and beep as a reminder to replace the filter. You may need to replace the filter earlier depending on the environment of the room.

**Note:** this filter is for Pro Breeze PB-P07 Air Purifier use only. For replacement filters visit [www.probreeze.com](http://www.probreeze.com)

## To replace the filter:

1. Shut down the appliance and turn the power off. (Figure 1)
2. Open the filter cover by lightly pulling the handle.
3. Remove the filter by pulling out the tab at the top of the filter. We recommend that you have a bag ready to prevent the pollutants on the filter falling back into the room (Figure 2).
4. Insert the new filter and re-attach the door cover.
5. Press and hold the "UV" and "timer" buttons simultaneously for 5 seconds after you have replaced the filter.

**Replacement Filter Model Number: PB-P07F**




Figure 1




Figure 2

## CLEANING AND STORAGE

**⚠ WARNING: ALWAYS TURN THE APPLIANCE OFF, UNPLUG THE POWER CORD FROM THE ELECTRICAL OUTLET BEFORE HANDLING OR CLEANING IT.**

**⚠ CAUTION: DO NOT ALLOW WATER OR OTHER LIQUIDS TO RUN INTO THE INTERIOR OF THE APPLIANCE, AS THIS COULD CREATE A FIRE AND/OR ELECTRICAL HAZARD.**

**⚠ CAUTION: DO NOT USE ANY ABRASIVE CLEANERS OR SOLVENTS, AS THIS CAN DAMAGE THE APPLIANCE.**

- Clean the exterior surface of the appliance by wiping it with a soft, damp cloth. Dry the appliance with a soft, clean cloth.
- Clean the vents and openings of the appliance regularly with a vacuum cleaner, using the brush attachment to avoid any dust build-up.
- To extend the lifespan of the filter, a vacuum cleaner, using the brush attachment can be used to remove dust from the surface of the filter.
- Store the appliance in a safe, clean and dry place, out of reach of children when not in use.
- Do not attempt to clean the appliance in any other way than that detailed by the manufacturer.
- To store your product, we recommend using the original or a similar-sized box.

## RECYCLING AND DISPOSAL

Waste electrical and electronic products (WEEE), batteries, accumulators and packaging should not be disposed of with general household waste. This is to prevent possible harm to the environment and human

well-being, and to help conserve our natural resources. Most electrical products with a plug, battery, or cable can be recycled. Contact your local council, household waste disposal service, or the store where you purchased the product for information regarding the collection schemes in your area.

### **Waste Electrical and Electronic Equipment (WEEE)**

This symbol on the product and/or packaging indicates that Waste Electrical products (WEEE) under Directive 2012/19/EU which governs used electrical and electronic appliances, should not be disposed of with general household waste.



### **The Mobius Loop**

This symbol indicates that the product or packaging is capable of being recycled.



### **Take-Back Scheme**

Waste electrical products (WEEE) can be sent to One Retail Group for recycling and disposal when you purchase a new product from One Retail Group, on a like-for-like basis. For more information on how to recycle this product please visit [www.probreeze.com](http://www.probreeze.com)

The end-user of electrical and electronic products (WEEE) is responsible for separating old batteries and lamp bulbs before they are handed over to a designated disposal and recycling service. Waste batteries can also be disposed of in collection bins, which can be found in most local supermarkets and household waste recycling centres.







[www.probreeze.com](http://www.probreeze.com)

One Retail Group, Ryland House  
24a Ryland Road, London, NW5 3EH, United Kingdom

EU Authorised Representative: Brandrep Limited, The Black Church  
St Mary's Pl N, Dublin, D07 P4AX, Ireland

© Copyright 2022