

# Am Tag

## User Manual





---

# Index

---

- 01      **Getting Started**
- 02      **Add Your Am Tag**
- 03      **Locate Your Am Tag**
- 04      **Notifications**
- 05      **When Your Am Tag Is Lost**
- 06      **Resetting Am Tag**
- 07      **Extras**
- 08      **The Fine Print**

---

# 01      Getting Started

---

## 01.1      **Power On / Off:**

Press the Am Tag Function Button once to turn it on. It should beep once to indicate that it is powered on.

To power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your Am Tag is powered off.

## 01.2      **Check For Updates:**

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

---

## 02      Add Your Am Tag

---

### 02.1      Start The App

Open Find My app on your supported iPhone.

### 02.2      Connect Your Am Tag

Press the function button once to power on your Am Tag.

Tap+, then "Add Other Item" .

Once your Am Tag is located, tap "connect"

Enter a name and choose an emoji for your Am Tag and tap "Continue".

Find My will ask for confirmation to add your Am Tag to your Apple ID Tap "Agree"

Tap "Finish" and your Am Tag will be set up and ready to be used.

---

## 03      **Locate Your Am Tag**

---

### **03.1      Find Am Tag When It's Nearby:**

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your Am Tag from the list.

Tap "Play Sound" to make your Am Tag beep.

Tap "Stop Sound" to stop the beeps once you find.

### **03.2      Find Am Tag's Location:**

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your Am Tag from the list.

Your Am Tag's location will appear on the Map with a time stamp of when the item was located.

To navigate to the Am Tag's location, tap "Directions" to open Apple Maps .

---

## 04 Notifications

---

### 04.1 Enabling "Notify When Left Behind":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your Am Tag from the list.

Under "Notifications" enable the "Notify When Left Behind" toggle.

You will receive a notification when you leave your Am Tag behind and it's no longer in range of your device.

### 04.2 Enabling "Notify When Found":

Under "Notifications", enable the "Notify When Found" toggle.

When your Am Tag is seen by another Find My network device, you will receive a notification of its location.

Note : "Notify When Found" can only be activated when your Am Tag is out of range.

---

## 05 When Your Am Tag Is Lost

---

### 05.1 Enabling "Lost Mode":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your Am Tag from the list.

Under "Lost Mode" tap "Enable"

A screen detailing Lost Mode will pop up, tap "Continue"

Enter your phone number or email address and tap "Next".

You may enter a message that will be shared with the person that finds your item.

Tap "Activate" to enable "Lost Mode"

Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.

Note: When "Lost Mode" is enabled, your Am Tag is locked and cannot be paired to a new device.



---

## 06      **Resetting Am Tag**

---

### **06.1      Remove The Am Tag From Find My App:**

Open Find My app and select the "Items" tab.

Tap on your Am Tag from the list.

please ensure "Lost Mode" is disabled.

Scroll to the bottom of the screen and tap "Remove Item".

A summary will open, tap "Remove" to confirm.

### **06.2      Factory Reset Your Am Tag:**

After successfully removing the Am Tag from Find My app, press the Am Tag's function button four times rapidly and then hold it a fifth time until you hear a ringing chime.

The Am Tag is now reset and ready to be paired to a new Apple ID.

---

## 07 Extras

---

### 07.1 Unwanted tracking:

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
2. If you don't have an ios device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.

---

## 08 The Fine Print

---

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user

---

## 08 The Fine Print

---

is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected .

---

## 09      About Apple Find My

---

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, or Mac. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

## ! WARNING

- INGESTION HAZARD: This product contains a button cell or coin battery
- DEATH or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH of CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."

b) The statement "Even used batteries may cause severe injury or death."

c) The statement "Call a local poison control center for treatment information."

d) A statement indicating the compatible battery type (e.g., LR44, CR2032).

e) A statement indicating the nominal battery voltage.

f) The statement "Non-rechargeable batteries are not to be recharged."

g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."

h) The statement "Ensure the batteries are installed correctly according to polarity (+ and -)."

i ) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."

j ) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."

k) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children."

# FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.





