





WiFi Thermometer Hygrometer User Instructions




INTRODUCTION




PAIRING SETTINGS

1. Power On




Slide to open the rear cover



Load 3x AA battery

2. Press and hold the button for 5 seconds, the device enters pairing mode with the signal icon flashing.



Press and hold the button for 5 seconds




Reminder:

Pairing takes roughly 120 seconds.

INSTALLATION

Simply place the device wherever you want.



Mobile APP

Search for 'Smart Life' app at iOS appstore or Google Android market. Register an account with the app before use. You can also scan the QR code below to download it.



Scan the QR code to download Smart Life App.
*App version subject to change without prior notice.

PAIRING

- Power on the device
- Make sure the signal icon is flashing. If not, press and hold the middle button until you hear two beeps (Di Di), then the device enters pairing mode.
- Make sure your smartphone is connected to WiFi network (preferably enable the Bluetooth).
- Open the mobile app and click ‘+’ on the upper right corner, pair the device following the instructions in the app.
- You ll hear a long beep (Di...) when pairing is finished.

TIME DISPLAY

- The device will sync the time automatically when it s connected to WiFi network.
- It displays the followings items sequentially, each time you press the middle button.
1.HOUR: MINUTE
2.MINUTE: SECOND
3.YEAR
4.MONTH DAY
5.DAYS OF THE WEEK
6.BACK TO 1

WARNING TEMPERATURE & HUMIDITY DISPLAY (APP control also supported)

- It displays the followings items sequentially, each time you press the left button.
1.Waring value of temperature (high)
2.Waring value of temperature (low)
3.Current temperature
4.BACK TO 1
- It displays the followings items sequentially, each time you press the right button.
1.Waring value of humidity (high)
2.Waring value of humidity (low)
3.Current humidity

SETTING OF WARNING TEMPERATURE VALUE (APP control also supported)

- Press left button, then press middle button to enter setting mode for warning temperature.
- Press left button to increase the warning value by 1 unit each time, or press and hold it so the warning value increases continuously.

- Press right button to decrease the warning value by 1 unit each time, or press and hold it so the warning value decreases continuously.
- Press middle button to save the settings.
- If you don’t press any buttons, the device will exit the setting mode in 5 seconds.

SETTING OF WARNING HUMIDITY VALUE (APP control also supported)

- Press right button, then press middle button to enter setting mode for warning humidity.
- Press left button to increase the warning value by 1 unit each time, or press and hold it so the warning value increases continuously.
- Press right button to decrease the warning value by 1 unit each time, or press and hold it so the warning value decreases continuously.
- Press middle button to save the settings.
- If you don’t press any buttons, the device will exit the setting mode in 5 seconds.

SPECIFICATIONS

Power source: 4.5VDC (3x 1.5VDC AA battery)
Working current: <100mA
Standby current: <30μA

WARRANTY CARD

WARRANTY POLICY

1. Consumers get return, replacement or repair service within 5 days of purchase, for manufacturing-caused performance malfunction.
2. Consumers get repair service within TWO months of purchase, for manufacturing-caused performance malfunction.

WARRANTY EXEMPTION

- 1.No warranty card or warranty period expires.
- 2.Damages caused by operation and maintenance not in accordance with the product instructions.
- 3.Damages caused by unauthorized dismantling and repairing. Damages caused by act of God.
- 4.Natural fading and wear of the product under normal usage.

FOR USERS

USER INFORMATION (following information to be used for the provision of after-sales service only).

Name _____

Phone _____

Email _____

Zip Code _____

Address _____

PRODUCT INFORMATION

Product Name _____ Product Model#_____

Color_____ Packaging#_____

Service Requested ☐return ☐replacement ☐repair

Problem Descriptions _____

Warranty Request Date:_____

Authorized Signature: _____

FOR MANUFACTURER

USER INFORMATION (following information to be used for the provision of after-sales service only).

Name _____

Phone _____

Email _____

Zip Code _____

Address _____

PRODUCT INFORMATION

Product Name _____ Product Model#_____

Color_____ Packaging#_____

Service Requested ☐return ☐replacement ☐repair

Problem Descriptions _____

Warranty Request Date:_____

Authorized Signature: _____