



## Z-Wave Protocol Implementation Conformance Statement

### WallMote Quad

#### General Information

<b>Product Identifier:</b>	ZW130-F
<b>Brand Name:</b>	Aeotec
<b>Product Version:</b>	HW: 130 FW: 2.03
<b>Z-Wave Certification #:</b>	ZC10-19036398

#### Product Features

<b>Firmware Updatable</b>	Updatable by Consumer by RF
<b>Supported Notification Types</b>	Power Management
<b>Z-Wave Scene Type</b>	Central Scene

#### Z-Wave Product Information

Supports Z-Wave Beaming Technology?	No
Supports Z-Wave Network Security?	Yes
Supports Z-Wave AES-128 Security S0?	Yes
Supports Security S2?	No
SmartStart Compatible?	No

#### Z-Wave Technical Information

<b>Z-Wave Frequency:</b>	India
<b>Z-Wave Product ID:</b>	0x0082
<b>Z-Wave Product Type:</b>	0x0902
<b>Z-Wave Hardware Platform:</b>	ZM5101
<b>Z-Wave Development Kit Version:</b>	6.61.01
<b>Z-Wave Library Type:</b>	Enhanced 232 Slave
<b>Z-Wave Device Type / Role Type:</b>	Wall Controller / Portable Slave

#### Association Group Information

Group # / Max	Description
Nodes	

# Z-Wave Protocol Implementation Conformance Statement

## (Continued)

### WallMote Quad

2 / 5	When touching the Button 1, the Basic Set command will be sent to the associated nodes in Association group 2.
3 / 5	When touching the Button 1, the Multilevel Switch Set command will be sent to the associated nodes in Association group 3.
4 / 5	When touching the Button 2, the Basic Set command will be sent to the associated nodes in Association group 4.
5 / 5	When touching the Button 2, the Multilevel Switch Set command will be sent to the associated nodes in Association group 5.
6 / 5	When touching the Button 3, the Basic Set command will be sent to the associated nodes in Association group 6.
7 / 5	When touching the Button 3, the Multilevel Switch Set command will be sent to the associated nodes in Association group 7.
8 / 5	When touching the Button 4, the Basic Set command will be sent to the associated nodes in Association group 8.
9 / 5	When touching the Button 4, the Multilevel Switch Set command will be sent to the associated nodes in Association group 9.

#### Supported Command Classes (16):

Association Group Info	Association V2
Battery	Central Scene V3
Configuration	Device Reset Locally
Firmware Update Meta-Data V2	Manufacturer Specific V2
Multi-Channel Association V3	Multi-Channel V4
Notification V4	Powerlevel
Security S0	Version V2
Wake Up V2	Z-Wave Plus Info V2

#### Controlled Command Classes (3):

Basic	Switch Binary V2
Switch Multilevel V4	