


Sunco

Lighting made better.

User Manual

Lux Solar Garden Light

SKU: GD_MD_SR-BK-2740K




support@sunco.com
(844) 334-9938




What's in the Box?

Solar Sidewalk Light



Let there be light!
(literally)



A

x1


Light



B

x2

Light Pole



C

x1

Ground Stake

Before You Start

Safety Information

To reduce the risk of fire or physical injury:

- Suitable for outdoor environments ranging from -4°F to 104°F.
- Do not cover the fixture with thermally insulating material.
- Not intended for use with emergency fixtures.
- Not compatible with occupancy sensors.
- Not compatible with dimmers or timing devices.
- Not compatible with third party sensors.
- All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards.
- Please review installation manual carefully before proceeding. Consult a qualified electrician if you are unfamiliar with proper installation.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference that may cause undesired operation. Please review all instructions carefully prior to installation.

WARNING:


Cancer & Reproductive Harm-
www.P65Warnings.ca.gov

Quickstart Guide



Step 1

Connect light poles and ground stake.




Step 2

Connect the light pole to the light. Press Power button to toggle CCT and brightness.



Step 3

Allow light to charge in sunlight before operation.




Step 4

Battery can be removed by unscrewing the cap from the light.


Installation Guide

STEP 1



- Remove accessories from packaging.
- Connect the light poles (B) and the ground stake (C).


STEP 2



- Connect the light pole (B) to the light (A).
- Press the Power button to turn the light on. Continue pressing the Power button to toggle between color temperatures and its selectable brightness.


Installation Guide (Cont.)

STEP 3




- Once fully assembled, place the light into desired location.
- This location should have clear access to sunlight and kept away from other sources of light that could interfere with the sensor.

STEP 4



Note: To replace the rechargeable battery, unscrew the cap from the light and replace the battery.

Product Details



Specifications

Voltage	3.7V	Lifetime	25,000 Hours
Wattage	2W	Lumens	120 lm
Battery	500mAh 3.7V	CRI	70+
CCT	2700K , 3000K , 4000K	Usage	Outdoor
Material	ABS	Warranty	1 Year
Beam Angle	120°	Battery Included	Yes
Dimmable	Selectable Brightness	Efficacy	130 lm/W

Common Troubleshooting

We've got you covered! Our troubleshooting section is here to shed some light and provide you with easy-to-follow solutions for any problem.

If you still need some assistance, feel free to contact us. Our team of lighting experts are happy to help brighten your day.

Installation

Light isn't turning on.

Allow the light to fully charge in sunlight before operation.

Turned On

Light doesn't turn on when Power button is pressed.

Allow the light to fully charge in sunlight before operation.

Clean Panel

Light doesn't turn on when power button is pressed.

Verify the solar panels are free of dust, dirt, or debris. Debris on solar panels can reduce their efficiency.

Location

Light isn't turning on in certain locations.

Check for any obstructions or damage on the light.



support @sunco.com
(844) 334-9938

REV 20