


STEPS FOR WEARING THE EARBUDS





STEP 1: Place the XClear Earbud inside your ear.



STEP 2: Then, rotate Earbud, back and away, to find a snug and comfortable fit. (Earbud fitting varies due to ear size).

EXAMPLES OF IMPROPER FIT




Do Not Rotate Earbuds Fully Horizontal (doing so WILL cause Earbuds to fall out).

Pairing

⚠ ATTENTION: Earbuds will be activated if removed from the Charging Case or if the Charging Case reaches 0% battery. They can be turned off manually by holding the MFB buttons for 3-4 seconds.

1. Open up the case to automatically Power ON earbuds. LED Lights will flash and a voice prompt will say, "Pairing".




2. Go to Settings. Go to Bluetooth. Select "XClear X1". Earbuds are now connected.

Using The Multi-Function Button



SINGLE PRESS
Music-Play/pause



DOUBLE PRESS (LEFT / RIGHT)
Left for Previous/Right for Next



SINGLE PRESS
Calls-Answer/End Calls or Switch Between Calls



SINGLE PRESS
Calls-Press and Hold For 1 Second Will Reject Call



**ACTIVATE VOICE ASSISTANT
(SIRI, GOOGLE ASSISTANT)**
Tap the MFB 3 times

Factory Reset

Follow the 2-Step Process to perform a Factory Reset.

IMPORTANT: You MUST turn OFF the earbuds first, before you RESET them. The Factory Reset is a 2-Step Process.

Step 1: TURN OFF

Action: Hold MFB buttons for 3-4 seconds.

Result: (LED Lights will blink signalling the earbuds are OFF).

Step 2: RESET

Action: Hold MFB buttons for 10-15 seconds.

Result: (LED Lights will turn on, blink, then eventually stop).

COMPLETE

Earbuds are now RESET and enter OFF state.

IMPORTANT: Please remember to DELETE your previous pairing history BEFORE you perform a Factory Reset. The Factory Reset DOES NOT remove pairing history.

FAQ

Q: What if I cannot find “**XCLEAR X1**” in the Bluetooth Page?

Reason 1: Earbuds are paired to another device.

Solution: Turn OFF Bluetooth on the mistaken devices to disconnect the Earbuds. Then, pair to your preferred device.

Reason 2: Earbuds reached 0% battery life.

Solution: Place both Earbuds into Charging Case and close it. Then, charge Earbuds for 5 mins. If Charging Case has low battery, use Micro USB Cable to charge it as well.

Reason 3: Earbuds are OFF.

Solution: Press and hold MFB's for 3-4 secs. to turn ON the Earbuds.

Q: Why won't the Left and Right Earbud sync? Why is sound only emitting from one Earbud? What if there are 2 “**XCLEAR X1**” choices on the Bluetooth page?

Solution: Complete the following process: Turn OFF Earbuds (hold MFB's for 3-4 secs.). Turn ON Earbuds (hold MFB's for 5 secs.). Voice prompt will say “Pairing”. White & Red LED Lights will flash slowly. Double tap MFB's (both L/R). LED Lights will flash faster. Once LED Lights flashing slows, the synching process is complete.