


Hisense

USER'S OPERATION MANUAL



MODEL: RS826N4ABU

Before operating the unit, please read this manual thoroughly, and retain for future reference.

Contents

Safety and warning information.....	2	Using your appliance.....	12
Installing your new appliance.....	7	Helpful hints and tips.....	13
Description of the appliance.....	9	Cleaning and care.....	14
Display controls.....	10	Troubleshooting.....	16
		Disposal of the appliance.....	17



This appliance is in accordance with the following EU guidelines: 2006/95/EC and 2004/108/EC and 2009/125/EC and EC.643/2009 and 2002/96/EC



Safety and warning information

For your safety and correct usage, before installing and first using the appliance, read this user manual carefully, including its hints and warnings. To avoid unnecessary mistakes and accidents, it is important to make sure that all people using the appliance are thoroughly familiar with its operation and safety features. Save these instructions and be sure that they remain with the appliance if it is moved or sold, so that anyone using it, throughout its life, will be properly informed on its usage and safety notices.

For the safety of life and property, keep the precautions of these user's

instructions as the manufacturer is not responsible for damages caused by omission.

Safety for children and others who are vulnerable people

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Keep all packaging away

blowing gas are flammable. When disposing of the appliance, do so only at an authorized waste disposal centre. Do not expose to flame.

Refrigerant

The refrigerant isobutene (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged. The refrigerant (R600a) is flammable.



Caution: risk of fire

If the refrigerant circuit should be damaged:

- Avoid opening flames and sources of ignition.
 - Thoroughly ventilate the room in which the appliance is situated.
- It is dangerous to alter the specifications or modify this product in any way. Any damage to the cord may cause a shortcircuit, fire, and/or electric shock.



Electrical safety

1. The power cord must not be lengthened.
2. Make sure that the power plug is not crushed or damaged. A crushed or damaged power plug may overheat and cause a fire.
3. Make sure that you can access the main plug of the appliance.
4. Do not pull the main cable.
5. If the power plug socket is loose, do not insert the power plug. There is a risk of electric shock or fire.
6. You must not operate the

from children as there is risk of suffocation.

- If you are discarding the appliance, pull the plug out of the socket, cut the connection cable (as close to the appliance as you can) and remove the door to prevent children playing from suffering an electric shock or from closing themselves inside it.
- If this appliance, featuring a magnetic door seals, is to replace an older appliance having a spring lock (latch) on the door or lid, be sure to make the spring lock unusable before you discard the old appliance. This will prevent it from becoming a death trap for a child

General safety



- **WARNING** — This appliance is intended to be used in household and similar applications such as
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type

environments;
-catering and similar non-retail applications

- **WARNING** — Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- **WARNING** — If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- **WARNING** — Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- **WARNING** — Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **WARNING** — Do not damage the refrigerant circuit.
- **WARNING** — Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- **WARNING** — The refrigerant and insulation

appliance without the interior lighting lamp cover.

7. The fridge is only applied with power supply of single phase alternating current of 220~240V/50Hz. If fluctuation of voltage in the district of user is so large that the voltage exceeds the above scope, for safety sake, be sure to apply A.C. Automatic voltage regulator of more than 350W to the fridge. The fridge must employ a special power socket instead of common one with other electric appliances. Its plug must match the socket with ground wire.

Daily use

- Do not store flammable gass or liquids in the appliance, There is a risk of an explosion.
- Do not operate any electrical appliances inthe appliance(e.g. electric ice cream makers, mixers etc.).
- When unplugging always pull the plug from the mains socket, do not pull on the cable.
- Do not place hot items near the plastic

components of this appliance.

- **Do not place food products directly against the air outlet on the rear wall.**
- Store pre-packed frozen food in accordance with the frozen food manufacture's instructions.
- The appliances manufactures storage recommendations should be strictly adhered to. Refer to relrelevant instructions for storage.
- Do not place carbonated or fizzy drinks in the freeze compartment as it creates pressure on the container, which may cause it to explode, resulting in damage to the appliance.
- Frozen food can cause frost burns if consumed straight from the freezer compartment.
- Do not place the appliance in direct sunlight.
- Keep burning candles, lamps and other items with naked flames away from the appliance so that do not set the appliance on fire.
- The appliance is intended for keeping food stuff and/or beverages in normal household as explained in this instruction booklet.

- The appliance is heavy. Care should be taken when moving it.
- Do not remove nor touch items from the freezer compartment if your hands are damp/wet, as this could cause skin abrasions or frost/freezer burns.
- Never use the base, drawers, doors etc. to stand on or as supports.
- Frozen food must not be refrozen once it has been thawed out.
- Do not consume ice popsicles or ice cubes straight from the freezer as this can cause freezer burn to the mouth and lips.
- To avoid items falling and causing injury or damage to the appliance, do not overload the door racks or put too much food in the crisper drawers.

caution!

Care and cleaning

- Before maintenance, switch off the appliance and disconnect the mains plug from the mains socket.
- Do not clean the appliance with metal objects, steam cleaner, ethereal oils, organic solvents or abrasive cleansers.
- Do not use sharp objects to remove frost from the appliance. Use a plastic scraper.

Installation Important!

- For electrical connection carefully, follow the instructions given in this manual.
- Unpack the appliance and check if there are damages on it. Do not connect the appliance if it is damaged. Report possible damages immediately to the place you bought it. In this case retain packing.
- It is advisable to wait at least four hours before connecting the appliance to allow the oil to flow back in the

compressor.

- Adequate air circulation should be around the appliance, lacking this leads to overheating. To achieve sufficient ventilation, follow the instructions relevant to installation.
- Wherever possible the back of the product should not be too close to a wall to avoid touching or catching warm parts (compressor, condenser) to prevent the risk of a fire, follow the instructions relevant to installation.
- The appliance must not be locate close to radiators or cookers.

- Make sure that the mains plug is accessible after the installation of the appliance.

Service

- Any electrical work required to do the servicing of the appliance should be carried out by qualified electrician or competent person.
- This product must be serviced by an authorized Service Center, and only genuine spare parts must be used.
 - 1)If the appliance is Frost Free.
 - 2)If the appliance contains freezer compartment.


Installing your new appliance

Before using the appliance for the first time, you should be informed of the following tips.

Ventilation of appliance

 In order to improve efficiency of the cooling system and save energy, it is necessary to maintain good ventilation around the appliance for the dissipation of heat. For this reason, sufficient clear space should be available around the refrigerator. Suggest :It is advisable for there to be 75mm of space from the back to the

wall, at least 100mm from its top, at least 100mm from its side to the wall and a clear space upfront to allow the doors to open 150°. See in follow diagrams



Relevant information (Constant / mm)

W	W1	D	D1
908	411.5	650	1196.5

Note!

● This appliance performs well in the below climate class. It may not work properly if being left at a temperature above or below the indicated range for a long period.

Climate class	Ambient temperature
SN	+10°C to +32°C
N	+16°C to +32°C
ST	+16°C to +38°C
T	+16°C to +43°C

● Stand your appliance in a dry place to avoid high moisture.

● Keep the appliance out of direct sunlight, rain or frost. Stand the appliance away from heat sources such as stoves, fires or heaters.




Leveling of appliance

● For sufficient leveling and air circulating in the lower rear section of the appliance, the bottom feet may need to be adjusted. You can adjust them by your fingers or a suitable spanner.

● To allow the doors to self-close, tilt back the top backwards for about 10mm or 0.5° by turning the adjustable feet.

● Whenever you want to move the appliance, remember to turn the feet back up so that the appliance can roll freely. Reinstall the appliance when relocating.

Caution! The rollers, which are not castors, should be only used for forward or backward movement. Moving the refrigerator sideways may damage your floor and the rollers.



Description of the appliance

View of the appliance




- | | |
|---------------------------------------|----------------------------------|
| 1. Freezer zone LED light | 11. Fresh zone LED light |
| 2. Freezer door Rack (four star zone) | 12. Fresh door Rack |
| 3. Freezer door seal | 13. Wind channel cover in fresh |
| 4. Wind channel cover in freezer | 14. Egg tray |
| 5. Freezer shelf | 15. Fresh shelf |
| 6. Ice box part | 16. Fresh door seal |
| 7. Freezer upper drawer | 17. Fresh upper drawer |
| 8. Freezer lower drawer | 18. Fresh lower drawer |
| 9. Freezer door Rack (two star zone) | 19. Right adjustable bottom feet |
| 10. Left adjustable bottom feet | |

Note: Due to unceasing modification of our products, your refrigerator may be slightly different from this Instruction Manual, but its functions and using methods remain the same.

Display controls

Use your appliance according to the following control regulations, your appliance has the corresponding functions and modes as the control panels showed in the pictures below.



When the appliance is powered on for the first time, the backlighting of the icons on display panel starts working. If no buttons have been pressed and the doors are closed, the backlighting will turn off after 60 seconds.

The control panel consists of two areas about temperature, one area about different modes.

Controlling the temperature

We recommend that when you start your refrigerator for the first time, the temperature for the refrigerator is set to 5°C and the freezer to -18°C. If you want to change the temperature, follow the instructions below.

Caution! When you set a temperature, you set an average temperature for the whole refrigerator cabinet. Temperatures inside each compartment may vary from the temperatures displayed on the panel, depending on how much food you store and where you place it. High or low room temperature may also affect the actual temperature inside the appliance.

Unlock

All the buttons are locked if the icon “” is illuminated, press the “Unlock” button for 3 seconds to unlock them. And it will be locked itself after 20 seconds no pressing any button.

Mode

You can select different modes by pressing the “Mode” button when “”. When certain mode is selected, wait for the corresponding icon flashing for 10 seconds.

Holiday

If you are going to be away for a long period of time, holiday function will be your best choice.

- Press "Unlock" button to select the Holiday function. The light will be illuminated.
- When the holiday function is activated, the temperature of the fridge is automatically switched to 15°C and the freezer to -18°C to minimize the energy consumption.

Important! Do not store any food in the fridge during this time.

Super Freeze

Super Freeze will quickly lower the temperature within the freezer so food will freeze faster. This can lock in the vitamins and nutrients of fresh food and keep food fresh longer.

- Press "Unlock" button to select the Super Freeze function. The light will be illuminated.
- For the maximum amount of food to be frozen, please wait about 24 h.
- Super freeze automatically switches off after 26 hours and the freezer temperature setted to -25°C.


Display controls

Artificial Intelligence

- When the function is selected, the temperature of the appliance is automatically adjusted.
- When the Artificial Intelligence function is activated, the temperature of the fridge is automatically switched to 5°C and the freezer to -18°C.


Fridge

- You can press the "Fridge" button to activate the mode to control the fridge temperature. When you press the button continuously, the temperature will be set as the following sequence.



Freezer

- You can press the "Freezer" button to activate the mode to control the freezer temperature. When you press the button continuously, the temperature will be set as the following sequence.



Door Alarm

- If the door of fridge or freezer is open for over 2 minutes, the door alarm will sound. The buzzer will automatically stop alarming 10 minutes later.
- To save energy, please avoid keeping the door open for a long time when using the appliance. The door alarm can be cleared by closing the door.


Using your appliance

This section tells you how to use most of the useful features. We recommend that you read through them carefully before using the appliance.

1. Adjust the door

When you find the doors are not at the same level, you can use the screwdriver to adjust the door.

When the freezer door is upper than the refrigerator door. First, you can use the screwdriver to turn the bolt anticlockwise on the lower hinge that can make the door go up. Then use the screwdriver to locking the nut.



2. Using your refrigerator compartment

The refrigerator compartment is suitable for storage of vegetables and fruit. Food inside shall be packed to store in order to avoid losing moisture or flavor permeating into other foods.

Caution! Never close the refrigerator door while the shelves, crisper and/or telescopic slides are extended. It may damage both them and the refrigerator.

Glass shelves and Door racks

The refrigerator compartment is provided with 3 glass shelves and several different door racks, which are suitable for the storage of eggs, canned liquid, bottled drinks and packed food.. They can be placed at different heights according to your need. Before you lift up the door shelf vertically, please take the food out.

- When you remove the shelves, gently pull them forward until the shelf comes

clear of the shelf guides.

- When you return the shelves, make sure there is no obstacle behind and gently push the shelf back into the position.

Note: All the door racks and covers are completely removable for cleaning.

3. Using your freezer compartment

The freezer compartment is suitable for storage of foods required to be frozen, such as meat, ice cream and others.

Caution! Ensure that bottles are not left in the freezer for longer than needed as freezing may cause the bottle to break.

Drawers

The drawers, mounted on telescopic extension slides, can be used to store rather more food..

- The method for removing the drawers is the same as the crisper in the refrigerator chamber.

4. Using your ice box

The ice box is as a independent part that can be take out of the freezing chamber.

Using the ice box

- Take out the ice box placed on a platform, then pour water into the ice trays and the water level shall not exceed the maximum line.

- Place the filled ice box back to the freezing room.

- When ice cubes form, twist the knobs dockwise and the ice will drop into the ice box below.

- Ice cubes can be stored in the ice box, if you need them, you can pull out the ice box and take them out.



water injection



take off ice

Note: If the ice box is used for the first time or has not been used for a long time, please clean it before using.

Helpful hints and tips

Energy saving tips

We recommend that you follow the tips below to save energy.

- Try to avoid keeping the door open for long periods in order to conserve energy.
- Ensure the appliance is away from any sources of heat (Direct sunlight, electric oven or cooker etc)
- Don't set the temperature colder than necessary.
- Don't store warm food or evaporating liquid in the appliance.
- Place the appliance in a well ventilated, humidity free room. Please refer to Installing your new appliance chapter.
- If the diagram shows the correct combination for the drawers, crisper and shelves, do not adjust the combination as this is designed to be the most energy efficient configuration.

Hints for refrigeration

- Don't place hot food directly into the refrigerator or freezer, the internal temperature will increase resulting in the compressor to work harder and will consume more energy.
- Do cover or wrap the food, particularly if it has a strong flavor.
- **Place food** properly so that air can circulate freely around it.
- Meat (All Types) Wrap in polythene food: wrap and place on the glass shelf above the vegetable drawer. Always follow food storage times and use by dates suggested by

manufacturers.

- Cooked food, cold dishes, etc.: They should be covered and may be placed on any shelf.
- Fruit and vegetables: They should be stored in the special drawer provided.
- Butter and cheese:

- It is recommended to label and date each frozen package in order to keep track of the storage time.

Hints for the storage of frozen food

- Ensure that frozen food has been stored correctly by the food retailer
- Once defrosted, food will deteriorate rapidly and should not be re-frozen. Do not exceed the storage period indicated by the food manufacturer.

Switching off your appliance

If the appliance needs to be switched off for an extended period, the following steps should be taken prevent mould on the appliance.

1. Remove all food.
2. Remove the power plug from the mains socket.
3. Clean and dry the interior thoroughly.
4. Ensure that all the doors are wedged open slightly to allow air to circulate.

Cleaning and care

For hygienic reasons the appliance (including exterior and interior accessories) should be cleaned regularly at least every two months.

Caution! The appliance must not be connected to the mains during cleaning. Danger of electrical shock! Before cleaning switch the appliance off and remove the plug from the mains socket.

Exterior cleaning

To maintain good appearance of your appliance, you should clean it regularly.

-Wipe the digital panel and display panel with a clean, soft cloth.-

-Spray water onto the cleaning cloth instead of spraying directly on the surface of the appliance. This helps ensure an even distribution of moisture to the surface.

-Clean the doors, handles and cabinet surfaces with a mild detergent and then wiped dry with a soft cloth.

Caution!

-Do not use sharp objects as they are likely to scratch the surface.

-Do not use Thinner, Car detergent, Clorox, ethereal oil, abrasive cleansers or organic solvent such as Benzene for cleaning. They may damage the surface of the appliance and may cause fire.

Interior cleaning

You should clean the appliance interior regularly. It will be easier to clean

when food stocks are low. Wipe the inside of the fridge freezer with a weak solution of bicarbonate of soda, and then rinse with warm water using a wrung-out sponge or cloth. Wipe completely dry before replacing the shelves and baskets. Thoroughly dry all surfaces and removable parts.

Although this appliance automatically defrosts, a layer of frost may occur on the freezer compartment's interior walls if the freezer door is opened frequently or kept open too long. If the frost is too thick, choose a time when the supply of food stocks are low and proceed as follows:

1. Remove existing food and accessories baskets, unplug the appliance from the mains power and leave the doors open. Ventilate the room thoroughly to accelerate the thawing process.

2. When defrosting is completed, clean your freezer as described above.

As the appliance does not automatically defrost, frost will occur in certain areas in the freezer compartment after a period of use. This frost can be scraped away by using a plastic scraper.

NEVER use a metal or sharp instrument.

However, complete defrosting will become necessary approximately four times per year, or if the frost layer exceeds 4mm (1/4") affecting the system efficiency. Complete defrosting should be carried out if the frost cannot be scraped away, or if it begins to interfere with the food storage. Choose a time when the supply of food is low and proceed as follows:

1. Remove existing food and accessories, unplug the appliance from the mains power and leave the doors open. Ventilate the room thoroughly to accelerate the thawing process.

2. Scrape away as much frost as possible using the plastic scraper (scraper not included).

3. If necessary, place a cloth soaked with warm water on the frost layer's surface to accelerate the thawing process.

4. When defrosting is completed, clean your freezer as described - see interior cleaning.

Caution! Do not use sharp objects to remove frost from the freezer compartment. Only after the interior is completely dry should the appliance be switched back on and plugged back into the mains socket.

Door seals cleaning

Take care to keep door seals clean. Sticky food and drinks can cause seals to stick to the cabinet and tear when you open the door. Wash seal with a mild detergent and warm water. Rinse and dry it thoroughly after cleaning.

Caution! Only after the door seals are completely dry should the appliance be powered on.

Replacing the LED light

Warning: The LED light must not be replaced by the user! If the LED light is damaged, consult a qualified, registered electrician for assistance.

Troubleshooting

If you experience a problem with your appliance or are concerned that the appliance is not functioning correctly, you can carry out some easy checks before calling for service, please see below. You can carry out some easy checks according to this section before calling for service.

Warning! Do not try to repair the appliance yourself. If the problem persists after you have made the checks mentioned below, contact a qualified electrician, authorized service engineer or the shop where you purchased the product.

Problem	Possible cause & Solution
Appliance is not working correctly	Check whether the power cord is plugged into the power outlet properly.
	Check the fuse or circuit of your power supply, replace if necessary.
	The ambient temperature is too low. Try setting the chamber temperature to a colder level to solve this problem.
	It is normal that the freezer is not operating during the automatic defrost cycle, or for a short time after the appliance is switched on to protect the compressor.
Odours from the compartments	The interior may need to be cleaned
	Some food, containers or wrapping cause odours.
Noise from the appliance	The sounds below are quite normal: <ul style="list-style-type: none"> ●Compressor running noises. ●Air movement noise from the small fan motor in the freezer compartment or other compartments. ●Gurgling sound similar to water boiling. ●Popping noise during automatic defrosting. ●Clicking noise before the compressor starts.
	Other unusual noises are due to the reasons below and may need you to check and take action: The cabinet is not level. The back of appliance touches the wall. Bottles or containers fallen or rolling.
The motor runs continuously	It is normal to frequently hear the sound of the motor, it will need to run more when in following circumstances: <ul style="list-style-type: none"> ● Temperature setting is set colder than necessary ● Large quantity of warm food has recently been stored within the appliance. ●The temperature outside the appliance is too high. ●Doors are kept open too long or too often. ●After your installing the appliance or it has been switched off for a long time.
A layer of frost occurs in the compartment	Check that the air outlets are not blocked by food and ensure food is placed within the appliance to allow sufficient ventilation. Ensure that door is fully closed. To remove the frost, please refer to cleaning and care chapter.

Temperature inside is too warm	You may have left the doors open too long or too frequently; or the doors are kept open by some obstacle; or the appliance is located with insufficient clearance at the sides, back and top
Temperature inside is too cold	Increase the temperature by following the "Display controls" chapter.
Doors cant be closed easily	Check whether the top of the refrigerator is tilted back by 10-15mm to allow the doors to self close, or if something inside is preventing the doors from closing.
Water drips on the floor	The water pan (located at the rear bottom of the cabinet) may not be properly leveled, or the draining spout (located underneath the top of the compressor depot) may not be properly positioned to direct water into this pan, or the water spout is blocked. You may need to pull the refrigerator away from the wall to check the pan and spout.
The light is not working	<ul style="list-style-type: none"> ●The LED light may be damaged. Refer to replace LED lights in cleaning and care chapter. ●The control system has disabled the lights due to the door being kept open too long, close and reopens the door to reactivate the lights.

Disposal of the appliance

It is prohibited to dispose of this appliance as household waste.

Packaging materials

Packaging materials with the recycle symbol are recyclable. Dispose of the packaging into a suitable waste collection container to recycle it.

Before disposal of the appliance

1. Pull out the mains plug from the mains socket.
2. Cut off the power cord and discard with the mains plug

Warning! Refrigerators contain refrigerant and gases in the insulation. Refrigerant and gases must be disposed of professionally as they may cause eye injuries or ignition. Ensure that tubing of the refrigerant circuit is not damage prior to proper disposal.

	Correct Disposal of this product
	<p>This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.</p>

المحتويات

12.....	استخدام جهازك	2.....	معلومات السلامة والتحذيرات
13.....	نصائح وتلميحات مفيدة	7.....	تركيب جهازك الجديد
14.....	تنظيف الجهاز والعناية به	9.....	وصف الجهاز
16.....	استكشاف الأخطاء وإصلاحها	10.....	ضوابط العرض
17.....	التخلص من الجهاز		

يتطابق هذه الجهاز مع المبادئ التوجيهية التالية للاتحاد الأوروبي: EC/2006/95 و
EC/2002/96 و EC/643/2009 و EC/2009/125 و EC/2004/108



معلومات السلامة والتحذيرات



تحذير: خطر الحريق



إذا تم إتلاف دائرة التبريد:
- تجنب إشعال النيران ومصادر الاشتعال.
- قم بتهوئة الغرفة التي يوجد بها الجهاز تماما.
من الخطر تغيير أو تعديل مواصفات هذا المنتج بأي شكل من الأشكال. قد يتسبب أي ضرر يلحق بالسلك بفصور في دائرة التبريد وحرق وصدمة كهربائية أو إحدى هذه الأمور.

السلامة الكهربائية



1. يجب عدم إطالة سلك الكهرباء.
2. تأكد من أن قابس التيار الكهربائي ليس محطما أو تالفا. قد تزداد حرارة قابس التيار الكهربائي المحطم أو التالف أو يتسبب في حدوث حريق.
3. تأكد من أنه يمكنك إلى القابس الرئيسي للجهاز.
4. لا تسحب الكابل الرئيسي.
5. إذا كان مأخذ قابس التيار الكهربائي واسعا، لا تقم بإدخال قابس الطاقة. حيث وجود خطر حدوث صدمة كهربائية أو حريق.
6. يجب عدم تشغيل الأطفال للجهاز حيث خطر الاختناق.
- إذا كنت ترغب في التخلص من الجهاز، اسحب القابس من المأخذ، وافصل الكابل (بحيث تكون قريبا من الجهاز بقدر المستطاع) وقم بإزالة الباب لمنع تعرض الأطفال الذين يلعبون لصدمة كهربائية أو من حبس أنفسهم داخل الجهاز.
- إذا كان من المقرر استبدال الجهاز القديم ذو القفل الذي يجعل بنافض (قفل) على الباب أو غطاء بجهاز جديد، والذي يتميز بقفل الباب المغناطيسي، تأكد من إفساد عمل

حفاظا على سلامتك ومن أجل استخدام صحيح للجهاز، يُرجى قراءة هذا الدليل وما يحتوي عليه من تلميحات وتحذيرات بعناية قبل تركيب الجهاز واستخدامه لأول مرة. لتجنب الأخطاء والحوادث التي لا داعي لها، يلزم التأكد من أن جميع الأشخاص الذين يستخدمون الجهاز على دراية تامة بخصائص السلامة والتشغيل. احتفظ بهذه التعليمات وتأكد من إلحاقها بالجهاز إذا ما تم نقله أو بيعه بحيث يمكن لأي شخص يستخدم الجهاز، طيلة عمر الجهاز، الإطلاع بشكل صحيح على إخطارات السلامة والاستخدام. لسلامة الأرواح والممتلكات، التزم دائما بالاحتياطات الخاصة بتعليمات المستخدم حيث لا يعتبر المُصنع مسؤولا عن الأضرار الناجمة عن الإغفال.

سلامة الأطفال وغيرهم من الفئات الضعيفة

- يمكن للأطفال الذين تتراوح أعمارهم بين 8 سنوات فما فوق استخدام هذا الجهاز وكذلك الأشخاص ذوي القدرات البدنية أو العقلية المنخفضة أو ممن يفتقدون الخبرة والمعرفة إذا ما تم منحهم رقابة أو تعليمات بشأن استخدام الجهاز بطريقة آمنة وتوعيتهم بالمخاطر الناجمة. يجب ألا يعيب الأطفال بالجهاز. لا ينبغي أن يقوم الأطفال بعملية التنظيف والصيانة دون إشراف.
- الحفاظ على جميع العبوات القابلة للاشتعال بعيدا عن الغاز الساري. عند التخلص من الجهاز، لا تقم بذلك إلا في مركز معتمد للتخلص من النفايات. لا تعرض الجهاز للهب المبرد.
- يوجد الأيزوبيوتلين (R600a) داخل دائرة تبريد الجهاز، وهو ما يعتبر غاز طبيعي ذو مستوى عال من التوافق البيئي وبالرغم من هذا فهو قابل للاشتعال. أثناء نقل وتركيب الجهاز، تأكد من عدم إتلاف أي من مكونات دائرة التبريد.
- فإن المبرد (R600a) قابل للاشتعال.

القفل ذو النابض قبل التخلص من الجهاز القديم. سوف يجنبنا ذلك من أن يصبح مصيدة مميتة لأي طفل من الأطفال.

السلامة العامة



- تحذير - تم تصنيع هذا الجهاز لاستخدامه في الأغراض المنزلية وما شابه ذلك مثل المطابخ المخصصة للعاملين في المحلات التجارية والمكاتب وغير ذلك من بيئات العمل الأخرى؛
 - البيوت الزراعية والنزل في الفنادق والنزل وغيرها من الأماكن السكنية؛
 - الأماكن المخصصة للنوم والأطوار؛
 - المطاعم وغير ذلك من الاستخدامات المماثلة
 - تحذير - لا تخزن مواد متفجرة مثل عبء الهباء الجوي (الأيروسول) ذات الوقود الدافع القابل للاشتعال داخل هذا الجهاز.
 - تحذير - إذا أصبح سلك إمداد الطاقة تالفاً، يجب استبداله من قبل الشركة المصنعة أو وكيل خدماتها أو غيرهم من الأشخاص المؤهلين لتجنب المخاطر.
 - تحذير - حافظ على فتحات التهوية الموجودة في حاوية الجهاز أو في بنيتة الداخلية خالية من أي انسدادات.
 - تحذير - لا تستخدم أدوات ميكانيكية أو غيرها من الأدوات لتسريع عملية إزالة الثلج، بخلاف الأدوات الموصى بها من قبل الشركة المصنعة.
 - تحذير - لا تتلف دائرة التبريد.
 - تحذير - لا تستخدم أجهزة كهربائية داخل الأماكن المخصصة لتخزين الطعام في الجهاز، ما لم تكن من النوع الموصى به من قبل الشركة المصنعة.
 - تحذير - يتم استخدام المررد وجهاز العزل دون غطاء معمل الإضاءة الداخلية.
 - 7. تجنب الثلجة فقط بالتيار المتردد أحادي الطور V/50Hz 240~220، إذا كان تذبذب التيار الكهربائي في المنطقة التي يقطن بها المستخدم كبيراً جداً بحيث يتجاوز النطاق المحدد، يُرجى التأكد من تطبيق التيار المتردد AC من أجل السلامة. يتم استخدام منظم التيار الأتوماتيكي لأكثر من 350 وات للثلجة. يجب استخدام مأخذ طاقة خاص للثلجة بدلاً من مأخذ مشترك مع أجهزة كهربائية أخرى. يجب أن يتوافق قابس الثلجة والمأخذ مع السلك الأرضي.
- ### الاستخدام اليومي
- لا تخزن غاز قابل للاشتعال أو سوائل في الجهاز، حيث يكون هناك خطر حدوث انفجار.
 - لا تُشغل أي أجهزة كهربائية أخرى داخل الجهاز (مثل: صناعة الأيس كريم الكهربائي، والخلاطات وغيرها من الأجهزة).
 - عند نزع القابس، تأكد دائماً من نزعه من المأخذ الرئيسي، لا تسحب من الكابل.
 - لا تضع أغراض ساخنة بالقرب من المكونات البلاستيكية للجهاز.

- لا تضع المنتجات الغذائية مباشرة في قبالة منفذ الهواء على الجدار الخلفي.
 - خزن الطعام المجمد المسبق التعبئة وفقاً للتعليمات الخاصة بتصنيع الأغذية المجمدة.
 - يجب الالتزام التام بتوصيات التخزين المقدمة من مصنع الجهاز. يُرجى الرجوع إلى التعليمات ذات الصلة الخاصة بالتخزين.
 - لا تضع المشروبات الغازية أو الفوارة في حجرة التجميد حيث أنها تخلق ضغط على الحاوية والتي بدورها قد يتسبب في انفجارها مما يسفر عن تلف الجهاز.
 - قد تتسبب الغذية المجمدة في إحداث حروق الصقيع إذا تم تناولها مباشرة بعد خروجها من حجرة التجميد.
 - لا تضع الجهاز في ضوء الشمس المباشر.
 - حافظ على إبقاء الشموع المحرقة والمصابيح وغيرها من الأغراض ذات اللهب المكشوف بعيداً عن الجهاز حتى لا تجعل الجهاز عرضة للحريق.
 - تم تصنيع هذا الجهاز لحفظ المواد الغذائية والمشروبات أو أي منهما لدى الأسر العادية كما جاء موضحاً في كتيب التعليمات هذا.
 - إن هذا الجهاز ثقيل، ينبغي توخي الحذر عند تحريكه.
 - لا تحرك الغراض أو تلمسها داخل غرفة التجميد إذا كانت يدك رطبة/مبللة، حيث قد يتسبب ذلك في حدوث سحجات في الجلد أو حروق جلدية/صقيعية.
 - لا تستخدم القاعدة أو الأدراج أو البواب مطلقاً في الوقوف عليها أو كدعامات.
 - لا يجب إعادة تجميد الأغذية المجمدة بمجرد إذابته الثلج عنها.
 - لا تتناول المصاصات الثلجية أو مكعبات الثلج بعد خروجها مباشرة من المجمد حيث يمكن أن يتسبب ذلك في إحداث حرق صقيعي للغم والشفتين.
 - لتجنب سقوط الأغراض والتسبب في وقوع إصابة أو تلف بالجهاز، لا تفرط في تحميل أرفف الباب أو تضع الكثير من الطعام في أدراج الحفظ.
- ### تحذير!
- ### الاهتمام والتنظيف
- يجب إيقاف تشغيل الجهاز قبل الصيانة وفصل قابس التيار الكهربائي من المأخذ الرئيسي.
 - لا تنظف الجهاز باستخدام أجسام معدنية أو منظف البخار أو الزيوت الأثيرية أو المنبيبات العضوية أو المنظفات الكاشطة.
 - لا تستخدم أدوات حادة لإزالة الثلج من الجهاز. استخدم كاشطة بلاستيكية
- ### هام للتركيب!
- فيما يتعلق بالتوصيل الكهربائي، اتبع الإرشادات المقدمة في هذا الدليل بكل عناية.
 - فك الجهاز وتحقق من وجود أي أضرار به. لا تقم بتوصيل الجهاز بالكهرباء إذا كانت هناك أي أضرار به. قم بإبلاغ المكان الذي اشتريته الجهاز منه عن الأضرار

المحتملة على الفور. يُرجى الاحتفاظ بالتعبئة والتغليف في هذه الحالة.

- من المستحسن الانتظار مدة لا تقل عن 4 ساعات قبل توصيل الجهاز بالتيار الكهربائي للسماح بتدفق الزيت مرة أخرى في الضاغط.
 - ينبغي أن يكون دوران الهواء المناسب حول الجهاز، وسوف يؤدي الإخلال بذلك إلى ارتفاع درجة الحرارة. لتحقيق التهوية الكاملة، اتبع الإرشادات الخاصة بالتركيب.
 - ينبغي ألا يكون الجزء الخلفي للجهاز قريب جداً من الجدار بقدر الإمكان لتجنب ملامسة أو الإمساك بالأجزاء الساخنة (الضاغط، المكثف) اتبع الإرشادات الخاصة بالتركيب، لمنع خطر حدوث حريق
 - يجب عدم وضع الجهاز بالقرب من الأجهزة المشعة أو المواقد.
 - تأكد من إمكانية الوصول إلى القابس الرئيسي بعد تركيب الجهاز.
- الخدمة**

- يجب تنفيذ أي عمل من أعمال الكهرباء اللازمة للجهاز بواسطة كهربائي مؤهل أو شخص مختص.
 - يجب أن تتم خدمة وصيانة هذا الجهاز لدى مركز خدمة معتمد، ويجب استخدام قطع الغيار الأصلية فقط.
- 1| إذا كان الجهاز لا يحتوي على وحدة التجميد.
2| إذا كان الجهاز يحتوي على وحدة التجميد.

تركيب جهازك

يجب معرفة النصائح التالية قبل استخدام الجهاز لأول مرة.

تهوية الجهاز

لتحسين كفاءة نظام التبريد وحفظ الطاقة، يجب الحفاظ على التهوية الجيدة حول الجهاز لتبديد الحرارة. لهذا السبب، يجب ترك مساحة فارغة كافية حول التلاجة. اقتراح: من المستحسن ترك مساحة 75 مم بين الجزء الخلفي للجهاز والجدار، وما لا يقل عن 100 مم أعلاه، وما لا يقل أيضاً عن 100 مم بين جانب الجهاز والجدار وكذلك مساحة فارغة كافية في المقدمة للسماح بفتح الأبواب بزوايا 150°. انظر الرسوم التخطيطية التالية.



معلومات ذات صلة (ثابتة/ مم)


D1	D	W1	W
.1196.5	.650	.411.5	.908

ملاحظة!


- يعمل هذا الجهاز جيداً في ظل الفئة المناخية المذكورة أدناه. قد لا يعمل بشكل جيد إذا تم وضعه في درجة حرارة أعلى أو أدنى من النطاق المحدد لفترة طويلة.

الفئة المناخية	درجة الحرارة المحيطة
SN	10°Cto+32°C+
N	16°Cto+32°C+
ST	16°Cto+38°C+
T	16°Cto+43°C+

- ضع جهازك في مكان جاف لتجنب الرطوبة العالية.
- حافظ على إبقاء الجهاز بعيداً عن أشعة الشمس المباشرة أو الأمطار أو الصقيع. ضع الجهاز بعيداً عن مصادر الحرارة مثل المواقد أو الحرائق أو السخانات.



إستواء الجهاز




أقدام سفلية قابلة للتعديل

• للحصول على درجة إستواء كافية وتدوير الهواء في الجزء الخلفي السفلي للجهاز، قد يلزم تعديل وضع قدمي الجهاز السفليين. يمكنك تعديلهما بأصابعك أو مفتاح براغي مناسب.

• للسماح بالعلق الذاتي للجهاز، أمل مقنمة الجهاز إلى الخلف حوالي 10 مم أو بزاوية 0.5 عن طريق تحويل قدمي الجهاز القابلة للتعديل.

• كلما أردت تحريك الجهاز، تذكر تحويل قدمي الجهاز إلى الخلف حتى يتحرك الجهاز بحرية. أعد تثبيت الجهاز عند نقله.

تحذير! يجب استخدام البكرات، والتي ليست بعجلات، فقط للتحرك إلى الأمام أو الخلف. قد يتسبب تحريك الجهاز بشكل جانبي إلى الإضرار بالأرضية والبكرات.



أقدام سفلية قابلة للتعديل

وصف الجهاز

عرض الجهاز



1. ضوء LED لمنطقة المجمد (المجمد)
2. رف باب المجمد (منطقة 4 نجوم)
3. قفل باب المجمد
4. غطاء مجرى الهواء في المجمد
5. رف المجمد
6. جزء صندوق الثلج
7. الدرج العلوي للمجمد
8. الدرج السفلي للمجمد
9. رف باب المجمد (منطقة نجمتين)
10. أقدام سفلية يسرى قابلة للتعديل
11. ضوء LED لمنطقة الحفظ الطازج (المجمد)
12. رف باب منطقة الحفظ الطازج
13. غطاء مجرى الهواء في منطقة الحفظ الطازج
14. صنية البيض
15. رف الحفظ الطازج
16. قفل باب منطقة الحفظ الطازج
17. الدرج العلوي لمنطقة الحفظ الطازج
18. الدرج السفلي لمنطقة الحفظ الطازج
19. أقدام سفلية اليمنى قابلة للتعديل

ملاحظة: قد تكون ثلاجتك مختلفة بعض الشيء عن دليل التعليمات هذا وذلك بسبب التعديل الدائم لمنتجاتنا ولكن تظل الوظائف وطرق الاستخدام واحدة.

ضوابط العرض

ثوان لفتحها. وسوف تفتح تلقائياً بعد 20 ثانية عند عدم الضغط على أي زر.

الوضع

يمكنك اختيار أوضاع مختلفة عن طريق الضغط

على زر "الوضع" عند "6". عندما يتم تحديد وضع معين، انتظر وميض الأيقونة المقابلة لمدة 10 ثوان.

العطلة 

إذا كنت ستتعب لفترة طويلة من الزمن، سيكون وضعية العطلة خيارك الأمثل.

• اضغط على زر "إلغاء القفل" لاختيار وضعية العطلة. سيتم تشغيل الضوء.

• عندما يتم تفعيل وضعية العطلة، سيتم تحويل درجة حرارة التلاجة تلقائياً إلى 15 درجة مئوية والمجمد إلى -18 درجة مئوية للحد من استهلاك الطاقة.

هام! لا تخزن أي طعام في التلاجة خلال هذه الفترة.

التجميد الفائق 

سوف يؤدي التجميد الفائق إلى خفض درجة الحرارة سريعاً داخل المجمد بحيث يتجمد الطعام بشكل أسرع. سوف يؤدي ذلك إلى حبس الفيتامينات والمواد المغذية بالطعام الطازج والمحافظة عليه طازجاً لفترة أطول.

• اضغط على زر "إلغاء القفل" لاختيار وضعية التجميد الفائق. سيتم تشغيل الضوء.

• لتجميد أكبر قدر من الأطعمة، يرجى الانتظار حوالي 24 ساعة.

• ينطفئ التجميد الفائق تلقائياً بعد مرور 26 ساعة ويتم ضبط درجة حرارة المجمد على -25 درجة مئوية.

استخدم جهازك وفقاً للوائح الضبط التالية، يتميز جهازك بالأوضاع والوظائف المقابلة كما أوضحت لوحات التحكم في الصور أدناه.

عندما يتم تشغيل الجهاز للمرة الأولى، تبدأ الإضاءة الخلفية للأيقونات الموجودة

على لوحة العرض في العمل.

إذا لم يتم الضغط على أي أزرار

وتم إغلاق الأبواب، سوف

تنطفئ الإضاءة الخلفية بعد 60 ثانية.

تتكون لوحة التحكم من

منطقتين خاصتين بدرجة

الحرارة ومنطقة خاصة

بأوضاع مختلفة.

التحكم في درجة الحرارة

نوصي بضبط درجة حرارة

التلاجة عند تشغيلها لأول مرة

عند 5 درجات مئوية والمجمد

عند -18 درجة مئوية. إذا

أردت تغيير درجة الحرارة،

التعليمات المذكورة أدناه.

تحذير! عند ضبط درجة

الحرارة، فإنك تضبط متوسط

درجة الحرارة لخزانة التلاجة

بأكملها. قد تختلف درجات

الحرارة داخل كل حجرة من حجرات التبريد عن

درجات الحرارة المعروضة على اللوحة وفقاً لمقدار

الطعام الذي قمت بتخزينه والمكان الذي وضعته فيه.

قد تؤثر درجة حرارة الغرفة المرتفعة أو المنخفضة

على درجة الحرارة الفعلية داخل الجهاز.

إلغاء القفل

تعتبر جميع الأزرار مغلقة إذا كانت الأيقونة


"5" مضاءة، اضغط زر "إلغاء القفل" لمدة 3



ضوابط العرض

المجمد

- يمكنك الضغط على زر "المجمد" لتنشيط الوضع الخاص بضبط درجة حرارة المجمد. عندما تضغط على الزر بشكل مستمر، سيتم ضبط درجة الحرارة **وفقا للتسلسل التالي.**



تنبيه الباب


- إذا تم فتح باب الثلاجة أو المجمد لمدة تزيد عن دقيقتين، سوف يصدر صوت تنبيه الباب. سوف تتوقف الصفارة تلقائياً عن التنبيه بعد مرور 10 دقائق.
- لحفظ الطاقة، يرجى تجنب إبقاء الباب مفتوحاً لفترة طويلة عند استخدام الجهاز. يمكن التخلص من تنبيه الباب عن طريق غلق الباب

التكاء الاصطناعي

- عندما يتم تحديد الوضعية، يتم ضبط درجة حرارة الجهاز تلقائياً.
- عندما يتم تفعيل وضعية التكاء الاصطناعي، سيتم تحويل درجة حرارة الثلاجة تلقائياً إلى 5 درجات مئوية والمجمد إلى -18 درجة مئوية.

الثلاجة

- يمكنك الضغط على زر "الثلاجة" لتنشيط الوضع الخاص بضبط درجة حرارة الثلاجة. عندما تضغط على الزر بشكل مستمر، سيتم ضبط درجة الحرارة وفقاً للتسلسل التالي.




استخدام جهازك

يطلعك هذا الجزء على كيفية استخدام معظم الخصائص المفيدة. نوصي بأن تقرأ هذا الجزء بعناية قبل استخدام الجهاز.

1. ضبط الباب

إذا وجدت أن الأبواب ليست على نفس المستوى، يمكنك استخدام مفك لضبط الباب.

إذا كان باب المجمد أعلى من باب الثلاجة، أولاً، يمكنك استخدام مفك البراغي لتحويل البرغي عكس عقارب الساعة على المفصل المنخفض الذي يمكنه أن يؤدي إلى ارتفاع الباب. ثم استخدم مفك البراغي لإغلاق الصمولة.



2. استخدام مقصورة الثلاجة الخاصة بك

تعتبر مقصورة الثلاجة مكاناً مناسباً لتخزين الخضروات والفاكهة. سيتم تعبئة الطعام داخل الثلاجة لتخزينه من أجل تجنب فقدان الرطوبة أو تخلل النكهة إلى أطعمة أخرى. **تحذير!** لا تغلق باب الثلاجة مطلقاً عند تمديد الأرفف وأدراج الحفظ والألواح المتداخلة أو أي من ذلك. قد يتسبب

ذلك في إتلاف كلا منهم والثلاجة.

الأرفف الزجاجية وأرفف البايك

يتم تزويد مقصورة الثلاجة بثلاثة أرفف زجاجية والعديد من أرفف البايك المختلفة والتي تعتبر مناسبة لتخزين البيض والسوائل المعبأة والمشروبات المعبأة في زجاجات والمواد الغذائية المعبأة. يمكن وضع تلك الغراض على ارتفاعات مختلفة وفقاً لحاجتك. يرجى إخراج الطعام قبل رفع رف البايك عمودياً.

• عند إزالة الأرفف، اسحبها بلطف إلى الأمام حتى يتحرر الرف من أذرع المنزلة.

• عند إعادة الأرفف، تأكد من عدم وجود عائق في الخلف واسحب الرف برفق مرة أخرى إلى موضعه الصلي.

ملاحظة: جميع أرفف البايك والأغطية يمكن إزالتها تماماً للتنظيف.

3. استخدام مقصورة المجمد الخاص بك

تعتبر مقصورة المجمد مكاناً مناسباً لتخزين الأطعمة اللازم تجميدها مثل اللحوم والأس كريمة وغيرها من المأكولات. **تحذير!** تأكد من عدم ترك الزجاجات في المجمد لأكثر من ٧ حيث يتسبب ذلك في كسر الزجاجات.

الأدراج

- عندما تتشكل مكعبات الثلج، حرك المقابض عكس عقارب الساعة وسوف يسقط الثلج أسفل علبة الثلج.
- يمكن تخزين مكعبات الثلج في علبة الثلج، ويمكنك سحبها خارجاً وأخذها إذا كنت بحاجة إليها



صب الماء



إخراج الثلج

إذا كنت تستخدم علبة الثلج لأول مرة أو لم: ملاحظة
تستخدمها لفترة طويلة، يرجى تنظيفها قبل الاستخدام

يمكن استخدام الأدرج التي تم وضعها على الألواح الممتدة المتداخلة لتخزين مزيد من الطعام.

• طريقة إزالة الأدرج هي نفس طريقة إزالة درج الحفظ داخل مقصورة الثلاجة.

4. استخدام علبة الثلج

تعتبر علبة الثلج جزء مستقل بذاته والذي يمكن إخراجها من مقصورة المجمد.

استخدام علبة الثلج

- إخرج علبة الثلج الموضوعه على منصة تحميل ثم صب الماء في أطباق الثلج على ألا يتجاوز مستوى الماء الحد الأقصى.
- ضع علبة الثلج الممتلئة مرة أخرى في مقصورة التجميد.

نصائح وتلميحات مفيدة

خطوات توفير الطاقة

نوصي باتباع النصائح التالية لتوفير الطاقة.
• حاول تجنب ترك الباب مفتوحاً لفترات طويلة للحفاظ على الطاقة.

• تأكد من إبقاء الجهاز بعيداً عن أي مصدر من مصادر الحرارة (ضوء الشمس المباشر، الفرن الكهربائي أو البوتجاز الخ)

• لا تضبط درجة الحرارة أبرد من اللازم.

• لا تخزن الطعام الساخن أو السوائل المتبخرة في الجهاز.

• ضع الجهاز في غرفة جيدة التهوية وخالية من الرطوبة.

• يرجى الرجوع إلى الفصل الخاص بتركيب جهازك الجديد.

• إذا أوضح الرسم البياني التركيب الصحيح للأدرج ودرج

الحفظ والرفق، فلا تقم بتعديل وضع التركيب حيث تم

تصميم هذا الوضع ليصبح أكثر كفاءة في استخدام الطاقة.

نصائح خاصة بعملية التبريد

• لا تضع الطعام الساخن مباشرة في الثلاجة أو المجمد حيث

ستزداد درجة الحرارة الداخلية نتيجة لعمل الضاغط بجهد

أكبر مما سيؤدي إلى استهلاك مزيد من الطاقة.

• غط الطعام أو لفه خاصة إذا كان ذو نكهة قوية.

• ضع الطعام بشكل صحيح حتى يدور الهواء بحرية من

حولته.

• لف اللحوم (جميع أنواع اللحوم) في البولييثين: لف اللحم

وضعه على الرف الزجاجي فوق درج الخضراوات. | اتبع

دائماً أوقات تخزين الطعام حسب اقتراح الشركة المصنعة.

• الأطعمة المطهية، والأطباق الباردة، الخ:

يجب تغطيتها ويمكن وضعها على الرف.

• الخضراوات والفاكهة: |

يجب تخزينها في الدرج المخصص لهذا الغرض.

• الجبن والزبد:

• يوصى بتسميتها وكتابة التاريخ على كل مجموعة مجمدة

حتى يمكن متابعة وقت التخزين.

نصائح خاصة بتخزين الأطعمة المجمدة

• تأكد من أنه قد تم تخزين الأطعمة المجمدة بشكل صحيح

من قبل بائعي التجزئة

• تتلف الأغذية المجمدة بمجرد فكها من الثلج ويجب ألا يعاد

تجميدها مرة أخرى. لا تتجاوز فترة التخزين الموضحة

من قبل مصنعي المواد الغذائية.

إطفاء جهازك

إذا لزم فصل الجهاز لفترة طويلة، يجب اتباع الخطوات

التالية لمنع ظهور التعفن على الجهاز.

1 أزل جميع الأطعمة.

2 انزع قابس الطاقة من المأخذ الرئيسي.

3 نظف وجفف الجهاز من الداخل بدقة.

4 تأكد من أن جميع الأبواب مفتوحة قليلاً للسماح بدوران

الهواء.

تنظيف الجهاز والعناية به

التجميد بعد فترة من الاستخدام نظرًا لأن الجهاز لا يتم بإذابة الثلج تلقائيًا. يمكن كشط هذا الثلج باستخدام مكشطة بلاستيكية.
لا تستخدم أداة حادة أو معدنية مطلقًا.

ومع ذلك، تصبح عملية إذابة الثلج بصورة كاملة أمرًا ضروريًا أربعة مرات في السنة وإلا ستؤثر طبقة الثلج إذا زادت عن 4 مم ($1/4$ ") على كفاءة النظام. ينبغي إذابة الثلج بصورة كاملة إذا لم يتسنى كشط الثلج أو بدأ في التداخل مع تخزين الطعام. اختر وقتًا حيث يكون مخزون الطعام منخفضًا واتبع الخطوات التالية:

1. أزل الطعام الموجود وعب الكسورات، ثم قم بفصل الجهاز من القابس الرئيسي واترك الأبواب مفتوحة. قم بتهوية الغرفة جيدًا لتسريع عملية الذوبان.
2. اكشط الثلج بقدر المستطاع باستخدام مكشطة بلاستيكية (لم يتم إرفاق مكشطة).
3. إذا كان ذلك ضروريًا، ضع قطعة قماش مبللة بماء دافئ على سطح طبقة الثلج لتسريع عملية الإذابة.
4. عند إكمال ذوبان الثلج، نظف المجمد على النحو

الموضح أعلاه- انظر التنظيف الداخلي.
تحذير! • لا تستخدم أدوات حادة لإزالة الثلج من مقصورة المجمد. لا يتم تشغيل الجهاز وتوصيله بالمقبس الرئيسي مرة أخرى إلا بعد جفاف الجهاز تمامًا من الداخل.

تنظيف أقفال الباب

احرص على إبقاء أقفال الباب نظيفة. يمكن أن تتسبب الماكولات والمشروبات اللزجة في التصاق الخزانة وتمزقها عند فتح الباب. اغسل القفل باستخدام منظف خفيف وماء دافئ. اشطفه وجففه جيدًا بعد التنظيف. تحذير! لا يتم تشغيل الجهاز إلا بعد جفاف أقفال الباب تمامًا.

استبدال مصباح LED

تحذير: لا ينبغي استبدال مصباح LED بواسطة المستخدم! في حال تلف مصباح LED، استشر كهربائيًا مؤهلاً معتمدًا للحصول على المساعدة

يجب تنظيف الجهاز (بما في ذلك الأكسسورات الخارجية والداخلية) لأسباب صحية بانتظام كل شهرين على الأقل. تحذير! يجب عدم توصيل الجهاز بالتيار الكهربائي أثناء التنظيف. خطر صدمة كهربائية.

يجب إيقاف تشغيل الجهاز قبل التنظيف وفصل قابس التيار الكهربائي من المأخذ الرئيسي.

التنظيف الخارجي

يجب تنظيف الجهاز بصفة منتظمة للحفاظ على مظهره الخارجي.
- امسح اللوحة الرقمية ولوحة العرض بقطعة قماش نظيفة وناعمة.
- رش المياه على قماش التنظيف بدلًا من رشه مباشرة على سطح الجهاز. يساعد هذا على ضمان توزيع الرطوبة على سطح الجهاز.

نظف أسطح الأبواب والمقابض ووحدة الحفظ باستخدام منظف خفيف ثم جففها بقطعة قماش ناعمة وجافة.
تحذير!
- لا تستخدم أدوات حادة حيث يمكن أن تخدش السطح.
- لا تستخدم التينز أو منظفات السيارات أو الكلوروكس أو الزيت الأثيري أو المنظفات الكاشطة أو المذيبات العضوية مثل البنزين في عملية التنظيف. قد تتسبب هذه المنظفات في إتلاف سطح الجهاز كما قد تتسبب في إحداث حريق.

التنظيف الداخلي

يجب عليك تنظيف الجهاز من الداخل بصفة منتظمة. تسهل عملية التنظيف عندما تكون كمية الطعام قليلة داخل الثلاجة. امسح المجمد من الداخل باستخدام محلول بيكرينات الصودا المخفف ثم اشطفه بالماء الدافئ باستخدام اسفنجة أو قطعة قماش. جفف المكان تمامًا قبل إعادة تركيب الأرفف والأدرج. جفف جميع الأسطح والأجزاء القابلة للإزالة تمامًا.

بالرغم من أن هذا الجهاز يتخلص من الثلج تلقائيًا، قد تتكون طبقة من الثلج على الجدران الداخلية للمجمد إذا تم فتح باب المجمد بشكل متكرر أو ظل مفتوحًا لفترة طويلة. إذا كان الثلج المترامك سميكًا جدًا، اختر وقت حيث يكون مخزون الطعام منخفضًا واتبع الخطوات التالية:

1. أزل الطعام الموجود وعب الكسورات، ثم قم بفصل الجهاز من القابس الرئيسي واترك الأبواب مفتوحة. قم بتهوية الغرفة جيدًا لتسريع عملية الذوبان.
2. عند إكمال ذوبان الثلج، نظف المجمد على النحو الموضح أعلاه.

سوف يتكون بعض الثلج في مناطق معينة داخل مقصورة

استكشاف الأخطاء وإصلاحها

إذا واجهت مشكلة مع جهازك أو كنت قلقا من أن الجهاز لا يعمل بشكل صحيح، يمكنك القيام ببعض الفحوصات السهلة قبل الاتصال بالخدمة، يرجى الإطلاع على ما يلي. يمكنك القيام ببعض الفحوصات البسيطة وفقا لهذا القسم قبل الاتصال بالخدمة.

تحذير! لا تحاول تصليح الجهاز بنفسك. إذا ظلت المشكلة قائمة بعد إجراء الفحوصات المذكورة أدناه، اتصل بكهربائي مؤهل أو مهندس صيانة معتمد أو المحل الذي اشتريته منه المنتج.

مشكلة	السبب المحتمل والحل
الجهاز لا يعمل بشكل صحيح	تحقق إذا ما كان سلك الطاقة مثبت جيدا في مآخذ الطاقة أم لا.
	تحقق من الصمام أو الدائرة الكهربائية الخاصة بك واستبدلها إذا لزم الأمر.
	درجة الحرارة المحيطة منخفضة جدًا. حاول ضبط درجة حرارة الغرفة على مستوى أكثر برودة لحل هذه المشكلة.
	من الطبيعي ألا يعمل المجمد أثناء دورة الإذابة التلقائية، أو لفترة قصيرة بعد تشغيل الجهاز لحماية الضاغط.
روائح صادرة عن المقصورات	قد تحتاج المقصورات الداخلية إلى التنظيف تتسبب بعض الأطعمة والحاويات واللجانف في إصدار روائح.
ضوضاء صادرة عن الجهاز	تعتبر الأصوات التالية أصواتا عادية: • أصوات صادرة عن تشغيل الضاغط • ضجيج حركة الهواء الصادر عن مروحة الموتور الصغيرة في المجمد أو غيره من الجزاء. • صوت غرغرة يشبه صوت غليان الماء. • صوت فرقعة أثناء عملية التخلص من الثلج التلقائية. • ضجيج يشبه النقر قبل بدء عمل الضاغط.
	هناك ضوضاء أخرى غير عادية ناجمة عن الأسباب المذكورة أدناه وقد تحتاج إلى الفحص واتخاذ إجراء: الخزانة ليست مستوية الجزء الخلفي للجهاز يلامس الجدار. سقوط الزجاجات أو الأوعية أو تدحرجها.
الموتور يعمل بشكل مستمر	من الطبيعي أن تسمع في كثير من الأحيان صوت الموتور، فسوف يعمل بشكل زائد في الحالات التالية: • تم ضبط درجة الحرارة أبرد من اللازم • تم تخزين كمية كبيرة من الطعام الساخن مؤخرًا داخل الجهاز • درجة الحرارة خارج الجهاز مرتفعة للغاية. • تم فتح الأبواب لفترة طويلة أو يتم فتحها بشكل متكرر. • بعد تركيب الجهاز أو إيقاف تشغيله لفترة طويلة.
تكون طبقة من الثلج في المقصورة	تحقق من عدم انسداد منافذ الهواء بالاطعمة وتأكد من وضع الطعام داخل الجهاز بشكل صحيح للسماح بالتهوية الكافية. تأكد من أن الباب مغلق بشكل كامل. للتخلص من الثلج، يرجى الرجوع إلى الفصل الخاص بالتنظيف والاهتمام بالجهاز.
درجة الحرارة الداخلية مرتفعة للغاية	ربما كنت قد تركت الأبواب مفتوحة لفترة طويلة أو بشكل متكرر؛ أو ظلت الأبواب مفتوحة بسبب بعض العقبات؛ أو تم وضع الجهاز دون ترك مساحة كافية خلفه وأعلى
درجة الحرارة الداخلية شديدة البرودة	يمكنك زيادة درجة الحرارة باتباع فصل "ضوابط العرض".

<p>تحقق ما إذا كان الجزء العلوي للثلاجة يميل بمقدار 10-15 مم للسماح بالغلاق الذاتي للأبواب، أو إذا ما كان هناك شيء يمنع الأبواب من الإغلاق.</p>	<p>لا يمكن غلق الأبواب بسهولة</p>
<p>قد لا يكون وعاء المياه (الموجود في الجزء السفلي الخلفي للخزانة) موضوعا بالشكل الصحيح، أو قد لا تكون فوهة الصرف (الموجودة تحت مستودع الضاغط) موضوعة بشكل صحيح لتوجيه المياه نحو هذا الوعاء، أو تكون فوهة المياه مسدودة. قد تحتاج إلى سحب الثلجة بعيدا عن الجدار لفحص وعاء المياه وفوهة الصرف.</p>	<p>قطرات ماء على الأرض</p>
<p>• قد يكون مصباح LED أصابه التلف. يرجى الرجوع إلى إنارة LED في فصل التنظيف والاهتمام. • عطل نظام التحكم الإنارة بسبب فتح الباب لفترات طويلة، إغلق الباب وأعد فتحه لإعادة تنشيط الإنارة.</p>	<p>الضوء لا يعمل</p>

التخلص من الجهاز

يحظر التخلص من هذا الجهاز باعتباره نفايات منزلية.

مواد التعبئة والتغليف

تعتبر مواد التعبئة والتغليف التي تحمل رمز إعادة التدوير قابلة لإعادة تدويرها. تخلص من مادة التعبئة في وعاء جمع النفايات المناسب لهذا الغرض لإعادة تدويرها.

قبل التخلص من الجهاز

1. انزع قابس الطاقة من المأخذ الرئيسي.

2. اقطع سلك الكهرباء وأزح القابس الرئيسي

تحذير! تحتوي الثلاجات على غاز تبريد وغازات في العزل. يجب التخلص من غاز التبريد والغازات الأخرى بطريقة مهنية حيث قد تسبب هذه الغازات في وقوع إصابات بالعين أو حدوث اشتعال. تأكد من عدم تلف أنابيب دائرة التبريد قبل التخلص من الجهاز بالشكل السليم.

التخلص السليم من هذا المنتج	
<p>تشير هذه العلامة إلى أنه لا ينبغي التخلص من هذا الجهاز مع غيره من المخلفات المنزلية في جميع أنحاء أوروبا. ولمنع أي إضرار محتمل بالبيئة أو صحة الإنسان ينتج عن التخلص غير المنظم للنفايات، ينبغي إعادة تدويرها بشكل مسؤول لتشجيع إعادة الاستخدام المستدامة للموارد المادية. لإرجاع جهازك المستخدم، يرجى استخدام نظم الإرجاع والجمع أو الاتصال بتاجر التجزئة حيث قد تم شراء المنتج. بوسعهم أخذ هذا المنتج وإعادة تدويره بصورة آمنة على البيئة.</p>	 

Hisense