

Key Finder 系列产品					
产品名称	Smart Card 说明书	尺寸	单页：54x86mm	日期	更改内容
文件编号		材质	80g 书写纸	2025/4/16	产品图简化，增加 FCC 警示语
设 计	Jafir	印刷	单黑双面印刷 风琴折		版本
					v1.2



Card Finder

User Manual



The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOs are trademarks of Apple inc. IOS is a trademark or registered trademark of Cisco in the US, and other countries and is used under license.

Quick Start Gdide

1. Turn on the device
Press and hold the button for 5 seconds, the device will beep and turn on.
2. Pair the device
 - Open the Find My APP
 - Hold the device close to your iPhone, tap the Items tab, tab + and then Add Other Item.
 - Tap Connect
 - Type a name for your device, selectan emoji.
 - Tap Agree to acknowledge that this item will be linked to your Apple ID.
 - Tap Finish
3. Enable Lost Mode
 - Open the Find My app, tap the items tab, then tap your item.
 - Under Lost Mode, tap Enable.
 - Read the instructions, tap Continue and enter a phone number or email address.
 - Confirm the information, customize the lost message, and tap Activate to complete the setup.
4. Remove the device
 - Open the Find My app, tap the Items tab, then tap your item.
 - Tap Remove Item and the tap Remove to complete the operation.

Note: After removing the device in the app, the device will beep and the light will flash six times.it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state, and the device and app cannot be paired at this time.If you need to pair the device, you need to click the device button once, the device will ring and the light will flash once. At this point,The device enters the pairing state and can be re-paired with the app.

Instructions for device button

1. Power on
Long press the button for five seconds, the device will beep, the light will flash three times, and the device will be turned on.
2. Device status confirmation
Double-click the device button, the device will beep, and the light will flash three times, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.
3. The device enters the pairing state again
After removing the device in the app, the device will beep and the light will flash six times, it will not shut down and will be in the pairing mode. If there is no re-pairing within 10 minutes, the device will leave the pairing state. If you want to pair a device at this time, you need to click the device button

正面

1

2

3

背面

once, the device will beep, and the light will flash once.At this time, the device enters the pairing state and can be paired with the app again.

4. Factory Reset

First, remove the item from Find My app then, after the device is powered on, double-click the device button. The device will beep. Long press the device button for eight seconds until the device beeps and the light flashes three times. Release the button to complete factory reset. The device can now be paired.

5. Power off

When the device is on, press the device button 5 times in 2 seconds. The device will beep, the light will flash three times, the device will be powered off.

FAQ

1. How to confirm whether the device has been turned on?

Double-click the device button, the device will beep, indicating that the device is working. If the device does not ring, the device is off. Long press the button for five seconds to turn it on.

2. When can the device be located?

When an item is separated from its owner for a period of time, it can be found by othe rApple devices that are part ofthe Find My network, and the owner can start to get the location of the device.


4



How to Charge the Finder?

1. Connect your wireless charger to power. User the power adapter that came with your accessory or power adapter recommended by the manufacturer.
2. Place the Card Finder on your charger. For best performance, place the wireless charging area in the center of the charger or in the location recommended by manufacturer.
3. The LED indicator in the card will be ON in red, indicating it is charging.

Product Overview



5

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

6