

Contents [[hide](#)]

- [1 MAHLE iWoc ONE Cycle Remote Control](#)
- [2 Description](#)
- [3 Charging the Battery](#)
- [4 Component Maintenance](#)
- [5 INSTRUCTIONS FOR USE](#)
- [6 PAIRING](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)

MAHLE


MAHLE iWoc ONE Cycle Remote Control



Description


- A System Start
- B System OK
- C Battery Charge Level

- D Assistance Level
- E Demo Mode
- F Bluetooth Operation
- N Notification
- L Turn On/Off Lights
- Y Safe Mode
- X System Error
- Z System Shutdown




Charging the Battery

Connect the charger first to a power outlet and then to the charging port on the bicycle. The light on the iWoc@ ONE will turn on automatically. While charging, the intensity of the LED will vary cyclically, indicating by color the current level of battery charge. The battery will be charged (>98%) when the LED remains lit in white.



MAHLE SmartBike App

MAHLE SmartBike APP provides you an advanced level of interaction with your e-bike, knowing its status and recording your training from your mobile. New functionalities: Better Data & Visualization, Dark Mode, Biometric Authentication, Dashboards, Range Extender screen, customizable Motor Maps and many more.



Component Maintenance

- The components of your eBike are associated with your frame number. If a component is replaced, it must be linked to your bike through a special system available at all technical service centers and shops authorized by your brand. Visit one of these points to complete the purchase and replacement operation. The components of your e-bike are designed to be used in poor weather conditions, such as rain and snow, and are protected against splashing, but not against immersion or pressurized water. It is important when transporting your eBike outside on a car or camper to properly protect the bike, or at least the most delicate electronic parts, such as the remote control, display and USB port, with a tarp.
- Keep the remote control free of dust and water. Never use pressurized water systems on the surface of the battery, motor, remote control, display or charging port.



INSTRUCTIONS FOR USE



TURNING ON AND OFF THE BICYCLEIS ELECTRICAL SYSTEM



- Short Button Press



- Turns on the system

-  Long Button Press
-  Turns off the system





CHANGING THE LEVEL OF ASSISTANCE

Short press the button and the RGB LED will blink, indicating the current assistance mode. If you short press it again while the LED is blinking, you will change the assistance level cyclically.





TURNING ON/OFF THE LIGHTS

Short press the button and while the LED is blinking, long press the button. The LED will light up in YELLOW to confirm you want to turn on/off the lights.

-  Current level of assistance
-  +  Long Button Press
-  Lights = ON/ OFF

PAIRING

BLUETOOTH PAIRING AND NOTIFICATIONS

-  When the bicycle is turned on, the system automatically connects to the closest telephone with an activated Bluetooth® connection. The connection or disconnection is confirmed when the LED lights up briefly in BLUE.
-  If you receive a notification (call, etc.) on your telephone while connected via

Bluetooth@, the RGB LED will light up in LIGHT BLUE for a few moments.


SYSTEM ERROR AND SPECIAL MODES



- If the RGB LED remains lit in PINK the bike is in SAFE MODE. Take it to your nearest store to diagnose the problem.



- If the RGB LED blinks constantly in PINK, there is an error in the system. Connect your mobile terminal by Bluetooth@ to see a detailed description or visit an authorized store for more information on the error. If the problem is serious, the system may stop providing assistance.



- The bicycle is in DEMO MODE and can only be ridden for 50 KM. This mode can only be deactivated by an authorized store. The second blinking in this mode indicates the current battery

MAHLE SmartBike User Web App

If you need better data, visualization and a dynamic experience, the web app enables you to manage functionalities as Privacy Zones and Locate my e-bike and analyze the routes in detail to graphically compare data as: elevation, health-related data and exclusive metrics from the e-bikes and the tour on the maps and share it through third platforms as STRAVATM, Facebook or Twitter.



Documents / Resources



[MAHLE iWoc ONE Cycle Remote Control \[pdf\]](#) User Guide

iWoc ONE Cycle Remote Control, iWoc ONE, Cycle Remote Control, Remote Control, Control, Remote

References

- [User Manual](#)

control, Cycle Remote Control, iWoc ONE, iWoc ONE Cycle Remote Control, MAHLE, remote, Remote

MAHLE Control

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.